Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TRESKO 1041

TRESKO® Foldable Garden Cart User Manual

Model: 1041

Introduction

Thank you for choosing the TRESKO® Foldable Garden Cart. This versatile and robust transport solution is designed to assist you with various outdoor activities, from gardening and camping to beach trips and family outings. Its foldable design ensures easy storage and portability, while features like the adjustable handle, solid rubber tires, and braking system provide convenience and safety. This manual provides essential information for the proper setup, operation, maintenance, and troubleshooting of your new garden cart.



Figure 1: TRESKO® Foldable Garden Cart with roof and accessories.

This image displays the TRESKO® Foldable Garden Cart in its fully assembled state, highlighting its green fabric, sturdy frame, and removable roof. Smaller insets show the cart in its compact, folded form, emphasizing its portability and ease of storage, along with a view of the insulated cooler bag.

Setup

The TRESKO® Garden Cart is designed for quick and easy setup. It arrives largely pre-assembled, requiring minimal effort to prepare for use.

Unfolding the Cart

1. Place the folded cart on a flat, stable surface.
2. Grasp the handle and pull upwards to extend the frame. The cart will begin to unfold.
3. Push down on the center of the cart's base until it locks into place, ensuring the frame is fully extended and stable.
4. Attach the removable roof by inserting its support poles into the designated slots on the cart's frame. Ensure it is securely fastened.

5. Adjust the handle to your desired height and angle for comfortable pushing or pulling.



Figure 2: Unfolding and folding mechanism of the cart.

This image illustrates the compact folded state of the cart and the simple steps to unfold it for use. It shows the cart transforming from a portable package to its full size, ready for transport.



Figure 3: Handle adjustment and smart folding function.

This visual demonstrates the adjustable handle, allowing users to customize its height and angle for comfortable pulling or pushing. It also highlights the intelligent folding mechanism that enables quick setup and compact storage.

Operating Instructions

The TRESKO® Garden Cart is designed for ease of use and versatility in various environments.

Transporting Goods

- **Loading:** Place items evenly within the cart's cargo area. Do not exceed the maximum load capacity of 80 kg (176 lbs).
- **Handle Adjustment:** The handle can be adjusted for both pushing and pulling. Use the integrated spring mechanism to adjust the handle's height and angle for optimal comfort and control.
- **Maneuvering:** The front wheels feature a 360° swivel function, allowing for easy steering and navigation in tight spaces.

Braking System

- **Front and Rear Brakes:** The cart is equipped with both front and rear brakes for enhanced safety and control. Engage the brakes by pressing down on the red levers located near the wheels.
- **Parking Brake:** For stationary use, ensure both front and rear brakes are engaged to prevent the cart from rolling.



Figure 4: Safety features of the TRESKO® Garden Cart.

This image highlights the cart's safety mechanisms, including the effective parking brake, supplementary brake for optimal safety, and the 360-degree swivel front wheels. It also shows the adjustable steering bar for improved control.

Using the Harness System (for children)

- The cart includes a 2 x 3-point harness system for securing small children during transport.
- Ensure children are seated properly and the harnesses are securely fastened before moving the cart.
- Always supervise children when they are in the cart.



Figure 5: 3-point harness system and load capacity.

This image emphasizes the dual 3-point harness system designed for secure transport of children, alongside an icon indicating the cart's robust 80 kg load capacity. It also shows the ergonomic handle and the removable sun roof.

Roof and Storage Features

- **Removable UV Protection Roof:** The included roof provides protection from sun and light rain. It can be easily attached or removed as needed.
- **Rear Carry Bag:** An additional removable carry bag is located at the rear for extra storage.
- **Side Pockets:** Utilize the various side pockets for organizing smaller items.



Figure 6: Flexible protection features.

This image details the cart's flexible protection options, including the easily adjustable and removable roof, and the ability to secure the cart with additional Velcro straps against wind. It also mentions the inclusion of three removable side panels for versatile use.

Recommended Uses

The TRESKO® Garden Cart is ideal for:

- Gardening tasks
- Beach trips (transporting towels, coolers, toys)
- Camping excursions
- Shopping and errands
- Family outings and picnics



Figure 7: Versatile usage scenarios.

This image illustrates the cart's adaptability for various outdoor settings, including the beach, garden, and camping. It also highlights the integrated cooler bag, capable of keeping drinks cool for several hours, and its UV and weather-resistant properties.

Maintenance

Proper maintenance will extend the life and performance of your TRESKO® Garden Cart.

- **Cleaning:**
  - Wipe down the metal frame with a damp cloth and mild detergent if necessary. Dry thoroughly to prevent rust.
  - The fabric (600D Oxford with PU coating) can be spot cleaned with a damp cloth and mild soap. Do not machine wash.
  - Clean wheels regularly to remove dirt, sand, or debris that may affect their movement.
- **Storage:**
  - Always fold the cart for compact storage when not in use.

- Store the cart in a dry, cool place, away from direct sunlight and extreme temperatures, to preserve the fabric and frame integrity.
- If storing for extended periods, ensure the cart is clean and dry to prevent mold or mildew.

- **Inspections:**
  - Periodically check all bolts, screws, and connections to ensure they are tight and secure. Tighten any loose fasteners.
  - Inspect the wheels and axles for any signs of wear or damage.
  - Check the fabric for tears or excessive wear.

Troubleshooting

This section addresses common issues you might encounter with your TRESKO® Garden Cart.

Problem	Possible Cause	Solution
Cart does not unfold or fold smoothly.	Mechanism obstructed or not fully engaged.	Ensure no fabric or debris is caught in the folding mechanism. Push down firmly on the center base until it clicks into place.
Wheels wobble or cart pulls to one side.	Loose wheel bolts or damaged wheel/axle.	Check and tighten all wheel bolts. Inspect wheels for damage. If damage is significant, contact customer support.
Brakes are not effective.	Brake mechanism dirty or misaligned.	Clean any debris from the brake mechanism. Ensure the brake levers are fully engaged.
Handle feels loose or detaches.	Loose connection points or worn locking mechanism.	Check and tighten any visible screws or bolts on the handle assembly. Ensure the handle's locking mechanism is fully engaged. If the issue persists, contact customer support.
Roof does not stay in place.	Support poles not fully inserted or strong wind.	Ensure roof support poles are fully inserted into their slots. Use the additional Velcro straps to secure the roof in windy conditions.

If you encounter a problem not listed here, or if the suggested solutions do not resolve the issue, please contact TRESKO customer support for assistance.

Specifications

Key technical specifications for the TRESKO® Foldable Garden Cart, Model 1041.

Feature	Detail
Brand	TRESKO
Model Number	1041
Color	Green

Feature	Detail
Assembled Dimensions (L x W x H)	124 x 56 x 108 cm (approx. 48.8 x 22 x 42.5 inches)
Folded Dimensions (L x W x H)	79 x 56 x 25 cm (approx. 31.1 x 22 x 9.8 inches)
Loading Area Dimensions (L x W)	76 x 42 cm (approx. 29.9 x 16.5 inches)
Rear Pocket Dimensions (L x W x H)	39 x 18 x 16 cm (approx. 15.3 x 7.1 x 6.3 inches)
Maximum Weight Capacity	80 kg (approx. 176 lbs)
Item Weight	12 kg (approx. 26.5 lbs)
Material	Steel tube frame, 600D Oxford fabric with PU coating, ABS plastic and rubber wheels
Special Features	Foldable, Robust, Front & Rear Brakes, 360° Swivel Front Wheels, Adjustable Handle, 2 x 3-point Harness System, Removable UV Protection Roof, Rear Carry Bag, Side Pockets
Tire Type	Solid Rubber (Tubeless)



Figure 8: Exact dimensions of the TRESKO® Garden Cart.

This diagram provides precise measurements for the assembled cart, its loading area, and the additional rear pocket, ensuring users have all necessary dimensional information for planning and storage.

Warranty and Support

Specific warranty details for the TRESKO® Foldable Garden Cart are not provided within this manual. For information regarding warranty coverage, claims, or technical support, please refer to the product packaging or visit the official TRESKO website. You may also contact the retailer from whom you purchased the product.

For spare parts availability, the provided product information indicates "Information indisponible sur les pièces détachées" (Information unavailable on spare parts). Please contact TRESKO customer service for further inquiries regarding replacement components.

© 2025 TRESKO®. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B092VQRKSG

More documents and user manuals: **https://manuals.plus/**