Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sandoo SC1110

Sandoo SC1110 Handheld Steam Cleaner Instruction Manual

Model: SC1110

1. Introduction

Thank you for purchasing the Sandoo SC1110 Handheld Steam Cleaner. This device uses high-temperature, high-pressure steam to clean and sanitize various surfaces without the need for chemical detergents. Please read this manual thoroughly before use to ensure safe and effective operation.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and personal injury.

- Always ensure the safety cap is securely closed before operating. The cap is designed not to open until the internal pressure has safely decreased.
- This appliance features a child lock. Ensure the child lock is engaged when not in use and understand its operation before releasing steam.
- The temperature lamp indicates heating status. It will turn off automatically when the device is ready for use. The power will automatically cut off if the temperature becomes abnormally high.
- Do not direct steam at people, pets, or electrical appliances.
- Use only clean tap water. Do not add detergents, perfumes, or other chemicals to the water tank.
- Unplug the appliance from the power outlet when not in use and before cleaning or maintenance.
- Keep the appliance out of reach of children.

セーフティキャップを付きの特殊ナット
安全安心



Image: Safety features including the safety cap, child lock, and temperature lamp for secure operation.



Image: The steam cleaner is designed with safety in mind for households with children, featuring high-temperature protection.

3. Package Contents

Your Sandoo SC1110 Handheld Steam Cleaner package includes the main unit and 9 versatile accessories:

- Sandoo SC1110 Main Unit
- Long Nozzle
- Cloth Nozzle
- Window Nozzle
- Brush Nozzle
- L-shaped Nozzle
- Measuring Cup
- Funnel
- Cleaning Cloth



Image: The Sandoo SC1110 steam cleaner with its complete set of accessories.

4. Product Features

- **Detergent-Free Cleaning:** Utilizes high-temperature steam (over 100°C) for effective cleaning, deodorizing, and pest removal without chemicals, making it safe for homes with children and pets.
- **High-Pressure Steam:** Generates steam at up to 4.2 bar with 1000W power, providing strong penetration to remove embedded dirt, limescale, and grease.
- **Ample Steam Output:** Delivers 25-35g/min of steam. The 350ml water tank allows for approximately 8-10 minutes of continuous use or over 15 minutes of intermittent use with 250ml of water.
- **Enhanced Safety:** Features a safety cap that prevents opening under pressure, a child lock, and a temperature lamp with automatic power cut-off for overheating protection.
- **Versatile Attachments:** Includes 9 accessories, such as a 360° rotating nozzle, long nozzle, brush nozzle, cloth nozzle, window nozzle, and L-shaped nozzle, for cleaning various surfaces and areas.



Image: Operational principle of the steam cleaner, showing water boiling and converting to high-temperature steam.

5. Setup

Follow these steps to prepare your steam cleaner for use:

1. **Fill Water:** Unscrew the safety cap. Use the provided measuring cup and funnel to fill the water tank with up to 350ml of clean tap water. Do not overfill.
2. **Close Cap:** Securely screw the safety cap back on until it is tight.
3. **Attach Nozzle:** Select the appropriate nozzle for your cleaning task and attach it firmly to the steam outlet.
4. **Plug In:** Insert the power plug into a suitable electrical outlet. The temperature lamp will illuminate, indicating that the device is heating.
5. **Wait for Heating:** Wait for the temperature lamp to turn off. This indicates that the water has reached the optimal temperature and pressure, and the steam cleaner is ready for use. This typically takes a few minutes.



Image: Simple 4-step setup process: fill water, close cap, plug in, and wait for the lamp to extinguish.

6. Operating Instructions

Once the steam cleaner is ready (temperature lamp off), you can begin cleaning.

1. **Release Child Lock:** Push the child lock button to the 'unlocked' position.
2. **Press Steam Button:** Press and hold the steam release button to emit steam. Release the button to stop the steam flow.
3. **Clean Surface:** Direct the steam towards the surface you wish to clean. For stubborn stains, hold the nozzle closer to the surface for a few seconds to allow the steam to penetrate.
4. **Wipe Clean:** Immediately wipe the steamed area with a clean cloth to remove loosened dirt and moisture.
5. **Continuous vs. Intermittent Use:** For continuous steam, the tank provides 8-10 minutes of operation. For longer cleaning sessions, use intermittently, allowing the device to reheat if the steam output decreases.

Using Different Attachments:

- **Long Nozzle:** Ideal for reaching tight spaces, corners, and crevices.

- **Brush Nozzle:** Use with the brush attachment for scrubbing stubborn dirt on surfaces like grout, stovetops, and grills.
- **Cloth Nozzle:** Attach a cleaning cloth to this nozzle for general cleaning of larger flat surfaces, floors, or upholstery.
- **Window Nozzle:** Perfect for streak-free cleaning of windows, mirrors, and other glass surfaces.
- **L-shaped Nozzle:** Designed for cleaning hard-to-reach angles and curved surfaces.



Image: Cleaning a stovetop with the steam cleaner, highlighting its high-pressure steam for grease removal.



Image: Cleaning bathroom tiles, demonstrating the ample steam output for wide-area cleaning.



Image: The steam cleaner with its diverse attachments, suitable for cleaning floors, stovetops, fabrics, and windows.

7. Maintenance

Regular maintenance ensures optimal performance and extends the life of your steam cleaner.

- **Empty Water Tank:** After each use, unplug the appliance and allow it to cool completely. Carefully unscrew the safety cap and empty any remaining water from the tank.
- **Clean Exterior:** Wipe the exterior of the steam cleaner with a damp cloth. Do not use abrasive cleaners or solvents.
- **Clean Nozzles/Attachments:** Rinse all attachments with water and allow them to air dry before storing. For stubborn residue, a small brush can be used.
- **Descaling (Periodically):** If you notice reduced steam output or mineral buildup, descaling may be necessary. Consult the manufacturer's website or customer support for recommended descaling procedures. Generally, a solution of water and white vinegar can be used, but always follow specific instructions to avoid damage.
- **Storage:** Store the steam cleaner and its accessories in a cool, dry place, out of reach of children.

8. Troubleshooting

If you encounter issues with your Sandoo SC1110, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No steam or very little steam	Water tank empty; Not fully heated; Child lock engaged; Mineral buildup.	Refill water tank; Wait for temperature lamp to turn off; Disengage child lock; Perform descaling.
Steam is not hot enough	Not fully heated; Continuous use has cooled the element.	Wait for the temperature lamp to turn off; Allow the unit to reheat for a few moments between bursts of steam.
Safety cap cannot be opened	Internal pressure is still high.	Unplug the unit and allow it to cool down completely. Press the steam button to release any residual pressure.
Water leaks from nozzle	Nozzle not properly attached; Unit not fully heated.	Ensure nozzle is securely attached; Wait for the temperature lamp to turn off before use.

If the problem persists after trying these solutions, please contact Sandoo customer support.

9. Specifications

Feature	Specification
Brand	Sandoo
Model Name	SC1110
Form Factor	Handheld
Special Feature	Child Lock
Recommended Uses	Windows, Bathroom, Kitchen, Toilet, Entryway

Feature	Specification
Voltage	220 Volts
Color	Yellow
Water Tank Capacity	Approx. 350ml
Steam Pressure	Up to 4.2 bar
Steam Output	25-35 g/min
Power	1000W

10. Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Sandoo website. Keep your proof of purchase for any warranty claims.

© 2023 Sandoo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B092VV19CY

More documents and user manuals: **https://manuals.plus/**