Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Frigidaire EFR753

Frigidaire EFR753 Retro Apartment Size Refrigerator User Manual

Model: EFR753

1. Important Safety Information

Read all instructions before using this appliance to reduce the risk of fire, electric shock, or injury to persons. Keep this manual for future reference.

Electrical Safety

- Ensure the refrigerator is connected to a properly grounded 120V, 60Hz electrical outlet.
- Do not use extension cords or ungrounded adapters.
- Never unplug the appliance by pulling on the power cord. Always grasp the plug firmly and pull straight out from the outlet.
- Before cleaning or making repairs, always unplug the refrigerator.

General Safety

- This appliance is intended for household use only.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not damage the refrigerant circuit.
- Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.

2. Product Overview

The Frigidaire EFR753 is a 7.5 cubic foot retro-style apartment size refrigerator with a top freezer. It features adjustable spill-proof glass shelves, door bins, and a crisper bin for organized storage.




Frigidaire



Front view of the Frigidaire EFR753 Retro Apartment Size Refrigerator in Mint color.



The Frigidaire EFR753 refrigerator integrated into a modern kitchen environment.

3. Installation and Setup

Unpacking

- Remove all packaging materials, including the foam base and adhesive tape.
- Inspect the refrigerator for any damage. Report any damage to your retailer immediately.
- Clean the interior and exterior surfaces with a soft cloth and lukewarm water before use.

Location Requirements

- Place the refrigerator on a flat, solid surface strong enough to support it when fully loaded.
- Allow at least 5 inches (12.7 cm) of space between the back and sides of the refrigerator and any adjacent walls or cabinets for proper air circulation.
- Avoid direct sunlight or heat sources (e.g., stove, heater) as this will increase energy consumption.
- Ensure the ambient temperature is between 50°F (10°C) and 90°F (32°C) for optimal performance.

Leveling

The refrigerator must be level for proper operation. Adjust the leveling legs at the bottom front of the unit by turning them clockwise to raise or counter-clockwise to lower.



Illustration highlighting key features including adjustable leveling legs, interior light, quiet operation, and flush back design.

Door Reversal

This model features a reversible door hinge, allowing for left or right-handed opening. Refer to the detailed instructions in the full PDF user guide for the specific steps to reverse the door swing.

Electrical Connection

After positioning and leveling, wait at least 4 hours before plugging the refrigerator into a power outlet. This allows the refrigerant to settle. Connect the appliance to a dedicated 120V, 60Hz, 15 Amp circuit.

4. Operating Instructions

Temperature Control

The refrigerator features easy-to-use mechanical controls for temperature management. The temperature control knob is located inside the fresh food compartment. Settings typically range from 1 (warmest) to 7 (coldest). A setting of 3-5 is generally recommended for typical residential use.



Interior layout of the refrigerator, indicating the temperature control dial, freezer compartment, interior lighting, adjustable glass shelves, transparent door shelves, and crisper bin.

Storage Features

- **Adjustable Glass Shelves:** Three spill-proof glass shelves can be adjusted to accommodate items of various heights.
- **Door Bins:** Multiple bins on the door provide convenient storage for bottles, jars, and smaller items.
- **Crisper Bin:** A dedicated crisper bin with a glass cover helps maintain optimal humidity for fresh fruits and vegetables.
- **Freezer Compartment:** The top freezer includes a wire shelf and a door bin for frozen food storage.

Defrosting

This refrigerator utilizes a convenient cycle defrost system for the fresh food compartment. The freezer compartment requires manual defrosting when frost accumulation reaches approximately 1/4 inch (0.6 cm) thick. To manually defrost the freezer:

1. Unplug the refrigerator from the power outlet.
2. Remove all food items from the freezer and place them in a cooler.
3. Leave the freezer door open to allow frost to melt naturally. Place towels on the floor to absorb water.
4. Once defrosted, clean and dry the interior thoroughly.
5. Plug the refrigerator back in and return food items once the temperature has stabilized.

5. Care and Maintenance

Cleaning

- **Interior:** Clean the interior regularly with a solution of mild soap and warm water. Rinse and dry thoroughly. Do not use abrasive cleaners or harsh chemicals.
- **Exterior:** Wipe the exterior surfaces with a soft cloth and mild detergent. For the chrome handles, use a non-abrasive cleaner designed for chrome.
- **Door Gaskets:** Clean door gaskets regularly to ensure a proper seal.

Power Outage

In case of a power outage, keep the refrigerator and freezer doors closed as much as possible to maintain internal temperatures. Food should remain frozen for several hours. If the outage is prolonged, consider transferring perishable items to a cooler with ice.

Vacation and Storage

- **Short Vacations:** Leave the refrigerator operating.
- **Long Vacations/Storage:** Unplug the refrigerator, empty all contents, defrost the freezer, clean the interior, and leave the doors slightly ajar to prevent odors and mold growth.

6. Troubleshooting

Before contacting customer service, review the following common issues and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Refrigerator does not operate	No power to the unit; Temperature control set to 'OFF' or too warm.	Check power cord connection and circuit breaker. Adjust temperature control to a colder setting.
Temperature is too warm	Door left open; Large amount of warm food added; Poor air circulation; Temperature control set too warm.	Ensure door is closed properly. Allow time for new food to cool. Ensure adequate space around the unit. Adjust temperature control to a colder setting.
Excessive noise	Refrigerator not level; Items vibrating inside.	Adjust leveling legs. Ensure bottles and containers are not touching.
Water on floor	Drain pan overflowing (during defrost); Door not sealing properly.	Ensure drain pan is correctly positioned. Check door gasket for proper seal.

7. Specifications

Detailed technical specifications for the Frigidaire EFR753 Retro Apartment Size Refrigerator:



Key dimensions of the Frigidaire EFR753 refrigerator: 21.5"D x 23.2"W x 55.5"H.

Feature	Detail
Brand	Frigidaire
Model Number	EFR753
Capacity (Total)	7.5 Cubic Feet
Fresh Food Capacity	6.5 Cubic Feet
Freezer Capacity	1 Cubic Foot
Product Dimensions (D x W x H)	23 x 24 x 57 inches
Item Weight	76 Pounds
Installation Type	Freestanding

Feature	Detail
Form Factor	Top Freezer
Number of Doors	2
Defrost System	Manual (Freezer), Cycle (Refrigerator)
Voltage	120 Volts
Annual Energy Consumption	20 Kilowatt Hours
Shelf Type	Recessed Glass
Crispers/Drawers	1
Door Hinges	Right (Reversible)

8. Warranty Information

Warranty information for the Frigidaire EFR753 refrigerator is typically provided with the product at the time of purchase. Please refer to the warranty card or documentation included in your product packaging for specific terms, conditions, and registration details. You may also visit the official Frigidaire website or contact their customer support for the most current warranty information.

9. Customer Support

For further assistance, technical support, or to inquire about parts and service, please contact Frigidaire customer support. Contact details can typically be found on the Frigidaire official website or in the documentation provided with your appliance.
You can also refer to the officialUser Guide (PDF) for more detailed instructions and diagrams.

Frigidaire is a registered trademark. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B093177FGR

More documents and user manuals: **https://manuals.plus/**