Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Frigidaire FPRU19F8WF

Frigidaire Professional 19 cu. ft. Single Door Freezerless Refrigerator

Model: FPRU19F8WF

1. Setup

1.1 Unpacking and Placement

Carefully remove all packaging materials, including tape and foam. Ensure the refrigerator is placed on a level, stable surface away from direct sunlight or heat sources. Allow at least 1 inch (2.54 cm) of clearance on the sides and back for proper air circulation. The unit requires a dedicated 115V, 60 Hz, 15 Amp AC-only electrical outlet.



Image: The Frigidaire Professional single door freezerless refrigerator, showcasing its sleek stainless steel exterior and professional handle.

1.2 Initial Cleaning

Before first use, clean the interior and exterior of the refrigerator with a mild detergent and warm water. Rinse thoroughly and dry with a soft cloth. Do not use abrasive cleaners or harsh chemicals.

1.3 Initial Power On

After placement and cleaning, plug the refrigerator into the dedicated electrical outlet. Allow the unit to cool for at least 4 hours before loading with food. The internal temperature will stabilize over time.

2. Operating

2.1 Temperature Control

The temperature control is located inside the refrigerator compartment. Adjust the setting to your desired temperature. A recommended setting for optimal food preservation is 37°F (3°C).



Image: An empty interior view of the refrigerator, highlighting the spacious design and clear shelving.

2.2 CrispSeal Crispers

The CrispSeal Crispers are designed to maintain optimal humidity levels for fruits and vegetables, helping them stay fresh longer. Adjust the humidity slider on each crisper to suit the contents: higher humidity for leafy greens, lower for fruits.



Image: A detailed view of the CrispSeal Crispers, demonstrating their capacity for fresh produce and the humidity control mechanism.

2.3 Adjustable Shelving and Door Bins

The glass shelves and door bins can be repositioned to accommodate items of various sizes. To adjust a shelf, lift the front edge, pull it out, and reinsert it into the desired slots. Door bins can be lifted straight up and out for repositioning.



Image: A close-up of the refrigerator's door bins, showing their clear construction and how they can hold various bottled items.



Image: The refrigerator interior fully stocked with groceries, demonstrating its large storage capacity and organized layout.

3. Maintenance

3.1 Cleaning the Interior and Exterior

Regularly clean the interior with a solution of 2 tablespoons of baking soda to 1 quart (0.95 liters) of warm water. Wipe down the exterior with a soft cloth and mild soap. Pay special attention to door gaskets to ensure a tight seal.

3.2 Condenser Coil Cleaning

For optimal efficiency, clean the condenser coils located at the back or bottom of the refrigerator every 6-12 months. Unplug the unit before cleaning. Use a vacuum cleaner with a brush attachment to remove dust and debris.

4. Troubleshooting

4.1 Common Issues and Solutions

- **Refrigerator Not Cooling:** Check if the power cord is securely plugged in. Ensure the temperature control is set correctly. Verify that the door is fully closed and the gasket is sealing properly.
- **Unusual Noises:** Some operating noises are normal (e.g., hum of the compressor, gurgling of refrigerant). If noises are loud or unusual, ensure the refrigerator is level and not touching a wall or cabinet.
- **Excessive Moisture Inside:** Check if the door is frequently opened or left ajar. Ensure food items are properly covered.

4.2 When to Call for Service

If troubleshooting steps do not resolve the issue, or if you experience persistent problems, contact a qualified service technician. Do not attempt to repair the appliance yourself.

5. Specifications

Feature	Detail
Brand	Frigidaire Professional
Model Name	FPRU19F8WF
Model Number	329741097
Capacity	19 cu. ft. (18.6 cu. ft. usable)
Dimensions (H x W x D)	71.5 x 32.88 x 26.62 inches
Weight	510 Pounds
Finish	Stainless Steel
Special Features	CrispSeal Crispers, Adjustable Shelving

6. Warranty and Support

This Frigidaire Professional appliance comes with a limited warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including coverage duration and limitations. For technical support, service requests, or to register your product, please visit the official Frigidaire website or contact their customer service line. Keep your proof of purchase for warranty claims.

For further assistance, you may visit the Frigidaire Store on Amazon.

© 2024 Frigidaire. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B093FZC4NF

More documents and user manuals: **https://manuals.plus/**