Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

WUPYI B094QVZMNZ

WUPYI Electric Heating Lunch Box and Mini Rice Cooker User Manual

Model: B094QVZMNZ

1. Introduction

Thank you for purchasing the WUPYI Electric Heating Lunch Box and Mini Rice Cooker. This appliance is designed to heat and cook food, providing a convenient solution for meals at home, office, or school. Please read this manual thoroughly before use to ensure safe and efficient operation.

2. Safety Instructions

- Always ensure the voltage of the appliance matches your local power supply (110V for US plug).
- Do not immerse the main unit (base with electrical components) in water or any other liquid.
- When heating food, do not cover the transparent bowl lid. The transparent lid is for heat preservation and anti-spill only. Remove it during heating or cooking.
- During operation, the appliance will produce steam from the jet nozzle. Exercise caution to avoid burns. Do not touch the upper cover or handle when the machine is working.
- Keep out of reach of children.
- Unplug the appliance from the power outlet when not in use and before cleaning.
- Do not operate the appliance if the power cord or plug is damaged, or if the appliance malfunctions or has been damaged in any manner.
- This appliance is for household use only.

3. Package Contents

Upon unpacking, please verify that all items listed below are present and in good condition:

- 1 x Electric Lunch Box Main Unit
- 3 x Stainless Steel Bowls (0.37L each)
- 2 x Lids for Stainless Steel Bowls
- 1 x Steamed Egg Rack
- 1 x Measuring Cup

- 1 x Power Cord (US Plug)
- 1 x English Instruction Manual

4. Product Overview

The WUPYI Electric Heating Lunch Box features a two-layer design with a total capacity of 1.48L (4 x 0.37L bowls). It is constructed from food-grade PP material and 304 stainless steel for durability and safety.



Image 4.1: Front view of the WUPYI Electric Heating Lunch Box. It is white and grey with a handle on top and a power button at the bottom front.



Image 4.2: Dimensions of the WUPYI Electric Heating Lunch Box. The height is 21.8cm (8.58 inches), depth is 12.8cm (5.04 inches), and width is 26.3cm (10.35 inches).



Image 4.3: The WUPYI Electric Heating Lunch Box with its top lid removed, revealing the internal structure and two stainless steel bowls with lids.



Image 4.4: Four individual stainless steel bowls, each with a transparent lid, designed for food storage within the lunch box.

5. Setup and Assembly

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Before first use, wash the stainless steel bowls, their lids, and the steamed egg rack with warm soapy water. Wipe the main unit with a damp cloth. Ensure all parts are dry before assembly.
3. **Assemble:** Place the stainless steel bowls into the designated compartments within the main unit. If using the steamed egg rack, place it in the lower compartment.

6. Operating Instructions

Follow these steps for heating or cooking food:

1. **Add Water:** Open the top cover of the main unit. Add an appropriate amount of water to the bottom of the outer case. The amount of water determines the heating/steaming time. Refer to the measuring cup for guidance.
2. **Prepare Food:** Place your food into the stainless steel bowls. If cooking rice, add rice and water to a bowl. If steaming eggs, place eggs on the steamed egg rack.
3. **Position Bowls:** Place the filled bowls (with their lids removed if heating/cooking) into the main unit.
4. **Close and Secure:** Close the top cover of the lunch box and fasten the safety buckles on the sides.
5. **Connect Power:** Plug the power cord into the appliance and then into a 110V power outlet.
6. **Start Operation:** Press the power button located on the front of the unit. An indicator light will illuminate, signifying that the heating process has begun.

7. **Completion:** The appliance will automatically power off when the water in the base has evaporated, or when the set heating time is complete. The indicator light will turn off.
8. **Serve:** Carefully open the top cover, being mindful of hot steam. Use caution when removing the hot bowls.

Important Note: When heating or cooking, **do not** cover the transparent lids on the individual stainless steel bowls. These lids are for storage and heat preservation only. Remove them to allow steam to circulate effectively.

7. Maintenance and Cleaning

- **Unplug Before Cleaning:** Always unplug the appliance from the power outlet before cleaning.
- **Main Unit:** Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water or allow liquid to enter the internal electrical components.
- **Removable Parts:** The stainless steel bowls, their lids, and the steamed egg rack are removable and can be washed with warm soapy water or placed in a dishwasher. Ensure they are thoroughly dried before reassembly or storage.
- **Storage:** Store the appliance in a cool, dry place when not in use.

8. Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; power button not pressed.	Ensure the power cord is securely plugged into a working outlet. Press the power button.
Food is not heating properly.	Insufficient water in the base; transparent bowl lids are on; too much food.	Add more water to the base. Remove transparent lids from bowls during heating. Reduce food quantity if necessary.
Appliance automatically shuts off too quickly.	Not enough water added to the base.	Add more water to the base for longer heating times.
Excessive steam or water leakage.	Top cover not properly secured; safety buckles not fastened.	Ensure the top cover is correctly aligned and the safety buckles are securely fastened.

9. Specifications

- **Model:** B094QVZMNZ
- **Brand:** WUPYI
- **Color:** White+Grey
- **Capacity:** 1.48 Liters (4 x 0.37L bowls)
- **Material:** PP + 304 Stainless Steel
- **Voltage:** 110V
- **Plug Type:** US Plug
- **Product Dimensions:** 26.3 cm (10.35 in) x 12.8 cm (5.04 in) x 21.8 cm (8.58 in) (L x W x H)
- **Item Weight:** Approximately 2.86 pounds

- **Special Feature:** Multipurpose (Heating, Steaming, Cooking)

10. Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official WUPYI store on Amazon: WUPYI Store.
Please retain your proof of purchase for any warranty claims.

© 2023 WUPYI. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B094QVZMNZ

More documents and user manuals: **https://manuals.plus/**