Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun Silk-épil 9 Flex 9-300

Braun Silk-épil 9 Flex 9-300 Beauty Set Instruction Manual

Model: Silk-épil 9 Flex 9-300

Brand: Braun

1. Safety Information

Please read all instructions carefully before using the Braun Silk-épil 9 Flex 9-300 Beauty Set. Keep this manual for future reference.

- Avoid using the device on broken or inflamed skin.
- Keep the device away from water to prevent electrical hazards. (Note: The device is 100% waterproof for wet & dry use, but ensure the charging port is completely dry before connecting the charger).
- Do not use on infants or children without supervision.
- Ensure the device is fully charged before first use.
- Do not disassemble or attempt to repair the device yourself. Contact authorized service personnel for assistance.
- Use only the charger provided with the device.

2. Product Overview

The Braun Silk-épil 9 Flex 9-300 Beauty Set is a versatile hair removal and grooming system designed for women. It features a fully flexible head for effortless hair removal and includes multiple attachments for epilation, shaving, trimming, massage, and exfoliation. The set also comes with a FaceSpa device for facial epilation and cleansing.

Key Features:

- **Long-Lasting Results:** Epilate once for smooth skin lasting up to 4 weeks.
- **All-in-One System:** Deluxe set for shaving, trimming, epilating, massaging, and exfoliating.
- **Flexible Head:** World's first epilator with a fully flexible head for enhanced contact and effortless hair removal.
- **Efficient Hair Removal:** Micro-Grip Technology and a 40% wider head remove hairs as short as 0.5mm.
- **Cordless & Rechargeable:** Convenient for at-home use with long-lasting battery.
- **100% Waterproof:** Suitable for wet and dry use, including in the shower or bath, with an anti-slip grip.



Figure 1: Braun Silk-épil 9 Flex 9-300 Beauty Set showing the main epilator unit and various interchangeable heads and accessories.

3. Setup

3.1 Charging the Device

1. Ensure the device is switched off before charging.
2. Connect the charger to the epilator's charging port.
3. Plug the charger into an electrical outlet. The charging indicator light will illuminate.
4. Charge the device fully before its first use. A full charge typically provides up to 50 minutes of cordless operation.

3.2 Attaching/Detaching Heads

1. To attach a head (e.g., epilator head, shaver head, FaceSpa head), align it with the main unit and press firmly until it clicks into place.
2. To detach a head, press the release button (if available) or gently pull the head away from the unit.



Figure 2: Close-up of the Braun Silk-épil 9 Flex epilator head, demonstrating the flexible design for optimal skin contact.

4. Operating Instructions

4.1 Epilation (Body)

1. Ensure your skin is clean and dry, or wet if using in the shower.
2. Attach the epilator head to the main unit.
3. Switch on the device.
4. Hold the epilator at a 90-degree angle to your skin and glide it slowly against the direction of hair growth.
5. Do not press too hard. The flexible head will adapt to your body contours.

4.2 Shaving & Trimming (Body)

1. Attach the shaver head or trimmer head.
2. For shaving, hold the shaver flat against your skin and move it against the direction of hair growth.

3. For trimming, use the appropriate comb attachment for your desired hair length. Glide the trimmer against the direction of hair growth.

4.3 FaceSpa Usage (Facial Epilation & Cleansing)

1. Attach the facial epilator head for precise facial hair removal.
2. For facial cleansing, attach the cleansing brush. Apply your facial cleanser to the brush or your face.
3. Gently move the device in small circles across your face.



Figure 3: The epilator in action on a leg, highlighting its ergonomic design and flexible head for effective hair removal.

5. Maintenance

5.1 Cleaning the Epilator Head

1. After each use, switch off the device and detach the epilator head.
2. Rinse the epilator head under running water. You can also use the provided cleaning brush to remove any trapped hairs.

3. Allow the head to air dry completely before reattaching or storing.

5.2 Cleaning Other Attachments

All attachments can be rinsed under running water. For shaver and trimmer heads, ensure no hair remains trapped in the blades. Use the cleaning brush for thorough cleaning if necessary.

5.3 Storage

Store the device and all attachments in the provided pouch in a dry place, away from direct sunlight and extreme temperatures.

6. Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on.	Low battery or not charged.	Charge the device fully.
Poor hair removal performance.	Incorrect angle, dirty head, or dull blades.	Ensure 90-degree angle, clean the head, or consider replacing the epilator head if blades are dull.
Skin irritation.	Pressing too hard, dry epilation on sensitive skin, or using on broken skin.	Apply gentle pressure. Try wet epilation. Avoid using on irritated or broken skin.

7. Specifications

- **Brand:** Braun
- **Model Number:** MGK7221
- **Power Source:** Battery Powered (Cordless, Rechargeable)
- **Battery Type:** Li-Ion (2 AAA batteries included for FaceSpa)
- **Waterproof:** 100% Waterproof (Wet & Dry use)
- **Product Dimensions:** 2.6 x 8.86 x 9.45 inches
- **Item Weight:** 1.4 Pounds
- **Color:** Black
- **Recommended Uses:** Nose, Beard, Trimming, Shaving, Grooming (for various attachments)

8. Warranty and Support

For warranty information, product support, or to purchase replacement parts and accessories, please refer to the warranty card included in your product packaging or visit the official Braun website. You can also contact Braun customer service for further assistance.
Official Braun Website: www.braun.com

9. Related Product Videos

Braun 10 in 1 precision face hair and body care cuts different lengths of hair

▶ **Watch video online**

Braun 10 in 1 precision face hair and body care cuts different lengths of hair

Video 1: This video demonstrates the Braun 10-in-1 trimmer, showcasing its versatility for face, hair, and body grooming with various length settings. It highlights the different attachments and their uses for comprehensive personal care.

Braun MGK3980 9-in-1 Beard Trimmer, Hair, Ear, Nose, Body

▶ **Watch video online**

Braun MGK3980 9-in-1 Beard Trimmer, Hair, Ear, Nose, Body

Video 2: An overview of the Braun MGK3980 9-in-1 trimmer, detailing its functions for beard, hair, ear, nose, and body grooming. The video illustrates the different attachments and how they contribute to a complete grooming experience.

Watch Before You Buy! Braun Hair Clippers

▶ **Watch video online**

Watch Before You Buy! Braun Hair Clippers

Video 3: A concise video review of Braun hair clippers, offering insights into their performance and features to help potential buyers make an informed decision. It covers key aspects of the clippers' functionality.

© 2023 Braun. All rights reserved.
For more information, visit www.braun.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B095SZNWSH

More documents and user manuals: **https://manuals.plus/**