Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Paladone PP9401XB

Paladone Xbox Icons Light, Bottle, and Sticker Set User Manual

Model: PP9401XB

Introduction

This manual provides comprehensive instructions for the Paladone Xbox Icons Light, Bottle, and Sticker Set (Model PP9401XB). This set includes an Xbox controller-shaped light, a steel water bottle, and two sheets of Xbox-themed gadget decals. Please read this manual thoroughly before using the product to ensure proper setup, operation, and maintenance.

Package Contents

Verify that all items listed below are present in your package:

- 1 x Xbox Controller Icon Light
- 1 x Xbox Icon Steel Water Bottle (300 ml / 10.1 fl oz)
- 2 x Xbox Gadget Decal Sheets



This image displays the complete set: the Xbox controller light, the green Xbox-themed water bottle, and two sheets of Xbox gadget decals.

Setup Instructions

1. Xbox Controller Icon Light

1. Locate the battery compartment on the underside of the Xbox Controller Icon Light.
2. Open the battery compartment cover.
3. Insert 2 x AAA batteries (not included), ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.



This image illustrates the Xbox controller light, highlighting its battery requirement (2 AAA, not included) and the activation point.

2. Xbox Icon Steel Water Bottle

- Before first use, wash the bottle thoroughly with warm soapy water.
- Rinse thoroughly and allow to air dry.



This image shows the green Xbox water bottle, detailing its construction, capacity, and the warning that it is not suitable for hot drinks.

3. Xbox Gadget Decal Sheets

- Ensure the surface where you intend to apply the decal is clean, dry, and smooth.
- Carefully peel the desired decal from the sheet.
- Apply the decal to the chosen surface, pressing firmly to remove any air bubbles.



This image displays the two sheets of Xbox gadget decals, featuring various designs for personalizing accessories.

Operating Instructions

Xbox Controller Icon Light

- To turn the light **ON**, press the button located on the base of the light.
- To turn the light **OFF**, press the button again.

Xbox Icon Steel Water Bottle

- Unscrew the lid to fill the bottle with cold beverages.
- Screw the lid back on tightly to prevent leaks.
- **Important:** This bottle is designed for cold drinks only. Do not use with hot liquids.

Maintenance

Xbox Controller Icon Light

- To clean the light, wipe gently with a dry, soft cloth. Do not use abrasive cleaners or immerse in water.
- If the light dims or stops working, replace the AAA batteries.
- Remove batteries if the product will not be used for an extended period to prevent leakage.

Xbox Icon Steel Water Bottle

- **Hand wash only.** Do not wash in a dishwasher.
- Use warm soapy water and a bottle brush for thorough cleaning.
- Rinse thoroughly and allow to air dry completely before storing to prevent odors.

Xbox Gadget Decal Sheets

- Decals are generally designed for single application. Attempting to reposition may damage the decal or reduce adhesion.
- Avoid exposing applied decals to extreme temperatures or harsh cleaning agents.

Troubleshooting

- **Light does not turn on:**
  - Ensure batteries are inserted correctly with the correct polarity.
  - Replace with fresh AAA batteries.
  - Check if the battery compartment cover is securely closed.
- **Water bottle leaks:**
  - Ensure the lid is screwed on tightly and correctly aligned.
  - Check the lid's seal for any damage or debris.
- **Decals not adhering:**
  - Ensure the surface is clean, dry, and smooth before application.
  - Press firmly across the entire decal during application.

Specifications

Brand	Paladone
Model Number	PP9401XB
Item Weight	11.1 ounces (314.7 grams)
Product Dimensions	7.28"W x 10.43"H (approximate for the set)
Water Bottle Volume	300 Milliliters (approx. 10.1 fl oz)
Light Power Source	2 x AAA Batteries (not included)
Material Feature	Insulated (bottle)

Product Care	Hand Wash Only (bottle)

Safety Information

- **WARNING:** Choking Hazard - Small parts. Not for children under 3 years.
- The water bottle is not suitable for hot liquids. Using hot liquids may cause burns or damage to the bottle.
- Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Dispose of used batteries responsibly according to local regulations.
- Do not immerse the Xbox Controller Icon Light in water or expose it to excessive moisture.

Warranty and Support

Paladone products are manufactured to high standards. For any questions regarding this product, please refer to the retailer where the product was purchased or visit the official Paladone website for support information. Please retain this manual for future reference.

© 2023 Paladone Products Ltd. All rights reserved. Xbox is a registered trademark of Microsoft Corporation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B096YK9HL3

More documents and user manuals: **https://manuals.plus/**