Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun MQS230BK

Braun MQS230BK MultiQuick Chopper Hand Blender Attachment User Manual

Model: MQS230BK | Brand: Braun

Introduction

This manual provides essential instructions for the safe and effective use of your Braun MQS230BK MultiQuick Chopper Hand Blender Attachment. This 2-cup chopper is designed to expand the functionality of your Braun MultiQuick 70xx and MultiQuick 9xxx series hand blenders, allowing for efficient chopping of various ingredients. Please read these instructions thoroughly before first use and retain them for future reference.

Important Safety Information

- Always ensure the hand blender motor unit is unplugged before assembling, disassembling, or cleaning the chopper attachment.
- The blades are very sharp. Handle with extreme care to avoid injury.
- Do not operate the chopper without the lid securely in place.
- Never immerse the gear unit (the black top part) in water or other liquids. Clean it with a damp cloth only.
- Keep hands and utensils out of the chopper bowl during operation to prevent injury and damage to the appliance.
- This appliance is not intended for use by children. Close supervision is necessary when any appliance is used near children.
- Do not process extremely hard ingredients like coffee beans or ice cubes, as this may damage the blades or the chopper bowl.

Product Components



Image showing the Braun MQS230BK MultiQuick Chopper Hand Blender Attachment, featuring the clear 2-cup bowl, stainless steel blade, and black gear unit.

The Braun MQS230BK MultiQuick Chopper Attachment consists of the following parts:

1. **Chopper Bowl (2-cup capacity):** A clear plastic bowl for holding ingredients.
2. **Chopper Blade:** A sharp stainless steel blade assembly for processing food.
3. **Gear Unit/Lid:** The black top part that houses the mechanism for connecting to the hand blender motor unit and drives the blade.

Setup and Assembly

Follow these steps to assemble your chopper attachment:

1. Place the chopper bowl on a stable, flat surface.
2. Carefully place the chopper blade onto the center pin inside the chopper bowl. Ensure it sits correctly.
3. Add your desired ingredients to the chopper bowl. Do not overfill; ensure the lid can close properly.
4. Place the gear unit/lid onto the chopper bowl, aligning the tabs, and twist clockwise until it locks securely into place.
5. Attach your Braun MultiQuick hand blender motor unit to the top of the gear unit. The patented EasyClick system ensures a simple click to secure the attachment.
6. Ensure all parts are securely assembled before plugging in the hand blender motor unit.

Operating Instructions

The Braun MQS230BK chopper is designed for efficient food preparation. It is compatible with Braun MultiQuick 70xx and 9xxx series hand blenders, utilizing their Smart Speed technology for precise control.

Using the Chopper:

1. With the chopper assembled and attached to the hand blender motor unit, plug the hand blender into a power outlet.
2. Press and hold the power button on your hand blender. The Smart Speed technology allows you to control the chopping intensity by varying the pressure on the button.
3. For a coarse chop, use short pulses or light pressure.
4. For a fine chop, mince, or puree, apply more continuous pressure.
5. Process ingredients until the desired consistency is achieved.
6. Once finished, release the power button and unplug the hand blender from the power outlet.
7. Carefully detach the hand blender motor unit from the gear unit, then unlock and remove the gear unit/lid from the chopper bowl.
8. Carefully remove the blade before emptying the contents.

Recommended Uses:

- Chopping hard cheeses, nuts, herbs, onions, garlic, and other vegetables.
- Preparing small quantities of sauces, dips, or purees.

Care and Cleaning (Maintenance)

Proper cleaning ensures the longevity and hygiene of your Braun MQS230BK chopper attachment.

- Always unplug the hand blender motor unit before cleaning.
- All parts in direct contact with food are BPA-free.
- The chopper bowl and chopper blade are dishwasher safe. Alternatively, they can be washed by hand with warm, soapy water. Rinse thoroughly and dry.
- The gear unit/lid (black top part) should **not** be immersed in water. Wipe it clean with a damp cloth.
- Store the chopper attachment in a clean, dry place.

Troubleshooting

If you encounter issues with your Braun MQS230BK chopper attachment, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Chopper not operating.	Hand blender not plugged in or not securely attached.	Ensure the hand blender is plugged in and securely clicked onto the chopper's gear unit.
Ingredients not chopping evenly.	Overfilling the bowl or ingredients are too large.	Reduce the quantity of ingredients. Cut larger items into smaller, more uniform pieces. Use pulsing action.
Lid not locking securely.	Blade not seated correctly or food obstructing the lid.	Check that the blade is properly placed on the center pin. Ensure no food is preventing the lid from closing.

Problem	Possible Cause	Solution
Unusual noise during operation.	Blade obstruction or worn parts.	Stop operation immediately. Unplug and check for any obstructions around the blade. If noise persists, contact customer support.

Specifications

Feature	Detail
Brand	Braun
Model Number	MQS230BK
Material	Plastic, Stainless Steel
Color	Black
Capacity	2-Cup
Blade Material	Stainless Steel
Product Dimensions	5.82 x 5.82 x 7.36 inches
Item Weight	12 ounces (0.75 Pounds)
Compatibility	Braun MultiQuick 70xx, MQ9xxx Series Hand Blenders
Care Instructions	Dishwasher Safe (bowl and blade), Wipe clean (gear unit)
Special Features	BPA Free (food contact parts), EasyClick System

Warranty and Support

Braun products are manufactured to high-quality standards. For specific warranty details, please refer to the warranty card included with your original hand blender motor unit or visit the official Braun website. For customer support, service, or replacement parts, please contact Braun customer service through their official channels.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B097N4D13S

More documents and user manuals: **https://manuals.plus/**