**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## Braun 9419s

# Braun Series 9 Pro Electric Shaver User Manual

Model: 9419s

Brand: Braun

## Introduction

This user manual provides comprehensive instructions for the safe and effective use of your Braun Series 9 Pro Electric Shaver. Please read this manual thoroughly before first use and keep it for future reference. The Braun Series 9 Pro is designed for efficient and gentle shaving, suitable for various beard lengths, from 1-day stubble to 7-day growth. It features the innovative ProLift trimmer and Precision Switch for optimal performance.




Image: The Braun Series 9 Pro Electric Shaver, presented with its retail packaging, charging stand, and a protective travel case, highlighting its complete kit.

## What's Included

Your Braun Series 9 Pro package includes the following components:

- 1 x Electric shaver
- 1 x Charging stand
- 1 x Travel Case
- 1 x Cleaning brush
- 1 x Charging cord
- 1 x User manual (this document)




Image: A clear layout of all items included in the Braun Series 9 Pro Shaver box: the electric shaver, a leather travel case, a charging cable, a charging stand, and a small cleaning brush.

## Safety Information

Please observe the following safety precautions to ensure safe operation and prevent damage to the device or injury:

- Always clean and dry the shaver after use to prevent bacterial growth.
- Do not use the shaver while charging.
- This appliance is suitable for cleaning under running tap water.
- Do not open the shaver body. For repairs, contact authorized service personnel.
- Keep out of reach of children.
- Only use the power supply provided with the appliance.

## Setup

### Charging the Shaver

1. Connect the charging cord to the charging stand.
2. Place the shaver into the charging stand.
3. Plug the charging cord into a power outlet.
4. The battery indicator lights will illuminate to show charging progress. A full charge typically takes about 1 hour and provides up to 60 minutes of cordless shaving.




Image: The Braun Series 9 Pro Shaver resting on its sleek, premium charging stand, indicating it is ready for charging.

### Initial Use

Before your first shave, ensure the shaver is fully charged. You may use the shaver wet or dry, with or without foam/gel.

## Operating the Shaver

### General Shaving Tips

- For best results, shave before washing your face.
- Hold the shaver at a right angle (90°) to your skin.
- Stretch your skin and shave against the direction of beard growth.
- Apply gentle pressure.




Image: A man demonstrating the use of the Braun Series 9 Pro shaver on different beard lengths, from short stubble to a longer 7-day beard, showcasing its versatility.

### ProLift Trimmer and Precision Switch

The unique ProLift trimmer is designed to lift and cut long and flat hairs, ensuring an efficient and gentle shave even on longer beards. The redesigned Precision Switch allows you to lock the shaver head for enhanced control, particularly useful for tricky areas like under the nose or sideburns.




Image: A detailed close-up of the Braun Series 9 Pro shaver head, highlighting the ProLift trimmer and the Protective SkinGuard for a gentle shave.

## Maintenance

### Cleaning the Shaver

Regular cleaning ensures optimal performance and hygiene:

- After each use, rinse the shaver head under hot running tap water.
- For a more thorough cleaning, remove the shaver head and use the provided cleaning brush to remove any trapped hair.
- The shaver is 100% waterproof and can be fully rinsed under water.

### Replacing Shaver Parts

To maintain 100% shaving performance, replace the shaver cassette (foil and cutter block) every 18 months. The shaver handle is built to last for up to 7 years.




Image: A visual guide illustrating the recommended replacement schedule for the Braun Series 9 Pro shaver cassette (every 18 months) and the expected lifespan of the shaver handle (up to 7 years).

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Shaver does not turn on. | Battery is depleted. | Charge the shaver for at least 1 hour. |
| Reduced shaving performance. | Shaver head is dirty or worn out. | Clean the shaver head thoroughly. If performance does not improve, replace the shaver cassette (foil and cutter block). |
| Skin irritation after shaving. | Incorrect shaving technique or sensitive skin. | Ensure you are shaving against the grain with gentle pressure. Consider using the shaver wet with foam or gel. If irritation persists, consult a dermatologist. |

## Specifications

- **Model:** 9419s
- **Power Source:** Battery Powered (1 Lithium Ion battery included)
- **Special Features:** Cordless, Wet & Dry Shave, ProLift Trimmer, Precision Switch
- **Waterproof:** 100% waterproof up to 5m
- **Runtime:** Up to 60 minutes (after 1 hour charge)
- **Dimensions:** 10.16 x 5.43 x 2.83 inches
- **Weight:** 1.28 Pounds
- **Manufacturer:** Procter & Gamble
- **UPC:** 069055890035




Image: An infographic highlighting key features of the Braun Series 9 Pro, including its ability to cut up to 7-day beards, skin protection, Autosense technology, 40,000 cutting actions per minute, a 7-year shaver lifespan, 60 minutes of runtime, and 100% wet/dry waterproof capability.




Image: The Braun Series 9 Pro shaver, emphasizing its "Made in Germany" origin and a symbol indicating its long-lasting design, up to 7 years.

## Warranty and Support

The Braun Series 9 Pro 9419s Electric Shaver comes with a manufacturer's warranty. For specific warranty details, please refer to the warranty card included in your product packaging or visit the official Braun website.
For further assistance, technical support, or to purchase replacement parts, please contact Braun Customer Service or visit their official website:

**Braun Official Website:** www.braun.com

© 2024 Braun. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B099SX6PN2**

More documents and user manuals: **https://manuals.plus/**