Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TelPal big button phone for seniors 856

TelPal Big Button Phone with Speaker for Seniors

Model: big button phone for seniors 856 | Brand: TelPal

1. Overview

The TelPal Big Button Phone is specifically designed for ease of use, particularly for seniors. It features large, easy-to-read buttons, one-touch memory dial with picture slots, an SOS emergency button, and adjustable volume controls for both handset and ringer. This phone operates without batteries, powered directly by your landline connection.



Figure 1: TelPal Big Button Phone with its large buttons and picture memory slots.

Key Features:

- **Pictured Big Buttons:** User-friendly design with 9 customizable picture slots for quick dialing.
- **Speed Dial:** Pre-store up to 7 family numbers, 1 meal order number, and 1 SOS number.
- **SOS One-touch Dial:** A prominent red SOS button for emergency calls.
- **Clear Voice:** Stable and clear call quality for easy understanding.
- **Handset Volume Control:** 3 adjustable levels (louder, medium, lower).
- **Speaker Function:** For hands-free communication.
- **Battery-Free Operation:** Powered by landline, no external batteries required.
- **Last Number Redial, Flash, Mute functions.**

2. Setup Guide

2.1 Connecting the Phone

1. Connect one end of the coiled handset cord to the handset and the other end to the handset jack on the left side of the phone base.
2. Connect one end of the straight line cord to the LINE jack on the back of the phone base.
3. Connect the other end of the straight line cord to your telephone wall jack.
4. Ensure all connections are secure. The phone is now ready for use.

2.2 Installing Pictures for Memory Buttons

The phone features 9 picture memory buttons (7 family/friends, 1 meal order, 1 SOS). You can insert small photos of your contacts into these slots for easy visual identification.

1. Gently lift the clear plastic cover on each picture button.
2. Cut a small photo (approximately 1.5 x 1.5 inches or 3.8 x 3.8 cm) to fit the button slot.
3. Insert the photo into the slot.
4. Replace the clear plastic cover securely.



Figure 2: Inserting pictures into the memory buttons.

2.3 Programming Speed Dial Numbers

You can pre-store numbers for the 9 picture memory buttons (M1-M9, where M9 is SOS).

1. Lift the handset or press the **SPEAKER** button to activate the phone.
2. Press the **STORE** button.
3. Dial the telephone number you wish to save (up to 16 digits).
4. Press the **STORE** button again.
5. Press the desired picture memory button (M1-M9) where you want to save the number.

6. Hang up the handset or press the **SPEAKER** button to end the programming mode.
7. Repeat for all desired memory buttons.

2.4 Adjusting Volume

The phone offers adjustable ringer and handset volumes.

- **Ringer Volume:** On the side of the phone, locate the RINGER switch. Slide it to OFF, LO (Low), or HI (High) as desired.
- **Handset Volume:** On the side of the phone, locate the HANDSET VOLUME switch. Slide it to LO (Low), MED (Medium), or HI (High) during a call to adjust the listening volume.



Figure 3: Ringer and Handset Volume controls located on the side of the phone.

3. Operating Your Phone

3.1 Making a Call

3.1.1 Using Picture Memory Buttons

1. Lift the handset or press the **SPEAKER** button.
2. Press the desired picture memory button (M1-M8). The phone will automatically dial the pre-stored number.

3.1.2 Using the Dial Pad

1. Lift the handset or press the **SPEAKER** button.
2. Dial the desired telephone number using the large numeric keypad.



Figure 4: Making a call using the TelPal Big Button Phone.

3.2 Using the SOS Button

The red **SOS** button (M9) is designed for quick emergency calls to a pre-programmed number (e.g., 911 or a family member).

1. Lift the handset or press the **SPEAKER** button.
2. Press the red **SOS** button. The phone will automatically dial the emergency number.



Figure 5: The dedicated red SOS button for emergencies.

3.3 Speakerphone Function

To use the speakerphone for hands-free conversation:

1. Press the **SPEAKER** button to initiate or answer a call without lifting the handset.
2. To switch from handset to speakerphone during a call, press the **SPEAKER** button and then place the handset back on the cradle.
3. To switch from speakerphone to handset, simply lift the handset.
4. To end a speakerphone call, press the **SPEAKER** button again.



Figure 6: Speaker function for hands-free communication.

3.4 Redialing the Last Number

To redial the last number called:

1. Lift the handset or press the **SPEAKER** button.
2. Press the **REDIAL** button. The phone will automatically dial the last outgoing number.

3.5 Mute Function

During a call, press the **MUTE** button to temporarily silence your microphone. The other party will not hear you, but you can still hear them. Press **MUTE** again to resume conversation.

3.6 Flash Function

The **FLASH** button is used to access certain telephone company services, such as call waiting or transferring calls, without disconnecting the current call. Consult your telephone service provider for specific instructions on using this feature.

4. Maintenance

To ensure the longevity and proper functioning of your TelPal Big Button Phone, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the phone's surface with a soft, damp cloth. Do not use harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the phone.
- **Environment:** Keep the phone in a dry place, away from direct sunlight, extreme temperatures, and high humidity.
- **Cords:** Periodically check the phone and line cords for any signs of wear or damage. Replace if necessary.
- **Handling:** Handle the phone with care. Avoid dropping it or subjecting it to strong impacts.

5. Troubleshooting

If you encounter any issues with your TelPal Big Button Phone, please refer to the following table for common problems and their solutions:

Problem	Possible Cause	Solution
No dial tone	Loose line cord connection. Phone line issue.	Ensure the line cord is securely plugged into both the phone and the wall jack. Test with another phone if possible to check the line.
Cannot hear caller / Caller cannot hear me	Handset volume too low. Mute function activated. Loose handset cord.	Adjust the HANDSET VOLUME switch to HI. Check if the MUTE button is pressed. Ensure the handset cord is securely connected.
Speed dial button not working	Number not programmed correctly.	Re-program the speed dial number following the instructions in Section 2.3.
Ringer is too quiet or too loud	Ringer volume switch setting.	Adjust the RINGER switch on the side of the phone to LO or HI as desired.
Phone does not ring	Ringer switch set to OFF. Phone line issue.	Check the RINGER switch and set it to LO or HI. Verify the phone line is active.

6. Product Specifications

- **Model Number:** big button phone for seniors 856
- **Brand:** TelPal
- **Color:** White
- **Material:** Plastic
- **Power Source:** Corded (Landline powered, no batteries required)
- **Product Dimensions (L x W x H):** 8.66 x 8.66 x 2.76 inches (22 x 22 x 7 cm)
- **Item Weight:** 1.54 pounds (0.7 kg)
- **Telephone Type:** Wired telephone

- **Dialer Type:** Single Keypad
- **Compatible Devices:** Landline
- **Date First Available:** July 29, 2021



Figure 7: Product dimensions of the TelPal Big Button Phone.

7. Warranty and Support

7.1 Return Policy

This product is typically eligible for a refund or replacement within 30 days of receipt, in accordance with standard retail return policies. Please refer to your purchase platform's specific return policy for detailed terms and conditions.

7.2 Manufacturer Support

For any technical assistance, warranty claims, or further inquiries regarding your TelPal Big Button Phone, please contact TelPal Technology directly. Contact information can typically be found on the product packaging or the seller's page where the product was purchased.

© 2025 TelPal Technology. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09BFDQ9RP

More documents and user manuals: **https://manuals.plus/**