Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Arregui C9244H-EUR

Arregui Cashier Clip C9244H-EUR Portable Cash Box Instruction Manual

Introduction

This instruction manual provides essential information for the safe and efficient use of your Arregui Cashier Clip C9244H-EUR Portable Cash Box. This cash box is specifically designed for securely storing money and is ideal for offices, businesses, or any establishment requiring secure cash management. It is constructed from durable steel with an enameled finish, offering resistance to impacts.

The cash box features a dedicated coin tray with numerical markings to assist in counting various denominations. The lower section includes four compartments with clips to securely hold banknotes. For convenience, the coin tray tilts when the box is opened, allowing easy access to both coin and banknote sections. The box is secured with a key lock, and a set of two keys is provided. For portability, it includes a side handle and a foam cushion under the lid to prevent coins from scattering during transport.

Setup

1. **Unpacking:** Carefully remove the cash box from its packaging. Inspect for any signs of damage.
2. **Initial Opening:** Use one of the provided keys to unlock the cash box. The keys are typically found attached to the lock or inside the box.
3. **Coin Tray Placement:** The coin tray is designed to sit securely within the upper section of the cash box. Ensure it is correctly positioned.
4. **Banknote Compartments:** The lower section features four compartments with metal clips for banknotes. Ensure these clips are functional and ready for use.
5. **Foam Cushion:** Verify that the foam cushion is present on the inside of the lid. This cushion helps secure coins when the box is closed.



Image: The Arregui Cashier Clip C9244H-EUR cash box shown open, displaying the coin tray and banknote compartments with various denominations of Euro currency.



Image: An open Arregui Cashier Clip C9244H-EUR cash box, illustrating the coin tray in its tilted position for easy access and the banknote clips in the bottom section.

Operating Instructions

1. **Placing Coins:** Open the cash box. The coin tray will automatically tilt. Place coins into their respective slots according to denomination. The numerical markings on the tray indicate the quantity and value of coins.
2. **Placing Banknotes:** Lift the metal clips in the lower compartments. Place banknotes flat underneath the clips, ensuring they are held securely.
3. **Closing the Cash Box:** Gently lower the lid. The foam cushion will press against the coins, preventing them from moving. Turn the key clockwise to lock the box.
4. **Transporting:** Use the integrated side handle to carry the cash box. Ensure the box is securely locked before transport.



Image: A detailed view of the coin tray within the cash box, showing Euro coins neatly arranged in their designated slots with quantity indicators.



Image: A close-up of the banknote compartments, highlighting the metal clips designed to hold banknotes securely in place within the cash box.



Image: The Arregui Cashier Clip C9244H-EUR cash box in a closed and locked state, with the key inserted into the front lock mechanism.

Instructional Videos

Video: This video demonstrates the features and usage of the ARREGUI Cashier Clip C9244-EUR cash box, including opening, organizing money, and closing the box.

Video: This video showcases the ARREGUI Cashier C9246-EUR cash box, illustrating its design and how to manage coins and banknotes within its compartments.

Video: This video demonstrates the functionality of a cash box, focusing on the organization of coins and banknotes in its various compartments.

Maintenance

- **Cleaning:** Wipe the exterior and interior surfaces with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish.
- **Key Care:** Keep both keys in a safe and separate location. Avoid leaving the spare key inside the cash box.
- **Foam Cushion:** Ensure the foam cushion remains in place under the lid to properly secure coins during transport.

Troubleshooting

- **Key Not Turning:** Ensure you are using the correct key. Check for any debris or obstructions in the keyhole. Do not

force the key.

- **Coins Scattering During Transport:** Verify that the foam cushion is correctly positioned under the lid. Ensure the lid is fully closed and the box is locked before moving.
- **Banknotes Not Secure:** Check that the metal clips are properly holding the banknotes. Ensure banknotes are placed flat and not overfilled.

Specifications

Manufacturer	Arregui
Model Number	Cashier Clip C9244H-EUR
Exterior Dimensions (W x D x H)	30 cm x 24 cm x 9 cm
Weight	2.15 kg
Color	Black
Material	Alloy Steel
Lock Type	Key
Components Included	Cash box, set of 2 keys
Special Features	Portable



Image: A visual representation of the cash box with its exterior dimensions clearly marked.

Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your purchase or contact the retailer/manufacturer directly. Keep your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09BM9V6J1

More documents and user manuals: **https://manuals.plus/**