Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun MultiQuick Series Chopper Lid

Braun MultiQuick Mixer Chopper Lid with Gear Adapter Instruction Manual

Model: MultiQuick Series Chopper Lid (Compatible with 4644, HM3000, HM3135, HM3137, M1050)

Introduction

This manual provides essential information for the proper installation, operation, and maintenance of your Braun MultiQuick Mixer Chopper Lid with Gear Adapter. This product is an original replacement part designed to restore the functionality of your compatible Braun MultiQuick mixer's chopper attachment.

Safety Information

- Always unplug the mixer unit from the power outlet before attaching, detaching, or cleaning any accessories.
- Keep hands and utensils out of the chopper bowl while the mixer is operating.
- Ensure the lid is securely locked in place before operating the appliance.
- This lid is designed for specific Braun MultiQuick models. Using it with incompatible models may result in damage or injury.
- Do not immerse the gear adapter part of the lid in water. Clean with a damp cloth.

Package Contents

- 1 x Braun MultiQuick Mixer Chopper Lid with Gear Adapter

Compatibility

This replacement lid is compatible with the following Braun MultiQuick mixer models:

- Braun MultiQuick 4644
- Braun MultiQuick HM3000
- Braun MultiQuick HM3135
- Braun MultiQuick HM3137
- Braun MultiQuick M1050

To verify compatibility, locate the model number on the rating plate of your mixer, typically found on the underside of the appliance.

Setup and Installation

Setup and Installation

Follow these steps to correctly install the chopper lid:

1. Ensure your Braun MultiQuick mixer unit is unplugged from the power supply.
2. Place the chopper blade onto the central pin inside the chopper bowl.
3. Add your ingredients to the chopper bowl, ensuring not to exceed the maximum fill line.
4. Align the replacement chopper lid with the top of the chopper bowl. The lid should fit snugly over the bowl, with the gear adapter facing upwards.
5. Twist the lid clockwise until it locks securely into place on the chopper bowl. You should feel a click or firm resistance indicating it is properly seated.
6. Attach the assembled chopper bowl with the lid to the main motor unit of your Braun MultiQuick mixer, following the specific instructions for your mixer model.



This image displays the white replacement lid for the Braun MultiQuick mixer's chopper accessory. It features a central spindle with a gear adapter designed to connect to the mixer's motor unit.

Operating Instructions

Once the chopper lid is securely installed on the chopper bowl and attached to the mixer unit:

- Plug in your Braun MultiQuick mixer.
- Select the desired speed setting on your mixer.
- Press and hold the power button to operate the chopper. Release the button to stop.
- Process ingredients in short bursts for better control and to prevent over-processing.
- After use, unplug the mixer before disassembling the chopper attachment.

Maintenance and Cleaning

Proper cleaning ensures the longevity of your chopper lid:

- **Before Cleaning:** Always unplug the mixer unit and detach the chopper lid from the bowl and motor unit.
- **Lid (Plastic Part):** The main plastic body of the lid can be hand-washed with warm, soapy water. Rinse thoroughly and dry immediately.
- **Gear Adapter:** The gear adapter mechanism should **not** be immersed in water. Wipe it clean with a damp cloth and dry thoroughly.
- **Avoid:** Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the plastic and gear components.
- Ensure all parts are completely dry before reassembling or storing.

Troubleshooting

Problem	Possible Cause	Solution
Lid does not fit or lock onto the chopper bowl.	Incorrect alignment; incompatible model; debris preventing closure.	Ensure the lid is correctly aligned with the bowl's grooves. Verify your mixer model is listed under compatibility. Check for any food particles or debris obstructing the fit.
Chopper does not operate when lid is attached.	Lid not securely locked; mixer not powered; motor unit not properly attached.	Ensure the lid is fully twisted and locked onto the chopper bowl. Confirm the mixer is plugged in and the motor unit is correctly attached to the lid.
Unusual noise during operation.	Lid or blade not properly seated; damaged gear.	Disassemble and reassemble the chopper, ensuring all parts are correctly seated. If noise persists, inspect the gear adapter for visible damage.

Specifications

- **Brand:** Braun
- **Product Type:** Mixer Chopper Lid with Gear Adapter
- **Dimensions (L x W x H):** Approximately 12 x 15.5 x 14 cm (4.7 x 6.1 x 5.5 inches)
- **Weight:** Approximately 150 grams (0.33 lbs)
- **Material:** Durable plastic and metal components
- **Color:** White

Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your original Braun MultiQuick mixer or contact Braun customer service directly. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09BNV5RSD

More documents and user manuals: **https://manuals.plus/**