Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZOKOP KAFO-1800A-D2

ZOKOP KAFO-1800A-D2 Air Fryer Oven User Manual

Model: KAFO-1800A-D2

Introduction

Thank you for purchasing the ZOKOP KAFO-1800A-D2 Air Fryer Oven. This versatile appliance combines the functions of an air fryer, oven, rotisserie, and dehydrator, allowing you to prepare a wide variety of healthy and delicious meals with minimal oil. Please read this manual thoroughly before operation to ensure safe and efficient use of your new appliance.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or main housing in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, level, heat-resistant surface.

- Adequate air circulation is required around the appliance during operation.

Product Overview

Familiarize yourself with the components of your ZOKOP Air Fryer Oven.



Image: Front view of the ZOKOP Air Fryer Oven with key components labeled, including the touch screen, temperature control, timer, power button, stainless steel handle, cooking chamber, and visual window.

Main Unit Features:

- **Digital Touch Control Panel:** Intuitive interface for setting time, temperature, and selecting presets.
- **Large Visual Window:** Allows monitoring of cooking progress without opening the door.
- **Internal Lighting:** Illuminates the cooking chamber for better visibility.
- **Stainless Steel Handle:** For safe and easy opening of the oven door.
- **Spacious Cooking Chamber:** 16.91 Quarts (16L) capacity, suitable for family-sized meals.

Included Accessories:



Image: The ZOKOP Air Fryer Oven displayed alongside its full set of accessories, including the drip tray, fry nets, chicken fork, rotating basket, and skewer rack.

- **Fry Pan (Drip Tray):** Collects excess oil and crumbs for easy cleaning.
- **Fry Nets (3x):** For air frying various foods, allowing hot air to circulate evenly.
- **Chicken Fork (Rotisserie Spit):** For roasting whole chickens or large cuts of meat.
- **Rotating Basket (Baking Cage):** Ideal for fries, nuts, or other small items that benefit from continuous tumbling.
- **Skewer Rack:** For preparing kebabs.
- **Fetch Rack:** Tool for safely removing hot accessories.



Image: Detailed view of the Baking Cage (Rotating Basket), Drip Tray, and Skewer Pack, highlighting their design and function for different cooking methods.

Setup and First Use

1. **Unpacking:** Carefully remove all packaging materials and accessories from the box and inside the oven.
2. **Cleaning:** Wipe the exterior of the oven with a damp cloth. Wash all accessories (fry nets, drip tray, rotisserie parts, etc.) with warm, soapy water. Rinse thoroughly and dry completely before first use.
3. **Placement:** Place the appliance on a stable, level, heat-resistant surface, away from walls or other appliances to ensure proper air circulation (at least 6 inches of space on all sides).
4. **Initial Burn-in:** Before cooking food, run the oven for approximately 15-20 minutes at 350°F (175°C) to burn off any manufacturing residues. A slight odor or smoke may be present; this is normal. Ensure the area is well-ventilated.
5. **Cool Down:** Allow the appliance to cool completely after the initial burn-in before proceeding.

Operating Instructions

The ZOKOP Air Fryer Oven features a digital touch control panel for easy operation.



Image: Close-up of the digital control panel showing temperature display (392°F) and various preset icons for different food types, indicating the appliance's versatility.

Basic Operation:

1. **Power On/Off:** Press the **Power Button** ( ) to turn the unit on or off.
2. **Setting Temperature:** Use the **Temperature Up/Down Arrows** (∧ / ∨) to adjust the cooking temperature (180-400°F / 80-200°C).
3. **Setting Time:** Use the **Time Up/Down Arrows** (∧ / ∨) to adjust the cooking time (0-60 minutes for most functions, up to 24 hours for Dehydrator).
4. **Start/Pause:** Press the **Start/Pause Button** (often the Power button or a separate play/pause icon) to begin or pause cooking.

Preset Functions:

The oven comes with 8 preset cooking functions for common dishes. Simply select the desired preset, and the oven will automatically set the optimal time and temperature. You can adjust these settings manually after selecting a preset if needed.

- Common presets include: Fries, Steak, Fish, Shrimp, Pizza, Chicken, Bake, Dehydrate. (Refer to your specific unit's icons for exact presets).

Using the Rotisserie Function:

The rotisserie function is ideal for roasting whole chickens or other large cuts of meat, ensuring even cooking and a crispy exterior.



Image: A whole chicken mounted on the rotisserie fork, positioned inside the ZOKOP Air Fryer Oven, demonstrating the rotisserie cooking method for even roasting.

1. Assemble the chicken fork by sliding the prongs onto the spit and securing them.
2. Insert the assembled chicken fork with food into the rotisserie slots inside the oven.

3. Select the appropriate cooking temperature and time.
4. Press the **Rotisserie Button** (often a circular arrow icon) to activate the rotation.
5. Use the fetch rack to safely remove the hot rotisserie assembly after cooking.

Using the Dehydrator Function:

The dehydrator function allows you to preserve fruits, vegetables, and make jerky at lower temperatures over extended periods.

- Place thinly sliced food items on the fry nets.
- Select the Dehydrate preset or manually set the temperature between 90-170°F (30-80°C) and time up to 24 hours.
- Monitor the food periodically until desired dryness is achieved.

Cooking Tips

- **Preheating:** For best results, preheat the oven for 3-5 minutes before adding food.
- **Oil Usage:** While not always necessary, a light spray or toss with oil can enhance crispiness for some foods.
- **Shake/Flip:** For even cooking, especially with smaller items like fries, shake the rotating basket or flip items on the fry nets halfway through cooking.
- **Don't Overcrowd:** Cook in batches if necessary to ensure proper air circulation and even cooking. Overcrowding can lead to soggy results.
- **Internal Temperature:** Always use a meat thermometer to ensure meats are cooked to a safe internal temperature.

Maintenance and Cleaning

Regular cleaning will extend the life of your appliance and ensure optimal performance.

1. **Unplug and Cool:** Always unplug the air fryer oven from the power outlet and allow it to cool completely before cleaning.
2. **Accessories:** All removable accessories (fry nets, drip tray, rotisserie parts, etc.) are dishwasher safe or can be washed by hand with warm, soapy water. Use a non-abrasive sponge.
3. **Interior:** Wipe the interior of the oven with a damp cloth and mild detergent. For stubborn grease, a paste of baking soda and water can be used. Avoid abrasive cleaners or metal scouring pads.
4. **Exterior:** Wipe the exterior with a soft, damp cloth. Do not immerse the main unit in water or any other liquid.
5. **Heating Element:** Gently clean around the heating element with a soft brush if necessary, ensuring the unit is unplugged and cool.
6. **Storage:** Ensure all parts are clean and dry before storing the appliance in a cool, dry place.

Troubleshooting

If you encounter issues with your ZOKOP Air Fryer Oven, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; Power outlet malfunction; Unit overheated.	Ensure plug is securely in outlet. Test outlet with another appliance. Unplug and allow unit to cool for 30 minutes before restarting.
Food is not cooked evenly.	Basket/tray overcrowded; Temperature too low; Cooking time too short.	Cook in smaller batches. Increase temperature or cooking time. Shake/flip food halfway through.
White smoke coming from the appliance.	Grease/oil residue from previous use; Fatty food being cooked.	Clean the drip tray and interior thoroughly. For fatty foods, ensure adequate ventilation.
Food is not crispy.	Too much moisture; Not enough oil (for some foods); Overcrowding.	Pat food dry before cooking. Lightly spray with oil. Do not overcrowd the cooking chamber.

Specifications



Image: Diagram showing the external dimensions of the ZOKOP Air Fryer Oven: 15.1 inches (width), 14.7 inches (height), and internal cooking chamber dimensions: 11.8 inches (width), 8.3 inches (depth), 10.2 inches (height).

- **Model:** KAFO-1800A-D2
- **Power:** 1800W
- **Voltage:** 120V / 60Hz
- **Capacity:** 16.91 Quarts (16 Liters)
- **Temperature Control:** 180-400°F (80-200°C)
- **Dehydrator Temperature:** 90-170°F (30-80°C)
- **Timer:** 0-60 minutes (general cooking), 24 hours (dehydrator)
- **Product Dimensions:** Approximately 17.32 x 17.32 x 17.48 inches (L x W x H)
- **Material:** Polycarbonate (Outer), Stainless Steel (Handle)
- **Control Method:** Touch
- **Color:** Black
- **Certification:** ETL Listed

Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your purchase or contact ZOKOP customer service directly. Please have your model number (KAFO-1800A-D2) and proof of purchase ready when contacting support.
For the most up-to-date information and support resources, please visit the official ZOKOP website or contact their customer service department.

© 2024 ZOKOP. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09C4J3K87

More documents and user manuals: **https://manuals.plus/**