Braun Type 5434

Braun Clean & Charge Base Instruction Manual

Brand: Braun
Model: Type 5434

1. Product Overview

The Braun Clean & Charge Base Type 5434 is designed to provide convenient charging and cleaning for compatible Braun electric shavers. This unit ensures your shaver is always ready for use, maintaining optimal performance and hygiene through an automated cleaning process.



Image 1.1: The Braun Clean & Charge Base Type 5434. This base is used for both charging and automatic cleaning of compatible Braun electric shavers.

2. Compatibility

This Clean & Charge Base (Type 5434) is specifically designed for use with certain Braun shaver types and models. It is crucial to verify your shaver's type number to ensure compatibility. The type number is typically located on the back or underside of your shaver.

Compatible Shaver Types:

- Type 5762
- Type 5764

Compatible Shaver Models (Series 5 - Easyclean, Series 6 - Sensoflex):

- 5010, 5011, 5012, 5015, 5018, 5020, 5035, 5044, 5049, 5050, 50
- 6010, 6011, 6012, 6020, 6040, 6045, 6072, 6075, 6090, 60
- 50-B1000s, 50-B1200s, 50-B1620s, 50-B4650cs, 50-M1000s, 50-M1200s, 50-M1300s, 50-M4000cs, 50-M4500cs, 50-R1000s, 50-R1200s, 50-R1300s, 50-W1000s, 50-W1200s, 50-W1500s, 50-W1600s, 50-W4200cs, 50-W4650cs
- 60-B1000s, 60-B1200s, 60-B1500s, 60-B4500cs, 60-B7200cc, 60-N1000s, 60-N1200s, 60-N4500cs, 60-N4820cs, 60-R1000s, 60-R1200s

Compatible Shaver Models (360° Flex - Series 7):

- 7011, 7012, 7018, 7020, 7027, 7071, 7075, 7081, 7120
- 70-B1000s, 70-B1200s, 70-N1000s, 70-N1200s, 70-N4300cs, 70-S1000s, 70-S1200s, 70-S4200cs, 70-S7200cc

Important: Always match the type number with your shaver to ensure proper function and avoid damage.



Image 2.1: Example of a shaver's underside showing the type number (highlighted in yellow). Verify this number on your shaver before use.

3. Setup

1. **Unpack:** Carefully remove the Clean & Charge Base from its packaging.
2. **Placement:** Place the base on a flat, stable surface in a dry environment. Ensure it is away from direct water sources.
3. **Connect Power:** Connect your existing Braun shaver power cord to the power input socket on the back of the Clean & Charge Base.
4. **Plug In:** Plug the power cord into a suitable electrical outlet.
5. **Insert Cleaning Cartridge (if applicable):** If your model requires a cleaning cartridge, open the base's cartridge compartment and insert a fresh Braun Clean & Renew cartridge. Close the compartment securely. *(Note: This base is for use with your existing cord and does not include a cartridge unless specified by your shaver model's original kit.)*

4. Operating Instructions

4.1 Charging Your Shaver

1. Ensure the Clean & Charge Base is connected to power.
2. Place your compatible Braun shaver into the Clean & Charge Base with the shaver head facing forward. The shaver should click securely into place.
3. The charging indicator on your shaver will illuminate, indicating that charging has begun.
4. A full charge typically takes approximately 1 hour.

4.2 Automatic Cleaning Cycle

The Clean & Charge Base can automatically clean, lubricate, and dry your shaver, depending on the model and cartridge used.

1. After shaving, ensure your shaver is turned off.
2. Place the shaver into the Clean & Charge Base as described for charging.
3. The base will automatically detect the shaver and initiate a cleaning cycle if needed. Some models may have a dedicated cleaning button on the base.
4. The cleaning process involves a cleaning solution and may include a drying phase. This process can take several minutes.
5. Once the cleaning cycle is complete, the shaver will continue to charge.

Note: The cleaning solution contains alcohol and should be handled with care. Refer to the cleaning cartridge instructions for specific safety information.

5. Maintenance

5.1 Replacing the Cleaning Cartridge

The cleaning cartridge should be replaced approximately every 3 months, or when the fluid level indicator on the base shows it is empty, or when the cleaning performance noticeably decreases.

1. Unplug the Clean & Charge Base from the power outlet.
2. Press the release button (if present) or lift the base to open the cartridge compartment.
3. Carefully remove the used cartridge. Dispose of it according to local regulations.
4. Insert a new Braun Clean & Renew cartridge into the compartment until it clicks into place.

5. Close the compartment securely.
6. Reconnect the power.

5.2 Cleaning the Base

Periodically wipe the exterior of the Clean & Charge Base with a damp cloth. Do not immerse the base in water or use abrasive cleaners.

6. Troubleshooting

Problem	Possible Cause	Solution
Shaver not charging.	Base not plugged in; shaver not seated correctly; incompatible shaver.	Ensure power cord is securely connected and plugged in. Re-seat shaver firmly. Verify shaver type number against compatibility list.
Cleaning cycle not starting.	Cleaning cartridge empty or not inserted correctly; shaver not seated correctly; shaver is already clean.	Check and replace cleaning cartridge if empty. Ensure cartridge is fully inserted. Re-seat shaver. The base may not initiate a cycle if the shaver is detected as clean.
Base indicator lights not working.	No power; malfunction.	Check power connection. If problem persists, contact customer support.

7. Specifications

- **Model Type:** 5434
- **Manufacturer:** Braun
- **Item Weight:** 2 Pounds (approximately 0.91 kg)
- **ASIN:** B09D4QMGN2
- **Function:** Charging and Cleaning for compatible Braun electric shavers.
- **Power Input:** Designed for use with existing Braun shaver power cord.

8. Warranty and Support

For warranty information and customer support, please refer to the documentation included with your original Braun shaver or visit the official Braun website. Keep your proof of purchase for warranty claims.
For further assistance, you may also contact the seller, Shaver Outlet, Inc., through the platform where the product was purchased.
Online Resources:

- Braun Official Website: www.braun.com
- Amazon Product Page: https://www.amazon.com/dp/B09D4QMGN2

© 2025 Braun. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question