Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Eureka NEW200

Eureka All in One Wet Dry Vacuum Cleaner and Mop

Model: NEW200

Your comprehensive guide to efficient floor cleaning.

1. Introduction

The Eureka NEW200 All in One Wet Dry Vacuum Cleaner and Mop is designed to simplify your cleaning routine by vacuuming debris and washing surfaces simultaneously. This corded appliance is suitable for multi-surface cleaning, including hard floors and area rugs, leaving no residue and refreshing your living spaces.

2. What's Included

Your Eureka NEW200 package contains the following components:

- Eureka NEW200 Wet Dry Vacuum Unit
- Storage Base
- Accessory Drying Rack
- Filter (pre-installed)
- Brushroll Cleaning Tool
- Brushroll (pre-installed)
- Cleaning Brush
- Cleaning Solution (sample bottle)



Figure 1: Included components of the Eureka NEW200 Wet Dry Vacuum Cleaner.

3. Setup

3.1 Assembly

The Eureka NEW200 requires minimal assembly. Simply connect the handle to the main body of the vacuum until it clicks securely into place.

3.2 Filling the Water Tanks

The appliance features a two-tank system to ensure you always clean with fresh water. The clean water tank has an 800ml capacity, and the dirty water tank has a 420ml capacity.

1. Locate the clean water tank on the unit.
2. Remove the tank and fill it with clean water up to the indicated MAX line.
3. Add the recommended amount of Eureka cleaning solution to the clean water tank. Refer to the solution bottle for specific ratios.
4. Securely reattach the clean water tank to the unit.



Figure 2: The XL Two Tank System ensures separation of clean and dirty water.

Video 1: An overview of the Eureka Wet Dry Vacuum Cleaner, including its setup and key functionalities.

4. Operating Instructions

4.1 Powering On and Mode Selection

Plug the power cord into a suitable electrical outlet. The unit is corded for continuous power. Use the controls on the handle to select your desired cleaning mode: Hard Floor or Area Rug. The powerful 450W motor ensures effective cleaning on both surfaces.



Figure 3: The powerful motor provides strong suction for thorough cleaning.

4.2 Vacuuming and Mopping Simultaneously

The Eureka NEW200 is designed to vacuum and mop at the same time, saving you time and effort. Simply push the unit forward to vacuum debris and pull it back while pressing the solution trigger to wash the floor. The unit is lightweight and features swivel steering for easy maneuverability around furniture and into corners.



Figure 4: The appliance vacuums and mops in a single pass for efficient cleaning.

4.3 Multi-Surface Cleaning

Easily switch between cleaning hard floors and area rugs using the fingertip controls. The unit effectively picks up debris and washes surfaces, leaving hard floors spotless and refreshing area rugs.



Figure 5: Versatile cleaning for both hard floors and area rugs.

4.4 Tangle-Free Brush Roll

The innovative design of the brush roll helps prevent hair from tangling, ensuring consistent performance and reducing the need for frequent manual cleaning of the brush.



Figure 6: The tangle-free brush roll minimizes hair wrap for continuous cleaning.

Video 2: A detailed demonstration of the Eureka NEW200's performance on various surfaces and its self-cleaning function.

5. Maintenance

5.1 Self-Cleaning System

After each use, place the upright vacuum mop on its storage tray and press the Self Clean button. The rolling brush will undergo a self-cleaning cycle, reducing the need for manual brush cleaning and keeping your hands clean.



Figure 7: Activate the self-cleaning system by placing the unit on its base and pressing the button.

5.2 Emptying and Cleaning Dirty Water Tank

The dirty water tank collects all vacuumed debris and dirty water. It should be emptied and rinsed after each use to prevent odors and maintain hygiene. Simply detach the tank, dispose of the contents, and rinse thoroughly with clean water before reattaching.

5.3 Brush Roll and Filter Maintenance

While the self-cleaning function is effective, occasional manual cleaning of the brush roll and filter may be necessary, especially if significant debris or hair accumulates. Use the provided brush roll cleaning tool and cleaning brush for thorough maintenance. Ensure all components are dry before reassembling.

6. Troubleshooting

If you encounter any issues with your Eureka NEW200, please refer to the following common troubleshooting tips:

- **No Power:** Ensure the power cord is securely plugged into a working electrical outlet. Check the circuit

breaker.

- **Poor Suction:** Check if the dirty water tank is full and needs emptying. Inspect the brush roll for any obstructions or tangled hair. Ensure the filter is clean and properly installed.
- **No Water Dispensing:** Verify that the clean water tank is filled and correctly seated. Ensure the solution trigger is being pressed during operation.
- **Unusual Noise:** Turn off the unit and check the brush roll and suction path for any foreign objects.

For more detailed troubleshooting or persistent issues, please contact Eureka customer support.

7. Specifications

Feature	Detail
Brand	Eureka
Model Name	NEW200
Color	Black and White
Power Source	Corded Electric
Motor Power	450W
Clean Water Tank Capacity	800 Milliliters
Dirty Water Tank Capacity	420 Milliliters
Item Weight	11.68 Pounds
Product Dimensions	45.7 x 11.4 x 10.2 inches
Form Factor	Upright
Assembly Required	Yes

8. Warranty and Support

For detailed warranty information and customer support, please refer to the official user manual or visit the Eureka website. A digital copy of the user manual can be accessed via the following link: Eureka NEW200 User Manual (PDF).

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09F2LQXN3

More documents and user manuals: **https://manuals.plus/**