Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEXiBOOK CG1335

Lexibook Chessman® FX Electronic Chess Game (Model CG1335) - Instruction Manual

Brand: LEXiBOOK | Model: CG1335

Introduction

The Lexibook Chessman® FX is an advanced electronic chess game designed for both beginners and experienced players. It features a modern design with tactile controls, light and sound effects, and a wide range of difficulty levels. This manual provides essential information for setting up, operating, and maintaining your Chessman® FX game.



Image: The Lexibook Chessman FX electronic chess game, showcasing its modern design with translucent chess pieces and illuminated squares on the board.

Package Contents

Please ensure all the following items are included in your package:

- 1 x Lexibook Chessman® FX Electronic Chess Board
- 32 x Chess Pieces (16 translucent, 16 black)
- 1 x Instruction Manual



Image: A close-up view of the Lexibook Chessman FX board, displaying the translucent and black chess pieces set up for a game.

Setup

1. **Power Supply:** The Chessman® FX requires 3 x LR6/AA batteries (not included) or a 9V 3000mA adapter (not included). Insert batteries into the compartment located on the underside of the board, ensuring correct polarity.
2. **Board Placement:** Place the electronic chess board on a stable, flat surface.
3. **Piece Arrangement:** Unpack the 32 chess pieces. The board features integrated drawers for storing the pieces when not in use. Arrange the translucent pieces on the white squares and the black pieces on the

black squares according to standard chess setup. The pieces have magnetic bases to ensure stability during play.



Image: The Lexibook Chessman FX board from above, showing the integrated drawers on the sides designed for convenient storage of the chess pieces.

Operating Instructions

The Chessman® FX offers various modes and features to enhance your chess experience:

- **Game Modes:** Play against the computer or engage in a 2-player mode.
- **Difficulty Levels:** Choose from 64 difficulty levels, including 5 specifically designed for beginners.
- **Advanced Play:** Features an Elo 1800 player rating system for advanced users.
- **Move Indication:** Moves are identified by 64 warning lights, illuminating under the played piece and its destination square.
- **Training Mode:** Utilize the TRAINING mode for improvement, which suggests optimal moves or allows you to attempt new moves.
- **Special Functions:** Access functions such as HINT (suggests a move), TAKE BACK (can go back up to 2 moves), MOVE (confirms a move), VERIFY (checks piece positions), and SET UP (arranges pieces for a custom game).
- **Chess Rules:** The game engine understands and applies standard chess rules, including the 50-move rule, stalemate ('pat'), draw by repetition, pawn promotion, and 'en passant' capture. It can also solve mate in 5 moves.
- **Memory Function:** The touch-sensitive board stores piece placement even when the board is turned off.



Image: A detailed view of the Lexibook Chessman FX board, highlighting an illuminated square beneath a translucent chess piece, indicating a move or position.

Maintenance

- **Cleaning:** Wipe the board and pieces with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- **Storage:** Store the chess pieces in the integrated drawers to prevent loss and damage. Keep the unit in a cool, dry place away from direct sunlight.
- **Battery Care:** Remove batteries if the unit will not be used for an extended period to prevent leakage.

Troubleshooting

- **Pieces Not Recognized / Incorrect Moves:** Ensure each piece is placed firmly and centrally on its square. Check that the batteries are correctly installed and have sufficient power.
- **Magnets Detaching from Pieces:** If a magnet detaches from the base of a piece, it can typically be re-inserted by gently pushing it back into place.

Specifications

Attribute	Detail
Model Number	CG1335
Product Dimensions	31 x 31 x 4.8 inches
Item Weight	2.94 pounds
Manufacturer Recommended Age	3 years and up
Power Supply	3 x LR6/AA batteries (not included) or 9V 3000mA adapter (not included)
Language	English
Manufacturer	Lexibook

Warranty and Support

The Lexibook Chessman® FX (Model CG1335) comes with a**2-year warranty**. This product is designed and developed in Europe and manufactured in China. For any support inquiries or warranty claims, please refer to the contact information provided on the product packaging or the official Lexibook website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09F8NTBQC

More documents and user manuals: **https://manuals.plus/**