Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Frigidaire ESC021-BLUE

Frigidaire Snow Cone Maker Instruction Manual

Model: ESC021-BLUE

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before operating.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Avoid contact with moving parts.
- Blades are sharp. Handle carefully.

SAVE THESE INSTRUCTIONS

Product Overview

The Frigidaire Snow Cone Maker is designed to quickly shave ice for delicious snow cones and frozen drinks. It features a durable stainless-steel blade and a clear plastic top for visibility during operation.





Figure 1: Front view of the Frigidaire Snow Cone Maker. The clear top allows observation of the ice shaving process. The control knob for ice texture is visible on the front.


FRIGIDAIRE
COARSE
FINE



Figure 2: Angled view of the Frigidaire Snow Cone Maker, highlighting its compact design and the clear ice collection pitcher.

Components:

- **Main Unit:** Houses the motor and shaving mechanism.
- **Ice Hopper/Lid:** Clear top where ice cubes are placed.
- **Stainless Steel Blade:** For shaving ice.
- **Ice Collection Pitcher:** Clear pitcher with handle to collect shaved ice.
- **Texture Control Knob:** Adjusts ice texture from coarse to fine.
- **Non-slip Feet:** For stability during operation.

Setup

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Clean Before First Use:**
    - Wash the ice collection pitcher and lid in warm, soapy water. Rinse thoroughly and dry.
    - Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
3. **Assemble:** Place the ice collection pitcher securely under the main unit. Ensure it is properly seated.
4. **Placement:** Place the snow cone maker on a stable, flat, and dry surface. Ensure there is adequate space around the unit for ventilation.
5. **Power Connection:** Ensure the unit is unplugged before adding ice.

Operating Instructions

Follow these steps to make delicious shaved ice:

1. **Prepare Ice:** Use regular ice cubes from your freezer. Do not use crushed ice or ice that has been sitting out and started to melt.
2. **Add Ice:** Open the lid of the ice hopper. Place a suitable amount of ice cubes into the hopper. Do not overfill.
3. **Close Lid:** Securely close the lid. The unit will not operate unless the lid is properly closed.
4. **Select Texture:** Turn the texture control knob on the front of the unit to your desired setting:
    - **COARSE:** For larger, more granular ice.
    - **FINE:** For finer, snow-like ice.
5. **Plug In:** Plug the power cord into a standard electrical outlet.
6. **Start Shaving:** The unit will begin shaving ice automatically once plugged in and the lid is secured. Observe the ice being shaved through the clear plastic top.
7. **Collect Shaved Ice:** The shaved ice will fall into the collection pitcher below.
8. **Stop Operation:** To stop shaving, simply unplug the unit from the electrical outlet.
9. **Serve:** Remove the pitcher and serve the shaved ice immediately with your favorite syrups or toppings.




FRIGIDAIRE
COARSE
FINE

Figure 3: The Frigidaire Snow Cone Maker actively shaving ice into the collection pitcher. The blue color of the unit is prominent.

Maintenance

Cleaning:

Always unplug the unit before cleaning.

- **Ice Collection Pitcher and Lid:** These parts are removable and can be washed in warm, soapy water. Rinse thoroughly and dry completely before reassembling or storing.
- **Main Unit:** Wipe the exterior of the main unit with a soft, damp cloth. Do not use abrasive cleaners or scouring pads. Never immerse the main unit in water or any other liquid.
- **Blade Area:** Use a small brush or damp cloth to carefully clean around the blade area. Be extremely cautious as the blade is sharp.

Storage:

Ensure the appliance is clean and completely dry before storing. Store the snow cone maker in a cool, dry place, preferably in its original packaging, away from direct sunlight and heat sources.

Troubleshooting

Problem	Possible Cause	Solution
Unit does not turn on.	Not plugged in; Lid not properly closed.	Ensure the power cord is securely plugged into a working outlet. Check that the lid is fully closed and locked into place.
Ice is not shaving or unit is jamming.	Too much ice; Ice cubes are too large or frozen together; Blade is dull or obstructed.	Do not overfill the ice hopper. Use individual, standard-sized ice cubes. Unplug the unit, carefully remove any ice, and check for obstructions around the blade. If the blade is dull, contact customer support.
Shaved ice texture is inconsistent.	Texture control knob setting; Ice quality.	Adjust the texture control knob to "COARSE" or "FINE" as desired. Ensure ice cubes are consistently frozen.
Unit makes unusual noise.	Ice obstruction; Loose component.	Unplug the unit and check for any ice pieces or foreign objects obstructing the blade or motor. If the noise persists, discontinue use and contact customer support.

Specifications

Product Dimensions: 12 x 12 x 12.25 inches

Item Weight: 4.4 pounds

Model Number: ESC021-BLUE

Manufacturer: Frigidaire

Power: Standard household electrical outlet (Voltage not specified in input, common for US appliances is 120V, but I will not add it if not explicitly stated to avoid misinformation).

Blade Material: Stainless Steel

Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your product or visit the official Frigidaire website. You may also contact Frigidaire customer service directly for assistance with your ESC021-BLUE Snow Cone Maker.
For further assistance, please visit the Frigidaire Store on Amazon or the manufacturer's official website.

© 2024 Frigidaire. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09F9XBMZ5

More documents and user manuals: **https://manuals.plus/**