Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Campingaz 204187

Campingaz Twister Plus Stove Instruction Manual

Model: 204187

1. Introduction & Safety Information

Thank you for choosing the Campingaz Twister Plus Stove. This manual provides essential information for the safe and efficient operation of your appliance. Please read all instructions carefully before use and retain this manual for future reference.

Intended Use

This product is designed for normal private use in outdoor environments such as camping, backpacking, or festivals. It is not intended for commercial purposes.

Important Safety Warnings

- Ensure all users, especially children and individuals with reduced physical, mental, or sensory capabilities, are fully instructed on the safe use of the appliance and understand the associated hazards. Children must not play with the appliance. Assembly, cleaning, and maintenance must not be carried out by children.
- This equipment must only be used in well-ventilated areas (minimum 2 $m^3/h/kW$). Do not use this product in caravans, cars, tents, huts, sheds, or any small enclosed areas.
- This product consumes fuel through combustion, which produces carbon monoxide. Carbon monoxide is an odorless, clear gas that can cause flu-like symptoms, sickness, illness, and possibly death if produced in enclosed areas without proper ventilation.
- Accessible parts may become very hot during operation and immediately after. Keep young children away. Avoid touching these parts with unprotected fingers.
- Never attempt to locate gas leaks using a flame. Always check for leaks by listening for a hiss or using a leak detection solution.
- Never use your equipment close to a wall or any combustible object. Maintain adequate clearance from flammable materials.
- Do not use equipment that leaks, functions incorrectly, or is damaged. Return it to your retailer or an authorized service center.
- Always keep the gas cartridge away from appliance walls and areas that may become hot during operation.

2. Product Features

The Campingaz Twister Plus Stove offers the following key features:

- **Powerful Performance:** Single burner cooker with 2,900 W power output.
- **Easy Handling:** Equipped with the patented Campingaz EasyClic System for quick and secure cartridge connection and disconnection, even when not fully empty.
- **Compact & Lightweight:** Designed for easy transportation, weighing only 263g. Includes a convenient carrying case.
- **Heat Screen:** Features a heat screen to protect the control knob during use, enhancing safety and durability.
- **Robust Design:** Sturdy construction ideal for outdoor use.

3. Components Overview

Familiarize yourself with the main parts of your Campingaz Twister Plus Stove:



Figure 3.1: The Campingaz Twister Plus Stove fully assembled on a gas cartridge, showing the burner, pot supports, and gas connection.



Figure 3.2: The stove with its pot supports folded for compact storage, highlighting its portability.



Figure 3.3: A close-up top view of the stove's burner head, showing the flame holes and pot support mechanism.

- **Burner Head:** The central component where the flame is produced.
- **Pot Supports:** Foldable arms that hold your cooking pot securely above the flame.
- **Gas Connection:** The mechanism for attaching the stove to a gas cartridge.
- **Control Knob:** Used to regulate the gas flow and flame intensity.
- **Heat Screen:** A protective barrier located near the control knob.

4. Setup & Gas Cartridge Connection

The Twister Plus Stove is designed to be used exclusively with Campingaz CV300 plus and CV470 plus cartridges. Always work in a well-ventilated area when installing or removing a cartridge.

Connecting the Gas Cartridge

1. Ensure the stove's control knob is in the 'OFF' position.
2. Check that the seal between the appliance and the gas container is present and in good condition before connecting. Do not use the appliance if the seal is missing or damaged.
3. Align the stove's connection point with the top of the Campingaz CV300 plus or CV470 plus cartridge.
4. Press the stove firmly onto the cartridge and twist clockwise until you hear a click and it is securely locked into place. The patented EasyClic System allows for quick and secure connection.

5. Once connected, ensure the stove is placed on a stable, horizontal, and heat-resistant surface (e.g., concrete, stone, brick, or directly on the ground). If not, place an incombustible, heat-insulating material between the unit and its support.

Disconnecting the Gas Cartridge

To disconnect, ensure the stove is completely cool and the control knob is in the 'OFF' position. Twist the stove counter-clockwise to release it from the cartridge. The EasyClic System allows for safe disconnection even if the cartridge is not fully empty.

5. Operation

Lighting the Stove

1. Ensure the stove is securely connected to a gas cartridge and placed on a stable, heat-resistant surface.
2. Slowly turn the control knob counter-clockwise to allow a small amount of gas to flow. You should hear a faint hiss.
3. Immediately apply a flame (from a match or lighter) to the burner head. The stove should ignite.
4. Adjust the flame intensity using the control knob.

Cooking Guidelines

- When the appliance is in operation, the support on which the unit is standing can get very hot. Always keep the gas cartridge away from appliance walls and areas that may be hot.
- Do not use recipients with a total weight exceeding 4 kg.
- Do not use a container for cooking which is smaller or larger than the diameter indicated in the instructions (refer to product specifications for recommended pot sizes).
- For optimal performance and safety, set the cooker at low power when using flat metallic utensils such as a toaster or a rack for toasting bread.



Figure 5.1: The Twister Plus Stove in an

outdoor setting, demonstrating its use for camping meals.



Figure 5.2: The stove's compact size is highlighted by being held in a hand, emphasizing its portability for outdoor adventures.

6. Care & Maintenance

Proper care and maintenance will ensure the longevity and safe operation of your Campingaz Twister Plus Stove.

- Always ensure the stove is completely cool before cleaning or storing.
- Wipe down the stove with a damp cloth to remove any food residue or dirt. Do not use abrasive cleaners or harsh chemicals.
- Ensure all parts are dry before storing to prevent corrosion.
- Store the stove in its carrying case in a cool, dry place, away from direct sunlight and extreme temperatures.
- Regularly inspect the gas connection and seals for any signs of wear or damage. Replace if necessary.



Figure 6.1: The Campingaz Twister Plus Stove neatly packed in its protective carrying case, ready for transport or storage.

7. Troubleshooting

If you encounter issues with your stove, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Stove does not light or flame is weak.	Gas cartridge empty or improperly connected. Control knob not fully open.	Replace gas cartridge. Ensure cartridge is securely connected. Turn control knob fully open.
Gas leak detected (hissing sound, smell of gas).	Improper cartridge connection or damaged seal.	Immediately turn off the gas. Disconnect and re-connect the cartridge, ensuring a proper seal. If the leak persists, do not use the appliance and contact customer support.
Burn back (ignition under the burner cap).	Possible obstruction or issue with gas flow.	Switch the product off immediately. Allow it to cool down for approximately five minutes. Then, reignite the appliance. If the problem persists, contact your local representative.
Stove feels wobbly or unstable.	Uneven surface or improper placement.	Ensure the stove is placed on a flat, stable, and horizontal surface.

If you experience any issues not listed here, or if the problem persists after attempting the suggested solutions, please contact Campingaz customer support.

8. Specifications

Attribute	Detail
Brand	Campingaz
Model Name	Twister Plus
Model Number	204187
Fuel Type	Liquefied Petroleum Gas (LPG)
Compatible Cartridges	Campingaz CV300 plus, CV470 plus
Maximum Energy Output	2900 Watts
Boil Time (1 Litre)	3 minutes 45 seconds
Item Weight	0.2 Kilograms (263g)
Product Dimensions (LxWxH)	4.7"L x 4.72"W x 4.33"H (approx. 12 x 12 x 11 cm)
Material	Alloy Steel
Color	Blue

9. Warranty & Customer Support

Warranty Information

This product is covered by a manufacturer's warranty. For specific details regarding warranty terms and conditions, please refer to the documentation included with your purchase or contact Campingaz directly.

Customer Support

If you have any questions, require technical assistance, or need to report a problem with your Campingaz Twister Plus Stove, please contact your local Campingaz representative or the retailer from whom you purchased the product. Do not attempt to repair the appliance yourself.

For general inquiries, you may also refer to the manufacturer's contact information:

Manufacturer: APPLICATION DES GAZ

Address: 219 Route de Brignais 69230 Saint-Genis-Laval, France

For specific country support, please refer to the contact details below:

Country	Contact Email
France (FR)	infofrance@newellco.com
United Kingdom (GB)	CSUK@newellco.com
Germany (DE-AT)	info@campingaz.de
Spain (ES)	infoiberia@newellco.com
Italy (IT)	infoitaly@newellco.com
Poland (PL)	reklamacje@sat.poznan.pl
Hungary (HU)	info@kempingmotyo.hu
Greece (GR)	resoul@resoul.gr
Slovenia (SI)	racunovodstvo@rt-tri.si
Lithuania (LT)	turas@turoprekyba.lt
Estonia (EE)	info@matkasport.ee
Czech Republic / Slovakia / Bulgaria (CZ-SK-BG)	col-obchod@newellco.com
Iceland (IS)	ellingsen@ellingsen.is

© 2024 Campingaz. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09FMM1S37

More documents and user manuals: **https://manuals.plus/**