Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Roadstar CDR-375D+/BK

Roadstar CDR-375D+/BK Portable DAB/DAB+ / FM Radio CD Player User Manual

Model: CDR-375D+/BK | Brand: Roadstar

Introduction

This manual provides detailed instructions for the safe and efficient operation of your Roadstar CDR-375D+/BK Portable DAB/DAB+ / FM Radio CD Player. Please read this manual thoroughly before using the device and retain it for future reference. The CDR-375D+/BK is a versatile audio system featuring DAB/DAB+ and FM radio, a CD player compatible with CD, CD-R, CD-RW, and MP3 formats, a USB port for MP3 playback, and an AUX-IN connection. It also includes a digital LCD display, alarm function, and a credit card-type remote control.

Safety Information

- Do not expose the unit to rain or moisture to prevent fire or electric shock.
- Do not block ventilation openings. Ensure adequate space around the unit for proper airflow.
- Avoid placing the unit near heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Use only attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way.

Product Overview



Figure 1: Front View of the Roadstar CDR-375D+/BK. This image displays the main unit from the front, showing the central control panel with the LCD screen, function buttons, volume controls, USB port, and AUX-IN jack. The two integrated speakers are visible on either side.



Figure 2: Product with Remote Control and Key Features. This image shows the Roadstar CDR-375D+/BK unit alongside its remote control. Below the unit, icons highlight key features such as DAB+, MP3, CD, RDS, USB, AUX-IN, AC/DC power, headphone output, alarm, and clock functions.



Figure 3: Detailed View of the Control Panel. A close-up shot of the central control panel, highlighting the LCD screen which displays time, date, and current input (e.g., 'Auxiliary Input'). Buttons for power, function, menu/info, EQ/repeat, track navigation, volume, and enter are clearly visible, along with the USB port and 3.5mm jacks.





Figure 4: Remote Control. This image shows the compact remote control for the CDR-375D+/BK, featuring buttons for standby, function selection, mute, repeat, scan, EQ, playback controls (play/pause, stop, previous/next), menu, info, program, and volume adjustment.

Setup

Powering the Unit

The Roadstar CDR-375D+/BK can be powered in two ways:

1. **AC Power:** Connect the supplied AC power cable to the AC IN socket on the unit and then to a standard 230V wall outlet.
2. **Battery Power:** For portable use, insert 4 x LR14 (C-type) batteries (not supplied) into the battery compartment located on the underside of the unit. Ensure correct polarity.

Antenna Setup

For optimal radio reception, fully extend the telescopic antenna when listening to FM radio. For DAB/DAB+ reception, ensure the antenna is positioned vertically.

Operating Instructions

General Controls

- **POWER button:** Press to turn the unit ON or OFF.
- **FUNCTION button:** Press to cycle through different modes (DAB, FM, CD, USB, AUX).
- **MENU/INFO button:** Access menu options or display information.
- **VOL-** / **VOL+ buttons:** Adjust the volume level.
- **ENTER button:** Confirm selections.
- **EQ/RPT button:** Select equalizer presets or repeat modes.

Radio Operation (DAB/DAB+ / FM)

1. Press the **FUNCTION** button to select DAB or FM mode.
2. **Automatic Tuning:** In DAB mode, the unit will automatically scan for available stations upon first use. In FM mode, press and hold the **PREV/TUN-** or **NEXT/TUN+** buttons to auto-scan for the next available station.
3. **Manual Tuning:** In FM mode, short press the **PREV/TUN-** or **NEXT/TUN+** buttons to fine-tune the frequency.
4. **Saving Presets:** The unit supports 30 DAB+ and 30 FM presets. To save a station, tune to the desired station, then press and hold the **PROG** button on the remote or follow on-screen instructions to assign a preset number.
5. **Recalling Presets:** Short press the **PROG** button or use the numeric buttons on the remote to select a saved preset.

CD Player Operation



Figure 5: CD Compartment Open. This image shows the top-loading CD compartment of the Roadstar CDR-375D+/BK with a compact disc placed inside, ready for playback. The lid is hinged and opens upwards.

1. Press the **FUNCTION** button to select CD mode.
2. Open the CD compartment lid by gently lifting it.
3. Place a CD (CD, CD-R, CD-RW, or MP3 CD) onto the spindle with the label side facing up.
4. Close the CD compartment lid. The unit will read the disc and begin playback automatically.
5. Use the **PREV/TUN-** and **NEXT/TUN+** buttons to skip tracks.
6. Press the **PLAY/PAUSE** button to pause or resume playback.
7. Press the **STOP** button to stop playback.
8. Use the **EQ/RPT** button to select repeat modes (e.g., repeat one, repeat all) or equalizer settings.

USB Playback

1. Press the **FUNCTION** button to select USB mode.
2. Insert a USB flash drive containing MP3 audio files into the USB port on the front panel.

3. The unit will automatically detect and begin playing MP3 files from the USB drive.
4. Use the **PREV/TUN-** and **NEXT/TUN+** buttons to skip tracks.
5. Press the **PLAY/PAUSE** button to pause or resume playback.

AUX-IN Connection

1. Press the **FUNCTION** button to select AUX mode.
2. Connect an external audio device (e.g., smartphone, MP3 player) to the**AUX-IN** jack on the front panel using a 3.5mm audio cable (not supplied).
3. Audio from the external device will now play through the CDR-375D+/BK speakers. Control playback from the connected device.

Headphone Output

To listen privately, connect headphones with a 3.5mm jack to the**HEADPHONE OUT** jack on the front panel. The speakers will automatically mute when headphones are connected.

Alarm and Clock Functions

The unit features a digital clock and alarm function. Refer to the on-screen menu (accessed via**MENU/INFO** button) for setting the time and configuring alarm settings.

Maintenance

- **Cleaning:** Wipe the unit with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **CD Care:** Handle CDs by their edges. Keep them clean and free of scratches. Store them in their cases when not in use.
- **Battery Replacement:** If using battery power, replace all batteries with new ones of the same type when the unit's performance diminishes.
- **Storage:** If storing the unit for an extended period, remove the batteries to prevent leakage.

Troubleshooting

Problem	Possible Cause	Solution
No power	AC cable not connected; Batteries depleted or incorrectly inserted.	Ensure AC cable is securely connected. Replace batteries or check polarity.
No sound	Volume too low; Headphones connected; Incorrect function mode.	Increase volume. Disconnect headphones. Select the correct function mode (CD, FM, DAB, USB, AUX).
Poor radio reception	Antenna not extended/positioned; Weak signal.	Fully extend and adjust the telescopic antenna. Try moving the unit to a different location.
CD skipping or not playing	CD dirty or scratched; CD inserted incorrectly; Unsupported disc format.	Clean the CD with a soft cloth. Re-insert the CD with the label side up. Ensure the disc is CD, CD-R, CD-RW, or MP3 CD.
USB not playing	USB drive not inserted correctly; Unsupported file format; USB drive corrupted.	Re-insert the USB drive. Ensure files are MP3 format. Try a different USB drive.

Problem	Possible Cause	Solution
Remote control not working	Batteries depleted; Obstruction between remote and unit; Remote not pointed at sensor.	Replace remote control batteries. Remove any obstructions. Point the remote directly at the unit's sensor.

Specifications



Roadstar

CD PLAYER	
Loader type	Top Loader
Electronic Shock Protection	-
Compressed audio playback	MP3
Disc support	CD, CD-R, CD-RW
Auto ID3 tag detection	-
MP3 search by	-
Data rate system	-
Fast forward / reverse	●
Track search	-
Intro scan	-
Random play	-
Repeat track / album	-
Program function	-

TUNER	
Tuner type	DAB/DAB+/FM
Ranges (band)	FM
RDS system / Radiotext	●
Preset stations	30 DAB+, 30 FM
Stereo / Mono selector	(Stereo)
Automatic tuning	●
Manual tuning	●

CASSETTE	
Cassette deck	-
Cassette mechanism	-
Automatic Level Control (ALC)	-
One Touch Recording (OTR)	-
Built-in microphone	-

USB/SD/MMC	
Recording	-
Playback	●
Copy	-
Delete	-
iPod compatibility	-

TURNTABLE	
R.P.M.	-
Tone Arm Mechanism	-

Roadstar

Roadstar Management SA
Via Passeggiata, 7
CH - 6883 Novazzano
Switzerland
www.roadstar.com

CONNECTIONS	
Bluetooth	-
USB port	●
Card slot	-
Aux in	Ø 3.5mm Jack
Line Out	-
Headphones Out	Ø 3.5mm Jack

AUDIO	
Speaker system	2 speakers
Total PMPO Output Power	32 Watt
Nominal Output Power	2 x 2 Watt RMS
Volume control	Digital
Equaliser	Flat, Rock, Pop, Jazz,Classic

GENERAL	
Accessories included	AC cord, Remote Control
Colour Versions	Black
Display / Illumination	LCD DOT MATRIX
Power supply	AC 230V ~50Hz 4xLR14 (not incl.)
Battery Memory	-
Weight	1.2 Kg
Dimensions (WxLxH)	211x233x120 mm

COMMERCIAL	
Container load 40'	7000 pcs
Container load 20'	3500 pcs
Shipping carton	6 pcs
Gift Box size (WxLxH)	237x232x133 mm
Shipping car. size (WxLxH)	375x480x250 mm

EAN code	
CDR-375D+/BK	7621800033048

Master Carton EAN code	
CDR-375D+/BK	7621800054937
Country of origin	P.R.C.

Ed.1.1 03/05/2021

Figure 6: Technical Specifications. This image presents a comprehensive table detailing the technical specifications of the Roadstar CDR-375D+/BK, including CD player features, tuner types, connections, audio output, and general product information.

Feature	Description
Model Number	CDR-375D+/BK
Brand	Roadstar

Feature	Description
Color	Black
Connectivity Technology	USB
Speaker Type	Stereo
Power Output	32 Watts (PMPO), 4W RMS (2 x 2W RMS)
Power Source	AC Cable (230V) or 4 x LR14 (C-type) Batteries (9V)
Radio Tuner	DAB/DAB+ / FM RDS Digital Tuner
Radio Presets	30 DAB+, 30 FM
CD Player	Top Loader, supports CD, CD-R, CD-RW, MP3
USB Port	For MP3 playback
AUX-IN	3.5mm Jack
Headphone Output	3.5mm Jack
Display	Large LCD with negative vision
Dimensions (L x H x P)	233 x 120 x 211 mm (as per product description) / 50 x 50 x 28 cm (as per specifications, likely packaging)
Weight	1.2 Kilograms
Accessories Included	AC cord, Remote Control

Warranty and Support

For warranty information and customer support, please refer to the documentation included with your product at the time of purchase or visit the official Roadstar website. Keep your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09FQD9DFJ

More documents and user manuals: **https://manuals.plus/**