Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEXiBOOK JG610

LEXiBOOK Table Electronic Pinball User Manual

Model: JG610 Retro

Introduction

This manual provides essential information for the setup, operation, and maintenance of your LEXiBOOK Table Electronic Pinball. Please read these instructions carefully to ensure proper use and to maximize your enjoyment of the product. This electronic pinball game is designed to provide an engaging action and reflex experience for children and families, featuring digital scoring, interactive sound, and light effects.

Setup

1. Unpacking

Carefully remove all components from the packaging. Ensure that the pinball unit, the ball, and any included stands are present.

2. Battery Installation

The LEXiBOOK Table Electronic Pinball requires **3 x LR14 / C 1.5V batteries** (not included).

1. Locate the battery compartment on the underside of the pinball unit.
2. Using a screwdriver, open the battery compartment cover.
3. Insert 3 LR14 / C 1.5V batteries, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.

3. Attaching the Stands

The unit includes two stands designed to provide the perfect playing angle. Attach these stands to the designated slots on the underside of the pinball machine. This elevates the back of the unit, allowing the ball to roll down the playfield effectively.



Image: Underside view of the pinball machine with its two stands extended, illustrating how to achieve the optimal playing angle.

Operating Instructions

1. Powering On/Off

Locate the power switch, typically on the side or back of the unit. Slide the switch to the 'ON' position to activate the pinball machine. To turn off the unit, slide the switch to the 'OFF' position.

2. Starting a Game

Press the 'Start' button on the control panel. The LCD screen will display the score, and the game will be ready to begin. Launch the ball using the spring-loaded plunger on the side of the unit.





Image: A direct front view of the pinball machine, highlighting the digital LCD scoring screen and the main control buttons for game operation.

3. Gameplay

The pinball machine features **4 flippers** and **5 bumpers**. Use the flipper buttons on the sides of the unit to control the flippers and keep the ball in play. Aim for the bumpers and other targets on the playfield to score points. The digital LCD screen will track your score.



Image: An angled view of the pinball machine's playfield, clearly showing the ball, the four flippers, and the five interactive bumpers.

4. Sound and Light Effects

The pinball machine is equipped with great sounds and light effects that activate during gameplay, simulating a real pinball experience. These effects enhance the interactive nature of the game.

5. Reset Button and Music Control

A 'Reset' button is available to clear the current score and start a new game. There is also a button to control the music, allowing you to turn it on or off as desired.

▶ **Watch video online**

Product Summary Video

Video: This official product summary video demonstrates the LEXiBOOK Table Electronic Pinball in action, showcasing its features such as digital scoring, sound and light effects, and overall gameplay. It provides a visual guide to the product's functionality.

Maintenance

1. Cleaning

To clean the pinball machine, use a soft, dry cloth. For stubborn marks, a slightly damp cloth can be used, but ensure no moisture enters the electronic components. Do not use abrasive cleaners or solvents.

2. Storage

When not in use, store the pinball machine in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, it is recommended to remove the batteries to prevent leakage.

3. Battery Replacement

Replace batteries when the sound and light effects become weak, or the unit fails to power on. Follow the battery installation steps outlined in the Setup section.

Troubleshooting

Problem	Possible Cause	Solution
Unit does not turn on.	Batteries are dead or incorrectly installed.	Check battery polarity and replace with new batteries if necessary.
No sound or lights during gameplay.	Batteries are low; music is turned off.	Replace batteries. Press the music control button to turn sound on.
Ball gets stuck or does not launch properly.	Obstruction on the playfield; weak plunger spring.	Ensure the playfield is clear. If the issue persists, contact customer support.
Sound is too loud.	No volume control feature.	While there is no volume adjustment, some users have found that placing a small piece of tape over the speaker can reduce the volume.

Specifications

- **Product Dimensions:** 20.47 x 10.24 x 1.97 inches
- **Item Weight:** 1.56 pounds
- **Model Number:** JG610
- **Power Supply:** 3 x LR14 / C 1.5V batteries (not included)
- **Recommended Age:** 3 years and up
- **Features:** Digital scoring, sound and light effects, 4 flippers, 5 bumpers, 1 ball, reset button, music cut option, 2 stands for optimal angle.
- **Origin:** Designed and developed in Europe - Made in China.

Warranty and Support

Warranty Information

This LEXiBOOK product comes with a**2-year warranty**. Please retain your proof of purchase for any warranty claims. The warranty covers manufacturing defects under normal use conditions.

Customer Support

For technical assistance, troubleshooting not covered in this manual, or warranty inquiries, please contact LEXiBOOK customer support. Refer to the product packaging or the official LEXiBOOK website for the most current contact information.

© 2024 LEXiBOOK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09HXMKV6N

More documents and user manuals: **https://manuals.plus/**