Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Celebrat TWS-W10

Celebrat TWS-W10 True Wireless Stereo Earbuds User Manual

Model: TWS-W10

1. Introduction

Thank you for choosing the Celebrat TWS-W10 True Wireless Stereo Earbuds. These earbuds are designed to provide a high-quality, seamless audio experience with advanced technology and user-friendly functions. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your new earbuds to ensure optimal performance.

2. Safety Information

- Do not expose the earbuds or charging case to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping, hitting, or disassembling the device. This may cause damage and void the warranty.
- Keep the earbuds and charging case away from water and liquids. These earbuds are not water-resistant.
- Use only the provided charging cable or a certified equivalent to charge the device.
- Listening at high volume levels for extended periods can cause permanent hearing damage. Adjust volume to a safe level.
- Keep out of reach of children and pets. Small parts may pose a choking hazard.

3. Package Contents

Please check the package for the following items:

- Celebrat TWS-W10 True Wireless Stereo Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- Ear Cushions (various sizes)
- User Manual

4. Product Overview

Familiarize yourself with the components of your Celebrat TWS-W10 earbuds.



Image: The Celebrat TWS-W10 True Wireless Stereo Earbuds are shown resting inside their open charging case. The earbuds are black, and the case is also black, indicating a sleek and compact design.



Image: A single black Celebrat TWS-W10 earbud is displayed next to its open black charging case. This view highlights the individual earbud's design and its relationship to the charging unit.



Image: The product packaging for the Celebrat TWS-W10 True Wireless Stereo Earbuds. The box is blue and features an image of the earbuds and charging case, along with key features like 'True Wireless Stereo Earbuds' and 'TWS-W10'.

5. Setup

5.1 Charging the Earbuds and Case

1. Place the earbuds into the charging case, ensuring they are correctly seated.
2. Connect the USB charging cable to the charging port on the case and plug the other end into a compatible USB power source (e.g., wall adapter, computer USB port).
3. The indicator lights on the case will show the charging status. Once fully charged, the lights will typically turn solid or turn off.
4. A full charge usually takes approximately 1-2 hours for the earbuds and 2-3 hours for the charging case.

5.2 Pairing with a Bluetooth Device

1. Ensure the earbuds are charged.

2. Open the charging case. The earbuds will automatically enter pairing mode, and their indicator lights will flash (e.g., blue and red alternately).
3. On your mobile phone or other Bluetooth-enabled device, go to the Bluetooth settings.
4. Search for available devices and select "Celebrat TWS-W10" from the list.
5. Once connected, the earbud indicator lights will stop flashing or flash slowly, and you will hear a confirmation tone.
6. If pairing fails, turn off the earbuds, restart your device's Bluetooth, and repeat the steps.

6. Operating Instructions

6.1 Power On/Off

- **Power On:** Open the charging case, and the earbuds will automatically power on. Alternatively, press and hold the touch control area on both earbuds for 3 seconds.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will automatically power off. Alternatively, press and hold the touch control area on both earbuds for 5 seconds.

6.2 Music Playback

- **Play/Pause:** Tap the touch control area on either earbud once.
- **Next Track:** Double-tap the touch control area on the right earbud.
- **Previous Track:** Double-tap the touch control area on the left earbud.
- **Volume Up:** Triple-tap the touch control area on the right earbud.
- **Volume Down:** Triple-tap the touch control area on the left earbud.

6.3 Call Management

- **Answer/End Call:** Tap the touch control area on either earbud once.
- **Reject Call:** Press and hold the touch control area on either earbud for 2 seconds.

6.4 Voice Assistant

- **Activate Voice Assistant:** Press and hold the touch control area on either earbud for 2 seconds (when not on a call).

7. Maintenance

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the earbuds and charging case. Do not use abrasive cleaners or solvents.
- **Ear Cushions:** Regularly remove and clean the ear cushions with a damp cloth. Ensure they are completely dry before reattaching.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage. Store in a cool, dry place.
- **Battery Care:** To prolong battery life, avoid fully discharging the earbuds and charging case frequently. Charge them regularly, even if not used for extended periods.

8. Troubleshooting

Problem	Possible Cause	Solution
Earbuds not powering on	Low battery; Incorrect power-on method	Charge the earbuds; Ensure earbuds are removed from case or touch control is held for 3 seconds.

Problem	Possible Cause	Solution
Earbuds not pairing	Earbuds not in pairing mode; Bluetooth off on device; Device too far	Ensure earbuds are out of case and flashing; Turn on Bluetooth on your device; Move device closer to earbuds; Forget device and re-pair.
No sound from earbuds	Volume too low; Earbuds not connected; Media paused	Increase volume on earbuds and device; Reconnect earbuds; Play media.
One earbud not working	Low battery on one earbud; Earbuds not properly synced	Charge both earbuds; Place both earbuds back in the case, close, then reopen to re-sync.
Charging case not charging	Faulty cable/adapter; Loose connection	Try a different USB cable or power adapter; Ensure cable is securely connected.

9. Specifications

Feature	Description
Model Name	TWS-W10
Brand	Celebrat
Connectivity Technology	Wireless
Headphone Form Factor	In-Ear
Control Type	Volume Control
Control Method	Touch
Noise Control	None
Sensitivity	99 dB
Compatible Devices	Mobile Phones
Specific Uses	Music Playback
Materials	Polyurethane (PU), Silicone
Color	Black
Water Resistance Level	Not Water Resistant
Style	Modern
Included Components	Ear Cushions
Age Range Description	Adult

10. Warranty and Support

The Celebrat TWS-W10 True Wireless Stereo Earbuds come with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions, including the warranty period and coverage details. For technical support, warranty claims, or any questions regarding your product, please contact the retailer or the official Celebrat customer service. Contact information can typically be found on the product packaging or the brand's official website.

© 2024 Celebrat. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09J8VQXB5

More documents and user manuals: **https://manuals.plus/**