Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Gardena 05341-20

Gardena Bobbin Cover Instruction Manual

For Turbotrimmer EasyCut 400, ComfortCut 450, PowerCut 500 (Model 05341-20)

Brand: Gardena

1. Safety Information

Warning: Always prioritize safety when operating power tools. Failure to follow safety instructions can result in injury or damage to equipment.

- Beware of flying debris when operating the string trimmer.
- Use caution near hard surfaces to avoid damage to the trimmer head and potential injury.
- Always wear appropriate safety gear, including eye protection, gloves, and sturdy footwear.
- Ensure the trimmer is switched off and disconnected from its power source before performing any maintenance or part replacement.

2. Product Overview

The Gardena Bobbin Cover (Model 05341-20) is an original replacement part designed for Gardena Turbotrimmers EasyCut 400, ComfortCut 450, and PowerCut 500 (Article Numbers 8846, 8847, 8848). This cover is essential for the safe operation of your lawn trimmer, protecting the bobbin head from damage during use. It ensures the trimmer head is shielded, especially when working near hard surfaces like masonry walls or rocks.

The cover is made from high-quality plastic, ensuring durability and a long service life under normal operating conditions.

3. Setup and Installation

Replacing the Bobbin Cover is a straightforward process that can be completed in a few simple steps. Ensure the trimmer is powered off and disconnected before proceeding.

1. **Remove the old cover:** If an old cover is present, carefully detach it from the trimmer head. This may involve pressing release tabs or unscrewing it, depending on your specific trimmer model.
2. **Position the new cover:** Align the new Gardena Bobbin Cover (Model 05341-20) with the trimmer head. Ensure the tabs or grooves on the cover match those on the trimmer head for a secure fit.

3. **Secure the cover:** Press the new cover firmly into place until it clicks or locks securely. Verify that it is fully seated and cannot be easily dislodged.



Image 1: Installation of the Gardena Bobbin Cover. The orange cover is being placed over the bobbin spool on the trimmer head.

Once the new Bobbin Cover is securely installed, your trimmer is ready for use again.

4. Operating Instructions

The Bobbin Cover's primary function is to protect the trimmer head and the user during operation. Always ensure the cover is correctly installed before starting your trimmer.

- **Protection:** The durable cover shields the trimmer head from impacts and abrasion, particularly when trimming along edges, masonry walls, fences, or rocks.
- **Safe Operation:** The cover helps contain debris and cut grass, directing it away from the operator and surroundings.
- **Optimal Performance:** A properly installed and undamaged cover contributes to the overall balance and efficiency of the trimmer.



Image 2: Trimmer in use, demonstrating how the cover protects the head while trimming along a path.



Image 3: Trimmer in use, showing the cover's role in protecting the head during trimming in confined spaces.

5. Maintenance

Regular inspection and timely replacement of the Bobbin Cover are crucial for maintaining the safety and performance of your Gardena Turbotrimmer.

- **Inspection:** Before each use, visually inspect the Bobbin Cover for any signs of wear, cracks, chips, or other damage.
- **Causes of Wear:** Frequent use, especially when working close to hard surfaces like rocks, concrete, or walls, can accelerate wear and tear on the cover.
- **Replacement:** If any damage is observed, replace the Bobbin Cover immediately. A damaged cover compromises protection and can lead to safety hazards or further damage to the trimmer head.
- **Cleaning:** Keep the cover clean from grass clippings and debris to ensure proper function and visibility.

6. Troubleshooting

This section addresses common issues related to the Bobbin Cover.

- **Cover does not fit:** Ensure you have the correct Bobbin Cover model (05341-20) for your Gardena Turbotrimmer (EasyCut 400, ComfortCut 450, PowerCut 500, Art. No. 8846, 8847, 8848). Refer to the product specifications.
- **Cover is loose or falls off:** Re-check the installation steps. Ensure the cover is fully seated and locked into place. If it continues to be loose, the cover or the trimmer head attachment points may be damaged and require replacement.
- **Trimmer head is getting damaged:** If the trimmer head is experiencing damage despite the cover being installed, inspect the cover for cracks or significant wear that might be compromising its protective function.

Replace the cover if damaged.

7. Specifications

Brand	Gardena
Model Number	05341-20
Compatible Trimmers	Gardena Turbotrimmer EasyCut 400, ComfortCut 450, PowerCut 500 (Art. No. 8846, 8847, 8848)
Item Weight	40 Grams
Product Dimensions (L x W)	3.54" x 1.38"
Material	High-quality plastic
Included Components	1x Spool cover

8. Warranty Information

For detailed warranty information regarding your Gardena Bobbin Cover (Model 05341-20), please refer to the official Gardena website or the documentation provided with your original Gardena Turbotrimmer. Warranty terms and conditions may vary by region and product.

9. Support

Should you require further assistance, have questions about installation, or need to purchase additional Gardena replacement parts, please contact Gardena customer support or visit the official Gardena Store.

Official Gardena Store: Visit the Gardena Store on Amazon

© 2024 Gardena. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09J98PYMC

More documents and user manuals: **https://manuals.plus/**