Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun SI1080VI

Braun TexStyle 1 SI 1080 VI Steam Iron User Manual

Model: SI 1080 VI

1. Introduction

Thank you for choosing the Braun TexStyle 1 SI 1080 VI Steam Iron. This manual provides essential information for the safe and efficient use, maintenance, and troubleshooting of your new appliance. Please read these instructions carefully before first use and keep them for future reference.

2. Product Features

- **SuperCeramic Coated Soleplate:** Ensures smooth gliding over various fabrics.
- **2000W Power:** Provides rapid heating and efficient steam generation.
- **Lightweight Design:** Facilitates comfortable and effortless ironing.
- **220ml Water Tank:** Allows for extended steam ironing sessions.
- **Eco Mode:** Reduces power consumption for energy-saving ironing.
- **Variable Steam:** Adjustable steam output for different fabric types.
- **Anti-Drip System:** Prevents water stains on garments at low temperatures.

3. Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, or injury.

- Always ensure the voltage indicated on the appliance corresponds to your mains voltage.
- Do not leave the iron unattended while it is switched on or connected to the mains.
- Keep the iron and its cord out of reach of children.
- Never immerse the iron in water or any other liquid.
- Do not operate the iron with a damaged cord or plug, or if the iron has been dropped or damaged.
- Always unplug the iron before filling with water, emptying, or cleaning.
- Use the iron only for its intended household purpose.
- The soleplate can become extremely hot. Avoid direct contact with hot surfaces.

4. Setup

4.1 Unpacking and First Use

1. Remove all packaging materials, labels, and protective film from the iron.
2. Before first use, iron an old piece of fabric to remove any manufacturing residues from the soleplate. This may produce a slight odor or smoke, which is normal and will dissipate.

4.2 Filling the Water Tank



Image: Top view of the Braun TexStyle 1 Steam Iron, highlighting the water fill opening and control dials.

1. Ensure the iron is unplugged from the power outlet.
2. Open the water tank inlet cover, usually located on the front of the handle.
3. Fill the water tank with tap water up to the 'MAX' mark. For areas with very hard water, a mixture of 50% tap water and 50% distilled water is recommended. Do not use perfumed water, water from tumble dryers, or chemically descaled water.
4. Close the water tank inlet cover securely.

5. Operating Instructions

5.1 Temperature Setting

1. Plug the iron into a suitable power outlet.
2. Turn the temperature dial to the desired setting according to the fabric type. Refer to the garment's care label.
3. The indicator light will illuminate, indicating the iron is heating up. It will turn off once the set temperature is reached.

5.2 Dry Ironing

For dry ironing, ensure the steam selector is set to the 'no steam' position. Select the appropriate temperature and wait for the iron to heat up.

5.3 Steam Ironing



Image: Side view of the Braun TexStyle 1 Steam Iron, displaying the SuperCeramic soleplate and steam vents.

1. Ensure the water tank is filled (see Section 4.2).
2. Set the temperature dial to a steam-suitable setting (usually indicated by the steam symbol on the dial).
3. Once the indicator light turns off, adjust the steam selector to the desired steam level.
4. For an extra burst of steam, press the steam shot button. This is useful for stubborn creases.

5.4 Eco Mode

To activate Eco Mode, press the dedicated Eco button. This mode optimizes steam output and temperature to save energy while still providing effective ironing results for most fabrics.

5.5 Vertical Steaming

The iron can be used for vertical steaming of hanging garments or curtains. Hold the iron vertically, press the steam shot button, and direct the steam towards the fabric. Ensure the iron is at a high temperature setting for effective vertical steaming.

6. Maintenance and Cleaning

6.1 After Each Use

1. Unplug the iron and allow it to cool down completely.
2. Empty any remaining water from the tank to prevent scale buildup.

6.2 Cleaning the Soleplate

To clean the soleplate, wipe it with a damp cloth after the iron has cooled down. Do not use abrasive cleaners or scouring pads, as these can damage the SuperCeramic coating.

6.3 Descaling

Regular descaling is important to maintain steam performance, especially in hard water areas. Refer to the specific descaling instructions provided in the full product manual or contact Braun customer service for guidance on descaling procedures for your model.

6.4 Storage

Store the cooled iron in an upright position on its heel rest, with the cord neatly wrapped, in a dry and safe place.

7. Troubleshooting

Problem	Possible Cause	Solution
Iron does not heat up.	Not plugged in; power outlet faulty; temperature dial set to 'Min'.	Check power connection; try another outlet; set temperature dial to desired heat.
No steam or insufficient steam.	Water tank empty; temperature too low; steam vents blocked.	Fill water tank; set temperature to steam-suitable range; descale iron.
Water drips from soleplate.	Temperature too low for steam; water tank overfilled.	Increase temperature; do not overfill water tank.
White flakes coming from soleplate.	Scale buildup.	Perform descaling procedure.

8. Specifications

- **Model Number:** SI1080VI
- **Power:** 2000 Watts
- **Voltage:** 240 Volts
- **Water Tank Capacity:** 220 ml
- **Soleplate Type:** SuperCeramic Coated
- **Item Weight:** 1.8 Kilograms
- **Product Dimensions:** 30.2 x 12.6 x 0.1 cm
- **Special Features:** Lightweight, Auto Shutoff, Eco Mode

9. Warranty and Support

This Braun product is covered by a manufacturer's warranty. For detailed warranty terms and conditions, please refer to the warranty card included with your product or visit the official Braun website. For technical support, spare parts, or service, please contact Braun customer service in your region. Keep your purchase receipt as proof of purchase.
You can find more information and support on the official Braun website:www.braunhousehold.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09JGRXHKF

More documents and user manuals: **https://manuals.plus/**