**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## FITHOOD CS-ZTS200SL

# FITHOOD Battery Replacement User Manual

Model: CS-ZTS200SL

## 1. Introduction

This manual provides essential information for the safe and effective use of your FITHOOD replacement battery. This battery is designed for compatibility with specific Geomax and Zipp10 devices. Please read this manual thoroughly before use.

**Compatible Models:**

- Geomax Zoom 30
- Geomax Zoom 20
- Geomax ZT20R
- Geomax ZT20
- Geomax Zoom Pro
- Geomax Zipp10

**Compatible Battery Part Numbers:**

- ZBA302
- ZBA301

## 2. Safety Information

Observe the following safety precautions to prevent damage to the battery or device, and to avoid personal injury.

- Do not attempt to disassemble, open, or service the battery pack.
- Replace only with the battery pack designated for this product.
- Do not crush, puncture, short external contacts, or dispose of in fire or water.
- Do not store above 60°C (140°F).
- Keep out of reach of children.
- Dispose of used batteries according to local regulations.

## 3. Package Contents

Verify that all items are present in the package:

- 1 x FITHOOD Replacement Battery (Model: CS-ZTS200SL)



Image 1: Top-down view of the FITHOOD replacement battery. The battery is black with a label on top showing model number CS-ZTS200SL, part numbers ZBA302 and ZBA301, and specifications 7.4VDC 4400mAh/32.56Wh.

## 4. Setup and Installation

Follow these steps to install the replacement battery into your compatible device.

1. **Power Off Device:** Ensure your Geomax or Zipp10 device is completely powered off before attempting battery replacement.
2. **Locate Battery Compartment:** Identify the battery compartment on your device. Refer to your device's original user manual if unsure.
3. **Remove Old Battery:** Carefully open the battery compartment and remove the existing battery.
4. **Insert New Battery:** Align the FITHOOD replacement battery (CS-ZTS200SL) with the battery compartment's contacts. Gently push the battery into place until it is securely seated.
5. **Close Compartment:** Close the battery compartment cover securely.
6. **Initial Charge:** It is recommended to fully charge the new battery before its first use.



Image 2: Angled view of the FITHOOD replacement battery, showing its rectangular shape and connection points. The label with specifications is visible on the top surface.

## 5. Operating Instructions

Once installed, the FITHOOD battery operates identically to the original battery. Refer to your device's original user manual for specific operating instructions related to power management and usage.

- **Charging:** Use the original charger provided with your Geomax or Zipp10 device to charge the FITHOOD battery.
- **Battery Level:** Monitor the battery level indicator on your device to determine remaining power.
- **Usage:** The battery provides power for the normal operation of your compatible device.

## 6. Maintenance

Proper maintenance extends the life of your battery.

- **Storage:** If storing the battery for an extended period, store it in a cool, dry place, ideally at 50% charge. Avoid extreme temperatures.
- **Cleaning:** Keep the battery contacts clean and free of dust or debris. Use a dry, soft cloth to wipe them if necessary.
- **Charging Cycles:** For optimal battery health, avoid frequent deep discharges. Recharge the battery before it is completely depleted.




Image 3: Bottom view of the FITHOOD replacement battery, showing the textured surface and the label with manufacturing details and safety warnings.

## 7. Troubleshooting

If you encounter issues with your FITHOOD replacement battery, consider the following:

- **Battery Not Charging:**
  - Ensure the battery is correctly inserted into the device and the charger.
  - Verify the charger is functioning correctly and connected to a power source.
  - Check for any debris on the battery or device contacts that might prevent proper connection.
- **Device Not Powering On:**
  - Confirm the battery is fully charged.
  - Re-insert the battery to ensure a secure connection.
  - Test the battery in another compatible device if possible, or test your device with a known working battery.
- **Short Battery Life:**
  - Ensure the battery has been fully charged before use.
  - Check if the device settings (e.g., screen brightness, GPS usage) are consuming excessive power.
  - Battery performance can degrade over time with extensive use.

If issues persist, please contact customer support.

## 8. Specifications

| Attribute | Detail |
|---|---|
| Model Number | CS-ZTS200SL |
| Battery Type | Li-ion (Lithium Ion) |
| Capacity | 4400mAh |
| Voltage | 7.4V |
| Watt-Hours (Wh) | 32.56Wh |
| Dimensions | 72.45 x 39.5 x 40.0mm (2.85 x 1.56 x 1.57 inches) |

| | |
|---|---|
| Weight | 270.8g (9.6 ounces) |
| Certifications | ISO9001, RoHS, CE, UN38.3, MSDS |

## 9. Warranty and Support

**Return Policy:** This product is subject to a 30-day refund/replacement return policy from the date of purchase. Please refer to the retailer's specific return guidelines for detailed information.
**Customer Support:** If you have any questions, concerns, or require professional suggestions regarding your battery, please send an email to the manufacturer with your battery details or pictures. Contact information is typically available through your purchase platform or the manufacturer's official website.
All batteries are certified with ISO9001, RoHS, CE, UN38.3, and MSDS, ensuring high quality and safety standards.

© 2023 FITHOOD. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

**Open the live page**

**https://manuals.plus/asin/B09JSC4SH3**

More documents and user manuals: **https://manuals.plus/**