Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEXiBOOK JC798i2

LEXiBOOK Educational and Bilingual Laptop

Instruction Manual - Model JC798i2

1. Introduction

The LEXiBOOK Educational and Bilingual Laptop (Model JC798i2) is designed to provide an engaging learning experience for children. It features 130 activities across various subjects, including Spanish and English language learning, mathematics, dactylography (typing), general knowledge, logic, music, and clock reading. The laptop is equipped with a color screen, a realistic mouse, and a keyboard, offering an ergonomic and interactive platform for educational play.



Figure 1: LEXiBOOK Educational and Bilingual Laptop (Model JC798i2)

2. Setup

2.1 Battery Installation

The LEXiBOOK laptop requires 4 AA batteries (included). To install or replace batteries:

1. Locate the battery compartment on the underside of the laptop.
2. Using a small Phillips head screwdriver, loosen the screw on the battery compartment cover.
3. Remove the cover.
4. Insert 4 AA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
5. Replace the cover and tighten the screw.

2.2 Connecting the Mouse

The laptop comes with a wired mouse for enhanced interaction. Plug the mouse connector into the designated port on

the side of the laptop.

2.3 Powering On/Off

To power on the laptop, locate the 'On/Off' button on the keyboard and press it. To power off, press the 'On/Off' button again. If the device becomes unresponsive, battery removal may be necessary to reset it.

3. Operating the Laptop

The LEXiBOOK laptop offers 130 educational activities accessible via its color screen and keyboard. Navigate through the activities using the keyboard and mouse.

3.1 Educational Activities

- **Language (Spanish & English):** Learn letters, words, typing, and spelling in both languages.
- **Mathematics:** Practice numbers and fundamental calculations (addition, subtraction, multiplication, division).
- **Dactylography (Typing):** Develop typing skills using the computer keyboard to answer questions and play games.
- **General Knowledge:** Explore various topics to broaden understanding.
- **Logic:** Engage in activities designed to test and improve logical reasoning.
- **Music:** Discover musical activities, including notes learning, composing, and playing melodies.
- **Clock Reading:** Learn to tell time with interactive exercises.

3.2 Games

Beyond educational exercises, the laptop includes fun games to test logic, memory, and speed. These activities provide an entertaining way to reinforce learned concepts.



Figure 2: Child engaging with the laptop's activities.



Figure 3: The laptop's compact design allows for use in various settings.

4. Maintenance

To ensure the longevity and proper functioning of your LEXiBOOK laptop, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the laptop. Avoid using liquid cleaners, sprays, or abrasive materials, as these can damage the device.
- **Storage:** Store the laptop in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Handle the laptop with care to prevent drops or impacts that could damage internal components or the screen.

5. Troubleshooting

If you encounter issues with your LEXiBOOK laptop, please refer to the following common solutions:

- **Device Freezes or Becomes Unresponsive:** If the laptop screen freezes or the keyboard/mouse stops responding, remove and reinsert the batteries to perform a hard reset. A small screwdriver may be required to access the battery compartment.
- **No Power:** Ensure that fresh batteries are correctly installed with the proper polarity. If using rechargeable batteries, confirm they are fully charged.
- **Sound Issues:** Check the volume settings on the device. If the problem persists, try resetting the device by removing and reinserting the batteries.

6. Specifications

Feature	Detail

Product Dimensions	9.45 x 7.09 x 1.42 inches
Item Weight	1.57 pounds
Item Model Number	JC798i2
Manufacturer Recommended Age	4 years and up
Batteries	4 AA batteries required (included)
Release Date	October 24, 2021
Manufacturer	LEXIBOOK

7. Warranty and Support

This product is covered by a 2-year warranty, as per safety information. For any questions, technical support, or warranty claims, please contact LEXiBOOK customer service. You can find more information and products on the official LEXiBOOK Store.

© 2025 LEXiBOOK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09K7NMG34

More documents and user manuals: **https://manuals.plus/**