Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun BG3350

Braun Body Groomer 3 Instruction Manual

Model: BG3350

Brand: Braun

1. Product Overview

The Braun Body Groomer 3 is designed for comfortable body grooming, featuring SkinShield technology to protect sensitive skin. This device is engineered for gentle and efficient hair removal across various body areas.

1.1. What's in the Box

- 1 Body Groomer
- 2 Fixed Combs
- 1 Sensitive Area Comb
- 1 Smart Plug Charger
- 1 User Manual



Image 1.1: Braun Body Groomer 3 and its complete set of accessories, including the main unit, various combs, and charging equipment.

2. Safety Information

WARNING: Use this product with care to avoid cuts or skin irritation. Do not use near eyes or in sensitive areas without the protective comb attachment. Keep out of reach of children.

- Always ensure the device is clean and free from damage before use.
- Do not immerse the charger or the device in water.
- Only use the provided Smart plug charger.
- If the device or charger is damaged, discontinue use immediately.

3. Setup

3.1. Charging the Device

1. Connect the Smart plug charger to the groomer.
2. Plug the charger into an electrical outlet.
3. Allow the device to charge fully before first use. A full charge provides approximately 80 minutes of cordless operation.

3.2. Attaching Combs

1. Ensure the groomer is turned off.
2. Select the desired comb (fixed comb or sensitive area comb).
3. Align the comb with the trimmer head and press it firmly until it clicks into place.
4. To remove, gently push the comb upwards and away from the trimmer head.

4. Operating Instructions

4.1. General Body Grooming

The Braun Body Groomer 3 is designed for efficient and comfortable hair removal across the body. Its wide cutting surface captures and trims more hair with each pass.

1. Ensure your skin is clean and dry.
2. Attach the desired comb for your preferred hair length. For closer trims, you may use the device without a comb.
3. Press the power button to turn on the groomer.
4. Hold the groomer at a slight angle against the skin and move it slowly against the direction of hair growth.
5. For best results, stretch the skin taut with your free hand.



Image 4.1: The groomer in use on the torso, illustrating its application for full body hair removal.

4.2. Grooming Sensitive Areas

For sensitive areas, the groomer features SkinShield technology and a dedicated sensitive area comb to minimize the risk of nicks and cuts.

1. Always use the sensitive area comb when grooming delicate skin.
2. Ensure the skin is clean and taut.
3. Move the groomer gently and slowly, applying minimal pressure.
4. Avoid pressing the blade directly against the skin without the comb.



Image 4.2: A detailed view of the sensitive comb, designed to provide optimal comfort and protection during grooming.



Image 4.3: The groomer being used in a sensitive area like the armpit, emphasizing gentle application.



Image 4.4: Demonstrations of the groomer's versatility across different body parts, including chest, groin, and armpit.

5. Maintenance

5.1. Cleaning the Groomer

1. Turn off the groomer and disconnect it from the charger.
2. Remove any attached comb.
3. Use the provided cleaning brush to remove hair from the trimmer head and combs.
4. The trimmer head can be rinsed under running water. Ensure it is completely dry before reattaching or storing.
5. Do not use abrasive cleaners or harsh chemicals.

5.2. Storage

Store the groomer and its accessories in a dry place, away from direct sunlight and extreme temperatures. Ensure the device is fully charged before long-term storage to maintain battery health.

6. Troubleshooting

- **Device not turning on:** Ensure the device is fully charged. Check if the power button is pressed firmly.
- **Poor trimming performance:** Clean the trimmer head and combs thoroughly. Ensure the combs are correctly attached. The blades may need to be replaced if performance does not improve over time.
- **Skin irritation:** Always use the sensitive area comb for delicate skin. Ensure the skin is taut during grooming. Reduce pressure and move the groomer slowly.
- **Charger not working:** Verify the charger is properly plugged into both the device and the wall outlet. Try a different outlet.

7. Specifications

Model Name	Braun Body Groomer 3 BG3350
Brand	Braun
Power Source	Battery Powered
Battery Type	NiHM (2 AAA batteries included)
Battery Life	80 minutes
Blade Material	Stainless Steel or Titanium
Color	Grey/White
Dimensions (L x W x H)	13.7 x 5.7 x 28.2 cm
Weight	365 grams
Special Features	SkinShield Technology, Sensitive Area Comb, Advanced German Design

8. Warranty and Support

For warranty information and customer support, please refer to the documentation included with your product or visit the official Braun website. Keep your proof of purchase for any warranty claims.
For further assistance, please contact Braun customer service through their official channels.

© 2023 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09L78G4T6

More documents and user manuals: **https://manuals.plus/**