Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TRESKO THSL-009

TRESKO 2000W Infrared Standing Heater

MODEL: THSL-009 USER MANUAL

1. Introduction

Thank you for choosing the TRESKO 2000W Infrared Standing Heater. This versatile and energy-efficient radiant heater is designed to provide comfortable warmth for both indoor and outdoor environments. Featuring a carbon tube heating element, multiple power settings, and a convenient remote control, it offers a safe and effective heating solution. Please read this manual thoroughly before operation to ensure proper use, optimal performance, and safety.



Figure 1.1: TRESKO 2000W Infrared Standing Heater and its remote control.

2. Safety Instructions

Your safety is paramount. Please adhere to the following safety guidelines:

- **Read All Instructions:** Before using the heater, read all instructions carefully.
- **Indoor and Outdoor Use:** The heater is rated IP34 for water splash protection, making it suitable for both indoor and outdoor use. However, avoid direct exposure to heavy rain or submersion.
- **Tip-Over Protection:** The heater is equipped with a safety tip-over switch that automatically shuts off the unit if it is accidentally knocked over. Ensure the heater is placed on a stable, level surface.
- **Power Supply:** Connect the heater only to a grounded outlet with the correct voltage (220 Volts). Do not overload the circuit.
- **Clearance:** Maintain a safe distance from flammable materials such as furniture, curtains, and other combustibles.

- **Do Not Cover:** Never cover the heater or block its air vents, as this can lead to overheating.
- **Children and Pets:** Keep children and pets away from the heater, especially when it is in operation, due to hot surfaces.
- **Maintenance:** Always unplug the heater and allow it to cool completely before cleaning or performing any maintenance.
- **Damaged Cord/Plug:** Do not operate the heater with a damaged cord or plug. Contact customer support for assistance.
- **Allergy-Friendly:** The radiant heating process does not stir up dust or dirt, making it suitable for allergy sufferers.



Figure 2.1: Robust and safe design with tip-over protection and efficient carbon tube technology.



Figure 2.2: Weather-resistant design with IP34 rating and accessible main switch.

3. Setup and Assembly

The TRESKO Infrared Heater is designed for quick and easy assembly, typically taking less than 5 minutes.

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Base Assembly:** Attach the heater body securely to the large, stable base plate using the provided screws. Ensure it is firmly seated to prevent wobbling.
3. **Placement:** Place the assembled heater on a firm, level surface, ensuring adequate clearance from walls and other objects (at least 1 meter).
4. **Power Connection:** Plug the power cord into a suitable grounded electrical outlet.

4. Operating Instructions

Operate your TRESKO heater using the control panel on the unit or the included remote control.

- **Power On/Off:** Use the main power switch located on the unit to turn the heater on or off. Once on, the unit will enter standby mode.
- **Activate Heater:** Press the power button on the control panel or remote control to activate the heating element.
- **Adjust Heat Levels:** The heater offers three adjustable heat levels:**650W**, **1350W**, and **2000W**. Use the corresponding buttons on the remote control to cycle through these settings.
- **Timer Function:** Press the 'TIMER' button on the remote control to set an automatic shut-off timer. The timer can be set from 1 to 24 hours. The display will show the remaining time.
- **Quiet Operation:** The heater operates with an extremely low noise level, making it ideal for use in quiet environments, even during sleep or conversations.



Figure 4.1: Modern design and key operational features including remote control, timer, and multiple heat settings.

5. Maintenance

Regular maintenance ensures the longevity and efficient operation of your TRESKO heater.

- **Cleaning:** Always unplug the heater from the power outlet and allow it to cool completely before cleaning. Use a soft, damp cloth to wipe down the exterior. Do not use abrasive cleaners or immerse the heater in water.
- **Protective Grille:** The stainless steel protective grille can be gently wiped to remove dust. Do not attempt to remove the grille.
- **Storage:** When not in use for extended periods, store the heater in a cool, dry place. A protective cover (often included) can be used to shield it from dust and moisture.



Figure 5.1: The heater is elegant and weatherproof, and often includes a protective cover for storage.

6. Troubleshooting

If you encounter issues with your heater, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Heater does not turn on.	No power supply; Main switch off; Tip-over switch activated.	Check power outlet and plug; Ensure main switch is ON; Place heater upright on a stable surface.
Heater not producing enough heat.	Low power setting; Large area; Extreme cold.	Increase heat level (1350W or 2000W); Ensure heater is appropriately sized for the space.
Heater suddenly turns off.	Tip-over switch activated; Overheating protection.	Ensure heater is upright and stable; Unplug, allow to cool for 30 minutes, then restart. Clear any obstructions.
Remote control not working.	Dead batteries; Obstruction.	Replace batteries; Ensure clear line of sight to the heater's receiver.

7. Specifications

Detailed technical specifications for the TRESKO Infrared Standing Heater:

Feature	Specification
Brand	TRESKO
Model Number	THSL-009
Color	Silver
Product Dimensions (L x W x H)	100 x 30 x 30 cm
Item Weight	5 Kilograms
Power Output	650W, 1350W, 2000W (Max)
Voltage	220 Volts
Automatic Shut-off Function	Yes (Tip-over safety)
Special Features	Programmable Thermostat, Countdown Timer, On/Off Timer
IP Rating	IP34 (Water splash resistant)
Heating Method	Radiant
Power Source	Corded Electric
Cable Length	1.8 meters
Material	Stainless steel protective grille, Aluminum housing
Recommended Uses	Garden, Patio, Indoor spaces



Figure 7.1: Key dimensions and detail of the durable stainless steel protective grille.

8. Warranty and Support

TRESKO stands behind the quality of its products.

- **Spare Parts Availability:** Spare parts for this product are available for a period of 2 years from the date of purchase.
- **Customer Support:** For any questions, technical assistance, or warranty claims, please contact your retailer or the manufacturer's customer service. Refer to your purchase documentation for contact details.

9. Intended Use

This TRESKO Infrared Standing Heater is intended for heating purposes in residential and commercial indoor and outdoor environments, such as patios, gardens, workshops, and covered outdoor areas. It is not intended for industrial or continuous heavy-duty use beyond its specified capabilities.



Figure 9.1: The TRESKO heater provides comfortable and cozy warmth for various settings.

© 2024 TRESKO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09M8WBCMS

More documents and user manuals: **https://manuals.plus/**