Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Enbrighten B09M9HK9MT

Enbrighten Dual Power Color Changing LED Rechargeable Lantern

Model: B09M9HK9MT - User Manual

1. Product Overview

The Enbrighten Dual Power Color Changing LED Rechargeable Lantern is a versatile lighting solution designed for various indoor and outdoor applications. It features a rechargeable battery, USB power bank functionality, dimmable white light, and multiple color-changing modes. This manual provides instructions for safe and efficient use of your lantern.



Image 1: Front view of the Enbrighten Dual Power Color Changing LED Rechargeable Lantern.

2. Safety Information

- Read all instructions before use.
- Do not immerse the lantern in water.
- Keep away from open flames and extreme temperatures.
- Do not attempt to disassemble or modify the lantern.
- Use only the specified charging cable and power source.
- Keep out of reach of children.

3. Package Contents

Verify that all items are present:

- Enbrighten Dual Power Color Changing LED Rechargeable Lantern
- USB Charging Cable
- User Manual (this document)

4. Component Identification

Familiarize yourself with the main components of your lantern:

1. **Power Button:** Controls power on/off and light modes.
2. **USB-C Input Port:** For charging the lantern's internal battery.
3. **USB-A Output Port:** For charging external devices (power bank function).
4. **Battery Indicator Lights:** Shows current battery level.
5. **Handle:** For carrying or hanging the lantern.



Image 2: The lantern demonstrating its USB power bank feature, charging a smartphone.

5. Setup

5.1 Initial Charging

Before first use, fully charge the lantern. This ensures optimal battery performance and longevity.

1. Connect the provided USB charging cable to the USB-C input port on the lantern.
2. Connect the other end of the USB cable to a compatible USB power adapter (not included) or a computer USB port.
3. The battery indicator lights will illuminate to show charging progress. All lights will be solid when fully charged.



Image 3: The lantern with a charging cable connected, indicating the charging process.

6. Operating the Lantern

6.1 Power On/Off and White Light Modes

- **Press the Power Button once:** The lantern will turn on to its brightest white light setting.
- **Press the Power Button repeatedly:** Cycle through different white light brightness levels (High, Medium, Low).
- **Press and hold the Power Button:** The lantern will turn off.

6.2 Color Changing Modes

To activate color modes, ensure the lantern is on in any white light setting.

- **Double-press the Power Button:** The lantern will switch to a color-changing mode.
- **Double-press again:** Cycle through various static color options or dynamic color effects.
- **Single-press the Power Button:** Return to white light modes.

6.3 USB Power Bank Function

The lantern can be used to charge other USB-powered devices.

1. Connect your device's charging cable to the USB-A output port on the lantern.
2. The lantern's internal battery will begin charging your device.
3. Monitor your device's charging status.

7. Care and Maintenance

- **Cleaning:** Wipe the lantern with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the lantern in a cool, dry place when not in use. For extended storage, charge the battery every 3-6 months to maintain its health.
- **Battery:** The internal battery is not user-replaceable. Do not attempt to remove or replace it.

8. Troubleshooting

Problem	Possible Cause	Solution
Lantern does not turn on.	Battery is depleted.	Charge the lantern fully.
Lantern not charging.	Charging cable or adapter faulty; improper connection.	Ensure cable is securely connected. Try a different USB cable or power adapter.
External device not charging from lantern.	Lantern battery low; improper connection; device incompatible.	Ensure lantern is sufficiently charged. Check cable connection. Verify device compatibility.
Light flickers or is dim.	Low battery.	Recharge the lantern.

9. Specifications

- **Model:** B09M9HK9MT
- **Battery Capacity:** 4400mAh
- **Light Output:** Up to 650 Lumens
- **Runtime:** Up to 425 Hours (on lowest setting)
- **Features:** Dimmable white light, color-changing modes, USB power bank

10. Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or visit the official Enbrighten website. Specific warranty terms may vary by region and retailer.

Manufacturer: Jasco Products Company, LLC

Website: www.enbrighten.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09M9HK9MT

More documents and user manuals: **https://manuals.plus/**