Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TRESKO THSL-009

TRESKO THSL-009 2500W Infrared Heater User Manual

Model: THSL-009

1. Introduction

This manual provides essential information for the safe and efficient operation of your TRESKO THSL-009 2500W Infrared Heater. Please read these instructions carefully before installation and use, and retain them for future reference.



Image 1.1: TRESKO 2500W Infrared Heater, remote control, and protective cover.

The TRESKO THSL-009 is a versatile infrared heater designed for both indoor and outdoor use, offering efficient and immediate warmth. It features three adjustable heat levels, a remote control, and a built-in timer for convenient operation.

2. Safety Instructions

WARNING: Failure to follow these safety instructions may result in fire, electric shock, or injury.

- Read all instructions before using this heater.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or heater in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, or has been dropped or damaged in any manner.
- Do not use outdoors unless specifically designed for outdoor use and protected from direct weather exposure. This heater is designed for both indoor and outdoor use, but ensure it is installed in a protected

area when used outdoors.

- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.
- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- Ensure the power supply matches the voltage specified on the heater's rating label.
- Keep flammable materials such as furniture, papers, clothes, and curtains at least 1 meter (3 feet) from the front of the heater and away from the sides and rear.
- Do not cover the heater.
- The heater is equipped with a protective grid. Do not remove this grid during operation.



Image 2.1: The heater is designed for both indoor and outdoor use and is corrosion resistant.

3. Product Features

- **Energy-Efficient Heating:** Integrated Instant-Heat process provides warmth in seconds. Quartz tube technology is approximately 30% more economical than standard halogen tubes.
- **Versatile Use:** Suitable for both indoor and outdoor environments. Waterproof and corrosion-resistant design.
- **Adjustable Heat Levels:** Three power settings (850W, 1650W, 2500W) for customized heating.
- **Remote Control Operation:** Conveniently adjust settings from a distance.
- **Integrated Timer:** Set operation duration from 1 to 24 hours.
- **Adjustable Tilt Angle:** The heater can be angled to direct heat precisely.
- **Quiet Operation:** Extremely low noise level, suitable for use in quiet environments.
- **Durable Construction:** Robust stainless steel protective grid and aluminum housing.
- **Direct Heat Reflection:** Reflector effect ensures direct heat distribution in all directions.
- **LED Display:** Provides clear indication of current settings.



Image 3.1: Key features including quick heating, cable length, timer, heat levels, and maximum power.

4. Package Contents

Please check the package contents upon unpacking. If any parts are missing or damaged, contact your retailer.

- TRESKO THSL-009 Infrared Heater
- Remote Control
- Mounting Hardware (screws, wall plugs, brackets)
- Protective Cover
- User Manual (this document)

5. Setup and Installation

The TRESKO THSL-009 heater is designed for wall mounting. Ensure the mounting surface is sturdy and can support the weight of the heater.

5.1 Choosing a Location

- Maintain a minimum distance of 1 meter (3 feet) from flammable materials.
- Ensure adequate clearance around the heater for proper air circulation.
- Avoid mounting near water sources or in areas where it could be splashed.
- The heater should be mounted at a height where it is not easily accessible to children or pets.

5.2 Mounting Instructions

1. Mark the desired mounting points on the wall using the provided bracket as a template.
2. Drill holes at the marked points.
3. Insert wall plugs into the drilled holes.
4. Secure the mounting bracket to the wall using the screws.
5. Attach the heater to the mounting bracket. Ensure it is securely fastened.
6. Adjust the tilt angle of the heater as desired.



Image 5.1: Illustration of easy wall mounting and construction details.



Image 5.2: Dimensions and adjustable mounting feature.

6. Operating Instructions

The heater can be operated using the remote control.

6.1 Remote Control Functions

- **Power Button:** Turns the heater ON or OFF.
- **Heat Level Buttons (850W, 1650W, 2500W):** Selects the desired heating power.
- **Timer Button:** Activates and adjusts the timer function (1-24 hours).

6.2 Initial Operation

1. Ensure the heater is securely mounted and plugged into a suitable power outlet.
2. Press the Power button on the remote control to turn on the heater. The LED display will illuminate.
3. Select your desired heat level (850W, 1650W, or 2500W) using the corresponding buttons on the remote.
4. To set the timer, press the Timer button and use the arrow buttons (if available on remote, otherwise repeated presses) to select the desired operating duration (1-24 hours). The heater will automatically turn off

after the set time.
5. To turn off the heater, press the Power button again.

The heater provides immediate warmth upon activation.

7. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your heater.

7.1 Cleaning

- Always unplug the heater from the power outlet and allow it to cool completely before cleaning.
- Do not immerse the heater in water or any other liquid.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Gently clean the protective grid with a soft brush or vacuum cleaner to remove dust and debris.
- Ensure all parts are completely dry before plugging the heater back in.

7.2 Storage

- If storing the heater for an extended period, clean it thoroughly.
- Use the provided protective cover to shield the heater from dust and moisture.
- Store the heater in a cool, dry place, away from direct sunlight and extreme temperatures.

8. Troubleshooting

Problem	Possible Cause	Solution
Heater does not turn on.	• Not plugged in. • Power outlet malfunction. • Remote control batteries are dead. • Overheat protection activated.	• Ensure the power cord is securely plugged into a working outlet. • Test the outlet with another appliance. • Replace remote control batteries. • Unplug the heater, allow it to cool for 30 minutes, then plug it back in.
Heater produces insufficient heat.	• Incorrect heat level selected. • Heater is too far from the target area. • Large open space or strong drafts.	• Increase the heat level using the remote control. • Adjust the heater's position or tilt angle to direct heat more effectively. • Minimize drafts or consider using multiple heaters for very large areas.
Remote control not working.	• Batteries are dead or incorrectly inserted. • Obstruction between remote and heater.	• Replace batteries, ensuring correct polarity. • Ensure a clear line of sight between the remote and the heater's receiver.

If the problem persists after attempting these solutions, please contact customer support.

9. Specifications

Feature	Detail
Model Number	THSL-009
Brand	TRESKO
Power Output	850W / 1650W / 2500W (3 levels)
Dimensions (L x W x H)	87 cm x 18 cm x 9 cm (approx.)
Weight	4 kg
Cable Length	2.0 m
Timer Function	1-24 hours
Control Method	Remote Control
Housing Material	Aluminum
Protective Grid Material	Stainless Steel
Usage Environment	Indoor / Outdoor

10. Warranty and Support

TRESKO products are manufactured to high-quality standards. For information regarding warranty terms and conditions, please refer to the documentation provided with your purchase or contact your retailer. For technical support or inquiries, please reach out to TRESKO customer service through their official channels.

© 2024 TRESKO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09MDBJHF3

More documents and user manuals: **https://manuals.plus/**