Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Geepas GWM36538

Geepas GWM36538 Waffle Maker Instruction Manual

Model: GWM36538 | Brand: Geepas

1. Introduction

This manual provides essential information for the safe and efficient operation of your Geepas GWM36538 Waffle Maker. Please read all instructions carefully before first use and retain this manual for future reference. This appliance is designed for domestic use only.

2. Important Safety Instructions

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical hazards, do not immerse the cord, plugs, or the appliance in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use the appliance for other than intended use.

3. Product Features

The Geepas GWM36538 Waffle Maker is designed for convenience and performance, allowing you to create delicious heart-shaped waffles.

- **5 Heart-Shaped Waffles:** Prepare up to five heart-shaped waffles simultaneously.
- **Non-Stick Coated Plates:** Ensures easy release of waffles and simplifies cleaning.
- **Adjustable Temperature Control:** Customize the browning level from soft to crispy.
- **Power and Ready Indicator Lights:** Clearly indicates when the appliance is powered on and preheated to the desired temperature.
- **1000W Heating Element:** Provides rapid heat-up for efficient cooking.
- **Compact & Space-Saving Design:** Ideal for smaller kitchens and minimal counter space.
- **Stable Non-Slip Feet:** Keeps the waffle maker secure on your worktop during operation.
- **Overheat Protection:** Automatically switches off for safe and reliable operation.



Image: The Geepas GWM36538 Waffle Maker, showcasing its ability to make multiple heart-shaped waffles at once.



Image: Easily remove heart-shaped waffles from the non-stick plates.

4. Setup

1. **Unpack:** Carefully remove the waffle maker and all packaging materials.
2. **Initial Cleaning:** Wipe the non-stick cooking plates with a damp cloth or sponge. Dry thoroughly.
3. **First Use Preparation:** For the first use, lightly grease the cooking plates with a small amount of cooking oil or butter. This helps condition the non-stick surface.
4. **Placement:** Place the waffle maker on a stable, heat-resistant, and dry surface. Ensure there is adequate ventilation around the appliance.

5. Operating Instructions

1. **Preheat:** Close the waffle maker and plug it into a 240V electrical outlet. The power indicator light will illuminate.
2. **Set Temperature:** Use the adjustable temperature control dial to select your desired browning level. Turn the dial

clockwise for crispier waffles and counter-clockwise for softer waffles.

3. **Ready Indicator:** Allow the waffle maker to preheat. The green 'Ready' indicator light will turn on when the appliance has reached the set temperature. This typically takes a few minutes.
4. **Add Batter:** Once the 'Ready' light is on, open the waffle maker. Pour your waffle batter evenly onto the lower cooking plate, ensuring it fills the heart-shaped sections without overflowing.
5. **Cook:** Close the lid gently. Do not force it shut. The 'Ready' light may turn off during cooking and cycle on and off as the appliance maintains temperature.
6. **Check Doneness:** Cooking time varies based on batter type and desired crispness. Typically, waffles are ready in 3-5 minutes. Open the lid to check.
7. **Remove Waffles:** Once cooked, use a heat-resistant plastic or wooden utensil to carefully remove the waffles. Do not use metal utensils, as they can damage the non-stick coating.
8. **Repeat:** Close the lid and wait for the 'Ready' light to illuminate again before adding more batter.
9. **Finish:** When you are finished cooking, unplug the waffle maker from the outlet.



Image: Pouring waffle batter into the preheated heart-shaped molds.



Image: The adjustable temperature control dial for precise browning.

6. Cleaning and Maintenance

Proper cleaning and maintenance will extend the life of your waffle maker.

1. **Cool Down:** Always unplug the appliance and allow it to cool completely before cleaning.
2. **Clean Plates:** Wipe the non-stick cooking plates with a soft, damp cloth or sponge. For stubborn residue, a small amount of mild dish soap can be used. Avoid abrasive cleaners or scouring pads, as these can damage the non-stick coating.
3. **Exterior:** Wipe the exterior of the waffle maker with a damp cloth. Do not immerse the appliance in water or any other liquid.
4. **Storage:** Once clean and dry, store the waffle maker in a cool, dry place. The compact design allows for easy storage.



Image: Cleaning the non-stick coated plates for easy maintenance.

7. Troubleshooting

Problem	Possible Cause	Solution
Waffles are not cooking evenly or are too pale.	Insufficient preheating time; temperature setting too low; uneven batter distribution.	Ensure the 'Ready' light is on before adding batter. Increase the temperature setting. Distribute batter evenly across all molds.
Waffles stick to the plates.	Plates not properly seasoned; too little oil/butter; batter too sticky.	Lightly grease plates before each use, especially for the first few batches. Ensure plates are clean. Adjust batter consistency if necessary.
Waffle maker does not heat up.	Not plugged in; power outage; appliance malfunction.	Check if the power cord is securely plugged into a working outlet. Check your circuit breaker. If the issue persists, contact customer support.

Problem	Possible Cause	Solution
Waffles are too soft or too crispy.	Incorrect temperature setting or cooking time.	Adjust the temperature control dial to a higher setting for crispier waffles or a lower setting for softer waffles. Adjust cooking time accordingly.

8. Specifications

Feature	Detail
Brand	Geepas
Model Number	GWM36538
Color	Silver and Black
Product Dimensions	22.5 x 28.5 x 13.5 cm (Depth x Width x Height)
Item Weight	1.62 Kilograms
Power/Wattage	1000 Watts
Voltage	240 Volts
Material	Cast Iron
Special Features	Temperature Control, Non-Stick Coating, Elegant Touch
Automatic Shutoff	No
Included Components	Waffle Maker

9. Warranty and Support

Your Geepas GWM36538 Waffle Maker comes with a**2-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures reliable operation under normal household use.
For warranty claims, technical support, or any inquiries regarding your product, please contact Geepas customer service through their official website or the retailer where the product was purchased. Please have your model number (GWM36538) and proof of purchase available when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09MJDC2Z8

More documents and user manuals: **https://manuals.plus/**