Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Snow Joe 24V-SS13-XR

Snow Joe 24V-SS13-XR 24-Volt IONMAX 13-Inch 5-Ah Cordless Snow Shovel User Manual

Model: 24V-SS13-XR | Brand: Snow Joe

Introduction

The Snow Joe 24V-SS13-XR is a cordless, grab-n-go snow-busting tool designed for easy and convenient snow removal. Powered by Snow Joe's IONMAX lithium-ion battery system, this snow shovel is ideal for quick pickups on decks, steps, patios, and sidewalks. It is lightweight, weighing less than 13.5 lbs, and features a dual-handle design for user comfort. The heavy-duty 2-blade paddle auger can clear a 13-inch wide by 6-inch-deep path, throwing snow up to 20 feet away. A durable scraper blade at the base ensures clearing right to the ground without damaging surfaces.



Image: The Snow Joe 24V-SS13-XR Cordless Snow Shovel kit, including the main unit, a 24V IONMAX 5.0-Ah rechargeable Lithium-ion battery, and a quick charger.

Safety Information

Always read and understand all safety warnings and instructions before operating the Snow Joe 24V-SS13-XR. Failure to follow the warnings and instructions may result in electric shock, fire, and/or serious injury.

- Keep hands, feet, and clothing away from moving parts.
- Ensure the battery is fully charged before use.
- Do not operate in conditions beyond the product's intended use (e.g., extremely heavy or wet snow, ice).
- Wear appropriate personal protective equipment, including eye protection and non-slip footwear.
- Keep children and bystanders away from the operating area.
- Always turn off the unit and remove the battery before performing any maintenance or clearing clogs.

Setup

The Snow Joe 24V-SS13-XR comes partially disassembled for shipping. Follow these steps for proper assembly:

1. **Handle Assembly:** Connect the three-piece handle sections. Ensure the internal electrical cord is properly routed and does not get pinched during assembly. Some users have noted that careful alignment and gentle turning of the sections are required to fit the cord.
2. **Attach Auxiliary Handle:** Secure the auxiliary handle to the main shaft using the provided knob. This handle can be adjusted for optimal user comfort and control.
3. **Battery Insertion:** Insert the fully charged 24V IONMAX 5.0-Ah rechargeable Lithium-ion battery into the designated slot on the main handle. Ensure it clicks securely into place.



Image: A hand demonstrating the insertion of the 24V IONMAX battery into the handle of the Snow Joe Cordless Snow Shovel.

For a visual guide on assembly and operation, please refer to the official demonstration video below:

▶ **Watch video online**
Snow Joe 24V-SS13 Demo

Video: Official Snow Joe 24V-SS13 Demo. This video demonstrates the assembly and operational features of the cordless snow shovel, including how it clears snow from various surfaces.

Operating Instructions

The Snow Joe 24V-SS13-XR is designed for efficient and comfortable snow removal. Follow these steps for optimal performance:

1. **Starting the Unit:** To activate the snow shovel, first press the safety button located on the handle, then squeeze the trigger. The auger will begin to spin.
2. **Clearing Snow:** Push the shovel forward into the snow. The 400W motor and 2-blade high-impact paddle auger

will move up to 300 lbs of snow per minute, throwing it up to 20 feet away.

3. **Path Clearing:** The unit clears a 13-inch wide by 6-inch-deep path. For best results, work in parallel passes, slightly overlapping each pass to ensure complete clearing.
4. **Edge Clearing:** The durable scraper blade at the base allows you to clear snow right down to the ground without damaging surfaces like decks or pavements.
5. **Battery Life:** A fully charged 5.0-Ah battery provides extended runtime for tackling snow removal jobs. Monitor battery indicator lights if available.



Image: The Snow Joe 24V-SS13-XR Cordless Snow Shovel effectively clearing a path through snow, demonstrating its operational

capability.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your Snow Joe 24V-SS13-XR:

- **Cleaning:** After each use, remove any snow, ice, or debris from the auger and housing. Use a damp cloth to wipe down exterior surfaces. Do not use harsh chemicals.
- **Battery Care:** Store the battery in a cool, dry place away from direct sunlight and extreme temperatures. Charge the battery fully before long-term storage.
- **Blade Inspection:** Periodically inspect the 2-blade paddle auger and scraper blade for wear or damage. Replace worn parts as needed to maintain clearing efficiency.
- **Storage:** When not in use, store the snow shovel in a dry, protected area. Its compact design allows for easy storage in a hall closet or garage.

Troubleshooting

If you encounter issues with your Snow Joe 24V-SS13-XR, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Unit does not turn on.	Battery not inserted correctly or not charged. Safety button/trigger not engaged properly.	Ensure battery is fully charged and securely inserted. Press safety button first, then squeeze the trigger.
Reduced snow throwing distance or clogging.	Wet, heavy snow. Debris caught in auger. Worn auger blades.	Clear snow in thinner passes. Turn off unit and remove battery, then clear any debris from auger. Inspect and replace worn auger blades.
Handle feels wobbly after assembly.	Handle sections not fully tightened.	Ensure all handle connection knobs are tightened securely. Consider adding washers if looseness persists (refer to user manual for specific guidance).

Specifications

Brand: Snow Joe

Model: 24V-SS13-XR

Power Source: Battery Powered (24V IONMAX Lithium-ion)

Motor: 400 W

Item Weight: 13.5 Pounds

Color: Blue

Maximum Throw Distance: 20 Feet

Clearing Width: 13 Inches

Ideal Snow Depth: 6 Inches

Product Dimensions: 14.5"D x 12.5"W x 25"H

UPC: 842470126817

Warranty and Support

For detailed warranty information, product registration, or further support, please refer to the official user manual provided with your product or visit the Snow Joe website. Protection plans are also available for extended coverage. You can access the official User Manual (PDF)here.

© 2024 Snow Joe. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09MV6TC76

More documents and user manuals: **https://manuals.plus/**