Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DeLUX DELUX M618PD

DeLUX M618PD Wireless Ergonomic Vertical Mouse

Instruction Manual

Overview Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Product Overview

The DeLUX M618PD is a wireless ergonomic vertical mouse designed to reduce wrist and hand strain associated with prolonged computer use. Its unique volute bionic design promotes a natural handshake posture, minimizing discomfort and improving accuracy. This mouse offers multi-device connectivity, adjustable DPI settings, and a comfortable, durable build.



Figure 1: DeLUX M618PD Vertical Ergonomic Mouse, showcasing its unique upright design.

Key Features:

- **Ergonomic Design:** Unique volute bionic design reduces arm discomfort and hand stiffness. Frosted texture is anti-sweat and dust-resistant.
- **Rechargeable and Multi-Device Connectivity:** Built-in 500mAh rechargeable battery provides up to a week of usage. Supports 2.4G wireless, BT1, and BT2 for seamless multi-device connectivity, allowing easy switching between up to 3 devices.
- **Precision Tracking with Adjustable DPI:** Five adjustable DPI settings (800 to 4000 DPI) for high precision tracking with minimal movement.
- **Removable Wrist Rest:** Includes a removable wrist rest to protect your wrist from friction and reduce strain.
- **Wide Compatibility:** Compatible with Windows 7, 8, 10, 11, and Mac OS operating systems.
- **Silent and Quiet Clicks:** Designed for less distraction and more focus during use.



Figure 2: Comparison illustrating the natural handshake posture promoted by the vertical ergonomic design versus a traditional mouse grip, highlighting reduced nerve compression.

2. Setup Guide

2.1. Unboxing and Initial Inspection

Carefully remove the DeLUX M618PD mouse and its accessories from the packaging. Verify that all components are present: the vertical mouse, USB receiver, and charging cable. Inspect the mouse for any visible damage.

2.2. Charging the Mouse

The mouse comes with a built-in 500mAh rechargeable battery. Before first use, it is recommended to fully charge the mouse.

1. Locate the charging port on the front of the mouse (typically a USB-C or Micro-USB port).
2. Connect the provided charging cable to the mouse and plug the other end into a USB power source (e.g., computer USB port, USB wall adapter).
3. The charging indicator light will illuminate. Once fully charged, the light may change color or turn off. A full charge provides up to a week of usage (based on 8 hours/day).



Figure 3: The DeLUX M618PD mouse connected via its charging cable, illustrating its built-in rechargeable battery feature.

2.3. Connecting the Mouse

The DeLUX M618PD supports three connection modes: 2.4G wireless (via USB receiver), Bluetooth 1 (BT1), and Bluetooth 2 (BT2). You can connect to up to three devices simultaneously and switch between them.

1. **Power On:** Locate the ON/OFF switch on the bottom of the mouse and slide it to the 'ON' position.
2. **Mode Selection:** Press the 'Mode' button on the bottom of the mouse to cycle through the connection modes (2.4G, BT1, BT2). The corresponding indicator light will show the active mode.
3. **2.4G Wireless Connection:**
    - Select 2.4G mode using the 'Mode' button.
    - Insert the USB receiver into an available USB port on your computer.
    - The mouse should automatically connect. If not, try pressing the 'Mode' button again or re-inserting the receiver.
4. **Bluetooth Connection (BT1/BT2):**
    - Select either BT1 or BT2 mode using the 'Mode' button.

- Press and hold the 'Mode' button for 3-5 seconds until the indicator light for the selected Bluetooth channel starts blinking rapidly. This indicates pairing mode.
- On your computer or device, go to Bluetooth settings and search for new devices.
- Select 'DeLUX M618PD' (or similar name) from the list of available devices to pair.
- Once paired, the indicator light will stop blinking and remain solid.



Figure 4: The DeLUX M618PD mouse connected to multiple devices (laptop, tablet, smartphone) via 2.4G and Bluetooth, demonstrating its multi-device workflow capability.

3. Operating Instructions

3.1. Holding the Mouse

The DeLUX M618PD is designed for a natural handshake grip. Place your hand over the mouse so your palm rests

comfortably on the body and your fingers align with the buttons. The removable palm rest can be attached for additional wrist support.



Figure 5: A hand demonstrating the natural, comfortable grip on the DeLUX M618PD vertical mouse, positioned next to a keyboard and tablet.

3.2. Button Functions

The mouse features 6 programmable buttons for enhanced productivity:



Figure 6: Detailed diagram of the DeLUX M618PD button layout, indicating the forward/backward buttons, left/right click, scroll wheel, DPI shift, and mode switch.

- **Left Button (3):** Standard left-click function.
- **Right Button (5):** Standard right-click function.
- **Scroll Wheel (4):** Scroll up/down, and middle-click when pressed.
- **Forward Button (1):** Navigates forward in web browsers or file explorers.
- **Backward Button (2):** Navigates backward in web browsers or file explorers.
- **DPI Shift Button (7):** Adjusts the mouse sensitivity (DPI).

3.3. Adjusting DPI (Sensitivity)

The mouse offers five adjustable DPI levels for precise control, ranging from 800 to 4000 DPI. Press the DPI Shift Button (7) located on the bottom of the mouse to cycle through the available DPI settings. Higher DPI allows for faster cursor movement with less physical mouse movement.



Figure 7: Illustration of the mouse's high precision tracking up to 4000 DPI, emphasizing less movement and less fatigue.

3.4. Switching Between Connected Devices

If you have connected the mouse to multiple devices using 2.4G, BT1, and BT2 modes, you can easily switch between them by pressing the 'Mode' button (9) on the bottom of the mouse. Each press will cycle to the next connected device.

4. Maintenance

4.1. Cleaning

To maintain optimal performance and hygiene, regularly clean your DeLUX M618PD mouse. Use a soft, lint-free cloth lightly dampened with water or a mild cleaning solution. Avoid harsh chemicals or abrasive materials. Ensure no liquid enters the mouse's internal components.

4.2. Charging

Recharge the mouse when the battery indicator shows low power or when you notice a delay in responsiveness. Use the provided charging cable for best results. Avoid overcharging for extended periods, though the mouse has built-in protection against this.

5. Troubleshooting

Problem	Possible Cause	Solution
Mouse not responding	Low battery; Incorrect connection mode; USB receiver not properly inserted (2.4G); Bluetooth not paired.	Charge the mouse; Switch to the correct connection mode (2.4G, BT1, BT2); Re-insert USB receiver; Re-pair Bluetooth.
Cursor movement is erratic or slow	Low DPI setting; Dirty optical sensor; Uneven surface.	Increase DPI using the DPI button; Clean the optical sensor; Use on a smooth, clean surface or mouse pad.
Cannot switch between devices	Devices not properly paired/connected to all channels.	Ensure all desired devices are paired to their respective 2.4G, BT1, or BT2 channels.
Wrist rest feels uncomfortable	Personal preference or incorrect positioning.	Adjust the position of the wrist rest or remove it if preferred. It may take a few days to adapt to the ergonomic design.

6. Specifications

Feature	Detail
Model Number	DELUX M618PD
Connectivity Technology	2.4G Wireless, Bluetooth (BT1, BT2)
DPI Settings	800 / 1200 / 1600 / 2400 / 4000 DPI (Adjustable)
Buttons	6 (Left, Right, Scroll Wheel, Forward, Backward, DPI Shift)
Battery	Built-in 500mAh Lithium Ion rechargeable battery
Item Weight	6 ounces (approx. 170g)
Product Dimensions	5.87 x 3.74 x 3.9 inches (approx. 14.9 x 9.5 x 9.9 cm)
Compatibility	Windows 7/8/10/11, Mac OS

Feature	Detail
Special Features	Ergonomic Design, Rechargeable, Soundless Clicks, Wireless, Removable Palm Rest

7. Warranty & Support

DeLUX products are designed for quality and reliability. For specific warranty details and support information, please refer to the warranty card included with your product packaging or visit the official DeLUX website. Keep your purchase receipt as proof of purchase for warranty claims.
For technical assistance or customer service inquiries, please contact DeLUX support through the channels provided in your product documentation.

© 2025 DeLUX. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09N972T84

More documents and user manuals: **https://manuals.plus/**