Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Rock&Rocker HWY12P

Rock&Rocker Electric Pressure Washer User Manual

Model: HWY12P

Product Overview

The Rock&Rocker Electric Pressure Washer is a powerful cleaning tool designed for various household and outdoor tasks. It features a robust 1500W motor, delivering up to 1950 PSI of water pressure at a maximum flow rate of 1.58 GPM, making it effective for removing dirt and stains from vehicles, driveways, patios, and more.



Figure 1: Rock&Rocker Electric Pressure Washer with included accessories.

Key features include a leak-proof design with metal connectors, a Total Stop System (TSS) for energy saving and pump longevity, and 360° large spinner wheels for easy mobility and anti-tipping stability. It comes equipped with four quick-connect nozzles and a soap tank to meet diverse cleaning needs.

Safety Information

WARNING: To reduce the risk of injury, users must read and understand this manual before using this product. Always follow basic safety precautions to reduce the risk of fire, electric shock, and personal injury.

- Never point the spray gun at any person or pet. The high-pressure stream can cause serious injury.
- Never allow children to play around the pressure washer when it is in use. Keep children and pets away from the operating area.

- It is strictly forbidden to use the machine without water. If water stops during use, immediately shut down the machine (the machine cannot run without water for more than 1 minute) to prevent damage.
- Ensure the safety plug is properly connected to automatically cut off electric power pressure and prevent electrical leakage.
- Always engage the safety lock switch on the spray gun when not actively spraying to prevent accidental spraying and ensure safety.
- The Total Stop System (TSS) automatically shuts off the pump when the trigger is not engaged, saving energy and prolonging pump life.

Package Contents

Before assembly, ensure all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.



Figure 2: All components included in the Rock&Rocker Electric Pressure Washer package.

- Rock&Rocker Electric Pressure Washer Unit
- High-Pressure Hose (16.4 ft)
- Power Cord (16.4 ft) with GFCI breaker
- Spray Gun
- Wand Extension
- 4 Quick-Connect Nozzles (0°, 15°, 25°, 40°)
- 250ml Soap Bottle
- 4 Quick-Lock Wheels
- Hose Hook
- Cable Hook

- User Manual
- Nozzle Cleaning Needle

Setup

Follow these steps to assemble your pressure washer before first use.

1. Assemble Wheels

Insert the four quick-lock wheels into their designated slots on the bottom of the pressure washer unit. Secure them with the provided screws using a Phillips head screwdriver. Ensure they are snug but do not overtighten to avoid stripping.



Figure 3: Installing the quick-lock wheels.

2. Attach Hose and Cable Hooks

Slide the hose hook and cable hook into their respective slots on the back and side of the pressure washer unit. These are designed to slide and click into place, providing convenient storage for the high-pressure hose and power cord.

3. Connect Water Inlet Filter

Screw the water inlet filter onto the water inlet connection point on the pressure washer unit. Ensure it is tightened securely to prevent leaks.



Figure 4: Connecting the water inlet filter.

4. Connect High-Pressure Hose

Connect one end of the high-pressure hose to the high-pressure outlet on the pressure washer unit. Twist the connection firmly until it is secure. Connect the other end of the high-pressure hose to the spray gun.



Figure 5: Connecting the high-pressure hose to the spray gun.

5. Connect Spray Gun and Wand

Attach the wand extension to the front of the spray gun. Push it in and twist until it locks securely. Select your desired quick-connect nozzle and insert it into the end of the wand extension, pulling back the collar to lock it in place.

6. Connect Water Supply

Connect your garden hose to the water inlet filter on the pressure washer. Ensure the garden hose is fully turned on before starting the pressure washer to allow the pump to prime and build pressure.

▶ **Watch video online**
(New Model) Rock&Rocker Electric Pressure Washer, 1950PSI

Video 1: This video demonstrates the assembly process of the Rock&Rocker Electric Pressure Washer, including attaching wheels, connecting hoses, and setting up the spray gun.

Operating Instructions

Nozzle Selection

The pressure washer comes with four quick-connect nozzles, each designed for specific cleaning tasks:

- **0° (Red) Nozzle:** Delivers a powerful, pencil-point jet stream for intense cleaning jobs on hard, stubborn dirt and weeds. Use with extreme caution as it can damage surfaces.
- **15° (Yellow) Nozzle:** Provides a concentrated fan spray for intense cleaning on hard surfaces like concrete, brick, and metal.
- **25° (Green) Nozzle:** Offers a wider fan spray suitable for general cleaning of home siding, brick patios, wood decks, driveways, or sidewalks.
- **40° (White) Nozzle:** Delivers the widest, gentlest spray, ideal for cleaning delicate surfaces such as cars, trucks, boats, patio furniture, or lawn equipment.



Figure 6: Universal 15°, 25°, and 40° nozzles for various cleaning applications.



Figure 7: The 0° nozzle provides a pencil spray for blasting deep dirt.

Using the Soap Tank

The 250ml soap bottle allows for easy application of detergent. Fill the bottle with your desired pressure washer-safe soap solution. Remove the standard nozzle from the wand and attach the soap bottle assembly. The pressure washer will automatically mix the soap with the water for foaming applications.



Figure 8: The foam cannon is an ideal companion for car washing.

Starting the Unit

Once fully assembled and connected to a water supply, plug the power cord into a grounded outlet. Turn the main power switch to the "ON" position. The pump will run briefly to build pressure and then the Total Stop System (TSS) will automatically shut off the motor. The motor will only run when the spray gun trigger is pressed.

Safety Lock

The spray gun features a safety lock switch. Always engage this lock when the pressure washer is not in active use to prevent accidental spraying and ensure safety.



Figure 9: Safety features including GFCI Protection, Total Stop System, and Safety Lock.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your pressure washer.

Cleaning Nozzles

If the nozzle becomes clogged, use the provided nozzle cleaning needle to clear any debris. Always disconnect the nozzle from the wand before cleaning.

Storage

After each use, drain all water from the pump and hoses. Store the pressure washer in a dry, frost-free area. Utilize the integrated hose and cable hooks for tidy storage. The compact design and 360° wheels make it easy to move and store in tight spaces.



Figure 10: Lightweight design for convenient storage and portability.

Troubleshooting

Problem	Possible Cause	Solution
Motor does not start	No power supply; GFCI tripped; Water supply off.	Check power connection; Reset GFCI; Ensure water supply is fully open.
No pressure or low pressure	Insufficient water supply; Clogged nozzle; Air in pump; Leaking connections.	Check water flow; Clean nozzle with needle; Purge air by running without nozzle; Tighten all connections.

Problem	Possible Cause	Solution
Water leakage	Loose connections; Damaged O-rings.	Tighten all hose and gun connections; Inspect and replace O-rings if damaged.

For further assistance, please refer to the "Warranty and Support" section.

Specifications

Feature	Detail
Brand	Rock&Rocker
Model Number	HWY12P
Power Source	Electric
Maximum Pressure	1950 PSI
Maximum Flow Rate	1.58 GPM
Motor Power	1500W
Item Weight	13.6 Pounds
Hose Length	16.4 Feet
Product Dimensions (L x W x H)	15.75" x 15.75" x 25"
Tank Volume (Soap)	250 Milliliters
IPX Rating	IPX5

Warranty and Support

The Rock&Rocker Electric Pressure Washer comes with a**12-month warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

For any product-related inquiries, technical support, or warranty claims, please contact our customer service team:

Email: support@rockrocker.com

Free Call: (US) (877)-756-8666



Figure 11: Rock&Rocker customer support details.

Our expert team is ready to respond to your needs with helpful solutions and professional repair service.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I properly hook up the water hose to the Rock&Rocker HWY12P pressure washer to prevent leaking?

To properly connect your water hose to the Rock&Rocker HWY12P and resolve leaking issues, follow these specific steps from the manual: Install the Water Inlet Filter: Before attaching your garden hose, you must screw...

Read full answer

Open the live page

https://manuals.plus/asin/B09NBNRDP4

More documents and user manuals: **https://manuals.plus/**