Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PHILIPS SPK7405

Philips SPK7405 2.4GHz Wireless Optical Mouse User Manual

Model: SPK7405

1. Introduction

Thank you for choosing the Philips SPK7405 2.4GHz Wireless Optical Mouse. This manual provides essential information for setting up, operating, and maintaining your new wireless mouse. Please read this guide thoroughly before using the product to ensure optimal performance and longevity.

2. Package Contents

Please check the package contents carefully. If any items are missing or damaged, contact your retailer.

- Philips SPK7405 Wireless Optical Mouse
- USB Receiver (stored inside the mouse)
- AA Battery (1 piece)
- User Manual (this document)

3. Product Overview

Familiarize yourself with the components of your Philips SPK7405 wireless mouse.



Figure 1: Philips SPK7405 Wireless Optical Mouse. This image displays the top-down view of the black wireless mouse, highlighting its ergonomic design and button layout.

1. Left Click Button
2. Right Click Button
3. Scroll Wheel / Middle Click Button
4. DPI Adjustment Button
5. USB Receiver Storage Slot (underneath the mouse)
6. Battery Compartment (underneath the mouse)
7. Optical Sensor (underneath the mouse)
8. Power ON/OFF Switch (underneath the mouse)

4. Setup

Follow these steps to set up your Philips SPK7405 wireless mouse.

1. **Install the Battery:**
    - Locate the battery compartment cover on the underside of the mouse.
    - Slide or lift the cover to open the compartment.
    - Insert the provided AA battery, ensuring the positive (+) and negative (-) terminals match the indicators inside the compartment.
    - Close the battery compartment cover securely.
2. **Retrieve the USB Receiver:**
    - The USB receiver is typically stored in a dedicated slot next to the battery compartment for safekeeping during transport.
    - Gently pull out the USB receiver.
3. **Connect the USB Receiver:**
    - Plug the USB receiver into an available USB port on your computer (desktop, laptop, etc.).
    - Your computer should automatically detect the device and install the necessary drivers. This may take a few moments.
4. **Power On the Mouse:**
    - Locate the ON/OFF switch on the underside of the mouse.
    - Slide the switch to the "ON" position.
5. **Test the Mouse:**
    - Move the mouse on a flat surface. The cursor on your screen should respond to your movements.
    - Click the left and right buttons, and scroll the wheel to confirm functionality.

If the mouse does not respond, refer to theTroubleshooting section.

5. Operating Instructions

The Philips SPK7405 mouse is designed for intuitive use.

- **Basic Navigation:** Move the mouse on a flat surface to control the cursor on your screen.
- **Left Click:** Press the left button to select items, open links, or activate functions.
- **Right Click:** Press the right button to open context menus or access additional options.
- **Scroll Wheel:** Roll the scroll wheel up or down to navigate through documents and web pages. Press the scroll wheel for middle-click functionality (e.g., opening links in new tabs).
- **DPI Adjustment:** The mouse features adjustable DPI (Dots Per Inch) settings, allowing you to change cursor sensitivity. Press the DPI button (usually located behind the scroll wheel) to cycle between available DPI settings (e.g., 800 DPI and 1600 DPI). A higher DPI setting results in faster cursor movement.

6. Maintenance and Care

Proper care will extend the life of your mouse.

- **Cleaning:** Use a soft, dry cloth to clean the surface of the mouse. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive cleaners.
- **Battery Replacement:** When the mouse performance degrades or stops responding, it's likely time to replace the battery. Follow the battery installation steps in the Setup section. Dispose of used batteries responsibly according to local regulations.

- **Storage:** When not in use for extended periods, turn off the mouse using the ON/OFF switch to conserve battery life. Store the USB receiver in its dedicated slot inside the mouse to prevent loss.
- **Environment:** Avoid exposing the mouse to extreme temperatures, direct sunlight, or excessive moisture.

7. Troubleshooting

If you encounter issues with your Philips SPK7405 mouse, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Mouse not responding / Cursor not moving	◦ Mouse is turned off. ◦ Low or dead battery. ◦ USB receiver not properly connected. ◦ Interference from other wireless devices. ◦ USB port issue.	◦ Ensure the ON/OFF switch is in the "ON" position. ◦ Replace the battery with a new AA battery. ◦ Unplug and re-plug the USB receiver into a different USB port. ◦ Move the mouse closer to the USB receiver. ◦ Try the USB receiver in another computer to rule out a port issue.
Erratic or jumpy cursor movement	◦ Dirty optical sensor. ◦ Mouse used on an unsuitable surface. ◦ Low battery.	◦ Clean the optical sensor with a soft, dry cloth. ◦ Use the mouse on a clean, opaque, non-reflective surface or a mouse pad. ◦ Replace the battery.
Buttons or scroll wheel not working	◦ Software conflict. ◦ Physical obstruction.	◦ Restart your computer. ◦ Ensure no debris is lodged around the buttons or scroll wheel.

8. Specifications

Key technical specifications for the Philips SPK7405 Wireless Optical Mouse.

Feature	Description
Model	SPK7405
Connectivity	2.4GHz Wireless (USB Receiver)
Sensor Technology	Optical
DPI Settings	800-1600 DPI (Adjustable)
Number of Buttons	4 (Left, Right, Scroll Wheel/Middle, DPI)
Power Source	1 x AA Battery
Color	Black
Compatibility	Windows, macOS (standard USB HID device)

9. Warranty and Support

Philips products are designed and manufactured to the highest standards. This product is covered by a limited warranty. For detailed warranty information, please refer to the warranty card included in your product packaging or visit the official Philips website.
For technical support, frequently asked questions, or to register your product, please visit the official Philips support website or contact their customer service.

- **Official Philips Website:** www.philips.com
- **Support Page:** Refer to the website for your regional support contact information.

© 2023 Philips. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09NN4NTT6

More documents and user manuals: **https://manuals.plus/**