Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Metz 32MTC6110Z

Metz MTC6110 Series 32-inch HD LED Smart TV User Manual

Model: 32MTC6110Z

1. Introduction

This manual provides essential information for the safe and efficient operation of your Metz MTC6110 Series 32-inch HD LED Smart TV. Please read this manual thoroughly before using the television and retain it for future reference. Your Metz TV combines advanced display technology with the versatility of Android TV, offering a rich entertainment experience.



Figure 1.1: Front view of the Metz MTC6110 Series 32-inch HD LED Smart TV. This image displays the sleek, borderless design of the television with its stand.

2. Safety Information

To ensure safe operation and prevent damage, please observe the following safety precautions:

- **Power Supply:** Connect the TV only to an AC power outlet with the correct voltage as indicated on the product label. Do not overload power outlets.
- **Ventilation:** Ensure adequate ventilation around the TV. Do not block ventilation openings. Avoid placing the TV on soft surfaces or in enclosed spaces.
- **Water and Moisture:** Do not expose the TV to rain or moisture. Do not place objects filled with liquids, such as vases,

on the TV.

- **Heat Sources:** Keep the TV away from heat sources such as radiators, heat registers, stoves, or other appliances that produce heat.
- **Cleaning:** Unplug the TV from the power outlet before cleaning. Use a soft, dry cloth. Do not use liquid cleaners or aerosol cleaners.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel. Opening covers may expose you to dangerous voltage or other hazards.
- **Children:** Supervise children to ensure they do not play with the TV or its remote control.

3. Package Contents

Please check that all items are included in your TV package:

- Metz MTC6110 Series 32-inch HD LED Smart TV
- Remote Control
- Power Cable
- Side Stands (Feet)
- Batteries for Remote Control
- User Manual (this document)

4. Setup

4.1 Attaching the Stands

Carefully place the TV face down on a soft, flat surface to prevent screen damage. Align the stands with the screw holes on the bottom of the TV and secure them with the provided screws. Ensure the stands are firmly attached before placing the TV upright.

4.2 Connecting External Devices

Your Metz TV offers various connection ports for external devices. Refer to the diagram below for port locations and types.



Figure 4.1: Rear view of the Metz MTC6110 TV showing connectivity ports. This image highlights the 2x USB 2.0 ports, 2x HDMI 1.4 ports, Digital Audio Output, and RJ45 (LAN) port for various connections.

- **HDMI:** Connect Blu-ray players, game consoles, or set-top boxes to the HDMI ports. This TV features 2 HDMI 1.4 ports.
- **USB:** Use the 2 USB 2.0 ports to connect USB storage devices for media playback.
- **Antenna/Cable:** Connect your antenna or cable TV signal to the DVB-C/T2/S2 input.
- **Network (LAN/Wi-Fi):** Connect to your home network via the RJ45 (LAN) port or wirelessly using the built-in Wi-Fi.
- **Digital Audio Output:** For connecting to external audio systems.

4.3 First-Time Setup

After connecting all necessary cables and plugging in the power cord, press the power button on the remote control or the TV. The TV will guide you through the initial setup process, which includes:

1. Language selection.
2. Network connection (Wi-Fi or wired).
3. Google Account sign-in (optional, but recommended for full Android TV features).
4. Channel scanning.

5. Operating Instructions

5.1 Remote Control Functions

The remote control provides access to all TV functions. Familiarize yourself with the button layout and their respective actions.



Figure 5.1: The remote control for the Metz MTC6110 TV. Key buttons include Power, Number buttons, Info, Source, Navigation (OK, Home, Back, Menu, Exit), Volume, Channel, and dedicated shortcut buttons for Netflix, YouTube, Prime Video, and Google Play.

- **Power Button:** Turns the TV on or off.
- **Number Buttons (0-9):** Select channels directly.
- **INFO:** Displays current program information.
- **SOURCE:** Selects input source (HDMI, USB, TV).

- **Navigation Buttons (Up/Down/Left/Right, OK):** Navigate menus and confirm selections.
- **HOME:** Accesses the Android TV home screen.
- **BACK:** Returns to the previous screen.
- **MENU:** Opens the TV settings menu.
- **EXIT:** Exits the current menu or application.
- **VOL +/-:** Adjusts volume.
- **CH +/-:** Changes channels.
- **Dedicated App Buttons:** Quick access to Netflix, YouTube, Prime Video, and Google Play.

5.2 Android TV Features

Your Metz TV runs on Android TV, providing access to a vast array of content and smart features.



Figure 5.2: The Android TV home screen displaying various streaming apps and content recommendations. This interface allows users to easily navigate and access a wide range of entertainment options.

- **Google Play Store:** Download thousands of apps, games, movies, and TV shows.
- **Chromecast Built-in:** Cast content from your smartphone, tablet, or computer directly to your TV.
- **Google Assistant:** Use voice commands via the remote control to search for content, control smart home devices, and get information.



Figure 5.3: Illustration of the Chromecast built-in feature. This image shows a smartphone casting content to the TV, enabling seamless sharing of media from mobile devices.

5.3 Picture and Sound Settings

Optimize your viewing and listening experience through the TV's settings menu.

- **Picture Modes:** Select from various preset picture modes (e.g., Standard, Vivid, Movie, Sport, Game) or customize settings like brightness, contrast, and color. The TV features **Trochilus Extreme™ 2.0** for enhanced picture quality.
- **Sound Modes:** Adjust audio settings with modes like Standard, Music, Movie, or customize equalizer settings. The TV supports **Dolby Audio** for immersive sound.



Figure 5.4: A visual comparison demonstrating the effect of Trochilus Extreme™ 2.0. The image shows a split screen, with one side labeled 'Ordinary' and the other 'Trochilus Extreme™ 2.0', highlighting the enhanced detail and vibrancy provided by the technology.



Figure 5.5: An illustration of the Dolby Audio experience. The image depicts a couple relaxing on a sofa, with sound waves emanating from the TV, symbolizing the immersive audio quality provided by Dolby Audio technology.

5.4 Special Modes

The TV includes optimized modes for specific content types:

- **Game Mode:** Reduces input lag for a more responsive gaming experience.
- **Sport Mode:** Enhances motion clarity and color vibrancy for sports broadcasts.



Figure 5.6: An image illustrating the Game Mode. It shows a fast-moving car on the TV screen with a person holding a game controller, emphasizing the TV's optimization for gaming.



Figure 5.7: An image depicting the Sport Mode. It shows a surfer on a wave, with visual effects suggesting enhanced motion and clarity, indicating the TV's optimization for sports viewing.

6. Maintenance

Proper maintenance ensures the longevity and performance of your TV.

- **Screen Cleaning:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a specialized screen cleaner. Never spray liquid directly onto the screen.
- **TV Body Cleaning:** Use a soft, dry cloth to wipe the TV's frame and back panel. Avoid abrasive cleaners or solvents.
- **Dust Removal:** Regularly dust the ventilation openings to prevent overheating.

7. Troubleshooting

If you encounter issues with your TV, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No Power	Power cord disconnected; Power outlet issue.	Ensure power cord is securely plugged in. Test the outlet with another device.
No Picture, but Sound is Present	Incorrect input source selected; External device issue.	Press the SOURCE button on the remote to select the correct input. Check the external device's connection and power.

Problem	Possible Cause	Solution
No Sound, but Picture is Present	Volume muted or too low; External audio system issue.	Increase volume. Check if mute is active. If using external audio, ensure it's powered on and correctly connected.
Wi-Fi Connection Issues	Incorrect password; Router issue; Signal interference.	Re-enter Wi-Fi password. Restart your router. Move TV closer to router or reduce interference.
Remote Control Not Working	Dead batteries; Obstruction; Incorrect pairing.	Replace batteries. Remove any obstructions between remote and TV. Re-pair if it's a Bluetooth remote.

If the problem persists after trying these solutions, please contact Metz customer support or a qualified service technician.

8. Specifications

Detailed technical specifications for the Metz MTC6110 Series 32-inch HD LED Smart TV:



Figure 8.1: Dimensional drawing of the Metz MTC6110 TV. This image provides precise measurements for the TV's width (719.4mm), height (475.6mm), and depth (189.6mm with stand), useful for installation planning.

- **Model Number:** 32MTC6110Z
- **Brand:** Metz
- **Screen Size:** 32 Inches (81 cm)
- **Display Technology:** LED
- **Resolution:** 720p (HD)
- **Refresh Rate:** 60 Hz
- **Operating System:** Android TV
- **Connectivity:**

- 2 x HDMI 1.4 ports
- 2 x USB 2.0 ports
- Wi-Fi (BT, Wi-Fi)
- RJ45 (LAN)
- Digital Audio Output

- **Special Features:** Smart / Internet, Chromecast Built-in, Google Assistant, Trochilus Extreme™ 2.0, Dolby Audio, Borderless Screen 4.0
- **Aspect Ratio:** 16:9
- **Product Dimensions (with stand):** 8.5D x 72W x 43H centimeters (approx. 71.94W x 47.56H x 18.96D cm)
- **Color:** Grey

9. Warranty and Support

For warranty information, please refer to the warranty card included with your product or consult the retailer from whom you purchased the TV. Metz provides quality products and support.
For further assistance or technical support, please visit the official Metz website or contact their customer service department. Information regarding spare parts availability and software updates is not explicitly provided in the product details and should be inquired directly with the manufacturer or retailer.

© 2024 Metz. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09NQJW7JD

More documents and user manuals: **https://manuals.plus/**