Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Minolta MN220NV

Minolta MN220NV Camcorder User Manual

Model: MN220NV

Introduction

The Minolta MN220NV is a versatile camcorder designed for capturing high-quality video and still images. It features 1080p Full HD video recording, 24-megapixel photo capabilities, and an advanced infrared sensor for night vision. With a 16x digital zoom, anti-shake stabilization, and a 3.0-inch IPS high-resolution display, this camcorder is suitable for various recording environments. Integrated Wi-Fi allows for seamless connectivity with your smartphone for easy file transfer and remote control.



Image: The Minolta MN220NV camcorder, showcasing its compact design and the infrared light for night vision.

Safety Information

- **Battery Safety:** Use only the specified battery type. Do not expose batteries to excessive heat or direct sunlight. Do not disassemble, crush, or puncture the battery. Dispose of batteries properly according to local regulations.
- **Water and Moisture:** This camcorder is not waterproof. Do not expose it to rain, moisture, or immerse it in water.
- **Temperature:** Operate and store the camcorder within recommended temperature ranges (typically 0°C to 40°C / 32°F to

104°F). Avoid extreme cold or heat.

- **Cleaning:** Disconnect power before cleaning. Use a soft, dry cloth. Do not use liquid cleaners or solvents.
- **Handling:** Avoid dropping the camcorder or subjecting it to strong impacts.
- **Night Vision:** The infrared illuminator emits light that is not visible to the human eye but can be detected by the camera. Avoid pointing the infrared light directly into eyes at close range.

Package Contents

Verify that all items listed below are included in your package:

- Minolta MN220NV Camcorder
- USB Cable
- HDMI Cable
- AC Adaptor
- Camera Pouch
- Lithium-Ion Battery
- 32GB Memory Card
- MiMedia Basic 1 Year Service (Digital)
- Kioza Starter Premium Membership (Digital)
- Take Control of Your Digital Legacy eBook (Digital)

Product Overview

Familiarize yourself with the various parts and controls of your Minolta MN220NV camcorder.



Image: Front view of the camcorder, showing the lens and infrared illuminator.



Image: Rear view of the camcorder with the 3.0-inch IPS LCD screen open, displaying controls and ports.

Key Components:

- **Lens:** Captures video and still images.
- **Infrared Illuminator:** Provides illumination for night vision recording.
- **3.0" IPS LCD Screen:** Rotatable display for viewing and menu navigation.
- **Power/IR Button:** Turns the camcorder on/off and activates infrared night vision.
- **Mode Button:** Switches between video, photo, and playback modes.
- **Menu/WiFi Button:** Accesses the menu system and Wi-Fi settings.
- **REC/STOP Button:** Starts and stops video recording.
- **Zoom Lever:** Controls the 16x digital zoom (Tele/Wide).
- **Navigation Buttons (Up/Down/Left/Right/OK):** For menu navigation and selection.
- **USB Port:** For connecting to a computer.
- **HDMI Port:** For connecting to an HDTV or monitor.
- **SD Card Slot:** For inserting the memory card.
- **Battery Compartment:** Houses the Lithium-Ion battery.

Setup

1. Battery Installation and Charging

1. Open the battery compartment cover on the bottom of the camcorder.
2. Insert the provided Lithium-Ion battery, ensuring the contacts align correctly. Close the cover.
3. Connect the AC adaptor to the camcorder's charging port and plug it into a power outlet. The charging indicator will illuminate.
4. Charge the battery fully before first use (approximately 2-3 hours). The indicator will change or turn off when charging is complete.

2. Memory Card Installation

The camcorder supports SD cards up to 32GB. A 32GB SD card is included.

1. Locate the SD card slot, typically on the side or bottom of the camcorder.
2. Insert the SD card with the metal contacts facing the correct direction (refer to the diagram near the slot). Push until it clicks into place.
3. To remove, gently push the card in again until it springs out.

3. Initial Power On and Settings

1. Open the LCD screen. This often automatically powers on the camcorder. Alternatively, press and hold the **Power/IR** button.
2. Upon first power-on, you may be prompted to set the date and time. Use the navigation buttons to adjust and the **OK** button to confirm.
3. It is recommended to format the SD card within the camcorder before first use to ensure compatibility and optimal performance. Navigate to the menu, find "Format SD Card," and confirm.

Operating Instructions

1. Recording Video

1. Ensure the camcorder is powered on and in video recording mode (indicated by an icon on the screen, usually a camera with a red dot). If not, press the **Mode** button to switch.
2. Frame your shot using the LCD screen.
3. Press the **REC/STOP** button to begin recording. A red recording indicator will appear on the screen.
4. To stop recording, press the **REC/STOP** button again.



Image: The camcorder's LCD screen displaying a live view, ready for recording.

2. Taking Photos

1. Press the **Mode** button until the camcorder is in photo mode (indicated by a camera icon).
2. Frame your shot.
3. Press the **REC/STOP** button (or a dedicated photo button if available) to capture a still image.

3. Night Vision Mode

The MN220NV features an infrared sensor illuminator for recording in low-light or no-light conditions.

1. In video or photo mode, briefly press the **Power/IR** button.
2. The screen will switch to a black and white display, indicating that night vision is active. The infrared illuminator will emit a red light (visible to the camera, sometimes faintly to the eye).
3. To deactivate night vision, press the **Power/IR** button again.



Image: The camcorder's LCD screen displaying a scene captured using infrared night vision, appearing in monochrome.



Image: Illustrates the camcorder's night vision capability in a dark outdoor setting, showing tents and camping chairs.

4. Using the Zoom Function

The camcorder features a 16x digital zoom.

- While in video or photo mode, push the zoom lever towards **T (Tele)** to zoom in on your subject.
- Push the zoom lever towards **W (Wide)** to zoom out.



Image: Visual representation of the digital zoom feature, highlighting how it magnifies a distant subject like a deer in a field.

5. Playback

1. Press the **Mode** button to switch to playback mode (indicated by a play icon).
2. Use the navigation buttons to scroll through your recorded videos and photos.
3. Press the **OK** button to play a selected video or view a photo.

6. Connecting to a Computer (USB)

1. Ensure the camcorder is powered off.
2. Connect the camcorder to your computer using the supplied USB cable.
3. Power on the camcorder. It should appear as a removable disk drive on your computer.
4. You can now transfer video (MOV format) and photo files from the camcorder's SD card to your computer.

7. Wi-Fi Connectivity

The camcorder's Wi-Fi feature allows for remote control and file transfer via a smartphone application.

1. Download the compatible smartphone application (refer to the camcorder's on-screen instructions or included documentation for the app name).
2. On the camcorder, press and hold the **Menu/WiFi** button to activate Wi-Fi mode. The camcorder will broadcast its own Wi-Fi network.
3. On your smartphone, go to Wi-Fi settings and connect to the camcorder's network (SSID and password will be displayed on the camcorder screen).
4. Open the smartphone application to control the camcorder remotely, view live footage, and transfer files.



Image: The camcorder illustrating its Wi-Fi connectivity feature, enabling wireless control and data transfer.

Maintenance

- **Cleaning the Lens:** Use a soft, lint-free cloth specifically designed for camera lenses. Do not use abrasive materials or harsh chemicals.
- **Cleaning the Body:** Wipe the camcorder body with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water, then wipe dry.
- **Battery Care:** Store batteries in a cool, dry place. If not using the camcorder for an extended period, remove the battery. Recharge the battery periodically if stored for long durations to maintain its life.

- **Storage:** Store the camcorder in a cool, dry, dust-free environment, away from direct sunlight and extreme temperatures. Use the provided camera pouch for protection.

Troubleshooting

Problem	Possible Cause	Solution
Camcorder does not power on.	Battery is depleted or not inserted correctly.	Charge the battery fully. Ensure the battery is inserted with correct polarity.
Cannot record video/take photos.	SD card is full, not inserted, or corrupted. Incorrect mode selected.	Check SD card capacity. Insert or reinsert SD card. Format SD card (will erase data). Switch to correct recording mode.
Poor image/video quality.	Lens is dirty. Insufficient lighting. Digital zoom used excessively.	Clean the lens. Ensure adequate lighting or use night vision. Avoid excessive digital zoom.
Night vision not working.	Night vision mode not activated.	Press the **Power/IR** button to activate night vision.
Wi-Fi connection issues.	Incorrect app. Incorrect password. Distance too far.	Ensure correct app is installed. Verify Wi-Fi password. Move closer to the camcorder.
Audio quality is poor.	Microphone is obstructed. Recording in noisy environment.	Ensure microphone is clear. Record in quieter environments.

Specifications

Feature	Detail
Model Number	MN220NV
Video Resolution	1080p Full HD
Still Image Resolution	24 Megapixels
Display	3.0 inch 262k IPS LCD screen
Zoom	16x Digital Zoom
Night Vision	Infrared Sensor Illuminator
Stabilization	Anti-Shake
Storage Media	SD cards up to 32 GB
Connectivity	HDMI, USB, Wi-Fi
Battery Type	Lithium Ion (included)
Product Dimensions	9 x 6 x 4 inches
Item Weight	1.6 pounds

Feature	Detail
Video Capture Format	MOV
Photo Sensor Technology	CMOS




Image: Illustrates the difference in clarity and detail between 480p, 720p, and 1080p video resolutions, highlighting the Full HD capability of the MN220NV.

Warranty and Support

Minolta products are manufactured with high-quality standards. For warranty information and customer support, please refer to the warranty card included in your product packaging or visit the official Minolta website. Keep your proof of purchase for warranty claims.

For technical assistance or troubleshooting beyond this manual, please contact Minolta customer support.

Visit the Minolta Store: Minolta Official Store

© 2024 Minolta. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09NZ528J6

More documents and user manuals: **https://manuals.plus/**