Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TRESKO B09PBT84K4

TRESKO 1200W Infrared Heater with Remote Control User Manual

Model: B09PBT84K4

1. Introduction and Product Overview

Thank you for choosing the TRESKO 1200W Infrared Heater. This manual provides essential information for the safe and efficient operation of your new heater. Please read it thoroughly before installation and use, and keep it for future reference.

The TRESKO Infrared Heater features Instant-Heat technology and a carbon tube, providing optimal warmth within seconds. Its reflector design ensures targeted heat distribution. With an IP34 protection rating, this heater is suitable for both indoor and outdoor use, offering water resistance, corrosion resistance, and a durable powder coating. It operates silently and offers two power levels (800W and 1200W) controllable via a remote.



Image 1.1: TRESKO Infrared Heater showcasing its modern design and key features.

2. Safety Instructions

WARNING: Failure to follow these safety instructions may result in fire, electric shock, injury, or property damage.

- Read all instructions before using this heater.
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 1 meter (3 feet) from the front of the heater and keep them away from the sides and rear.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Always unplug the heater when not in use.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped, or damaged in any manner. Return heater to authorized service facility for examination, electrical or mechanical adjustment, or repair.
- Do not use outdoors in heavy rain or extreme weather conditions beyond its IP34 rating.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- To disconnect heater, turn controls to off, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.

- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- Ensure the power supply voltage matches the rating label on the heater.

3. Package Contents

Carefully unpack your TRESKO Infrared Heater and check that all items are present and in good condition. If any items are missing or damaged, please contact your retailer.

- TRESKO 1200W Infrared Heater (Black)
- Remote Control
- Stainless Steel Mounting Chain
- Carabiner Hooks (2x)
- User Manual (this document)



Image 3.1: Main components of the TRESKO Infrared Heater package.

4. Product Components and Controls

Familiarize yourself with the parts of your TRESKO Infrared Heater:

1. **Heating Element:** Carbon tube for efficient infrared heat.
2. **Protective Grille:** Stainless steel grille covering the heating element.
3. **Housing:** Durable aluminum body with powder coating.
4. **Power Button:** Manual on/off switch located on the unit.
5. **Remote Control Receiver:** Sensor for remote commands.
6. **Mounting Point:** Top of the unit for attaching the chain.

Remote Control Functions:

- **Power Button ( ):** Turns the heater on or off.

- **800W Button:** Selects the lower heat setting.
- **1200W Button:** Selects the higher heat setting.



Image 4.1: TRESKO Infrared Heater with remote control detailing its functions.

5. Setup and Installation

The TRESKO Infrared Heater is designed for ceiling mounting. Ensure the mounting surface is sturdy and can safely support the weight of the heater.

1. **Choose Location:** Select a suitable location for ceiling mounting, ensuring adequate clearance from walls, ceilings, and any combustible materials (minimum 1 meter / 3 feet). The heater should be positioned to provide optimal heat distribution to the desired area.
2. **Secure Mounting Point:** Install a robust hook or bracket into the ceiling that can safely hold the heater's weight. Ensure it is securely fastened to a structural beam or joist.
3. **Attach Chain:** Connect one end of the provided stainless steel chain to the mounting point on top of the heater.

4. **Hang Heater:** Use the carabiner hooks to attach the other end of the chain to the securely installed ceiling hook/bracket. Ensure the heater hangs level and is stable.
5. **Power Connection:** Plug the heater's power cord into a suitable 220V electrical outlet. Ensure the outlet is easily accessible and not overloaded.



Image 5.1: Example of the TRESKO Infrared Heater installed on a patio ceiling.

6. Operating Instructions

Once the heater is securely installed and plugged in, you can begin operation.

1. **Power On:** Press the Power button ( ) on the remote control or the manual power button on the unit. The heater will typically start at a default setting or the last used setting.
2. **Select Heat Level:** Use the '800W' or '1200W' buttons on the remote control to select your desired heat output. The heater will quickly reach the selected temperature.
3. **Power Off:** Press the Power button ( ) on the remote control or the manual power button on the unit to turn off the

heater. Always unplug the heater from the power outlet when not in use for extended periods.

7. Maintenance

Regular maintenance ensures the longevity and efficient operation of your TRESKO Infrared Heater.

- **Cleaning:** Before cleaning, always ensure the heater is turned off, unplugged, and completely cool. Use a soft, damp cloth to wipe down the exterior surfaces. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.
- **Protective Grille:** Periodically check the protective grille for any dust or debris accumulation. Gently clean with a soft brush or vacuum cleaner.
- **Storage:** If storing the heater for an extended period, ensure it is clean and dry. Store it in a cool, dry place, preferably in its original packaging, to protect it from dust and damage.
- **No User-Serviceable Parts:** The heating element and internal components are not user-serviceable. Do not attempt to open or repair the heater yourself. Contact qualified personnel for any repairs.

8. Troubleshooting

If you encounter issues with your TRESKO Infrared Heater, refer to the following troubleshooting guide:

Problem	Possible Cause	Solution
Heater does not turn on.	No power supply. Remote control battery is dead. Heater is switched off at the main power button.	Check if the power cord is securely plugged into a working outlet. Replace the remote control battery. Ensure the manual power button on the unit is in the 'ON' position.
Insufficient heat output.	Incorrect power setting. Room/area is too large for the heater. Heater is too far from the target area.	Ensure the 1200W setting is selected for maximum heat. Consider using additional heating for very large spaces. Adjust the heater's position to be closer to the area requiring heat.
Unusual noise or smell.	New unit smell (normal for first use). Foreign object inside. Internal malfunction.	The initial smell should dissipate after a few uses. Ensure good ventilation. Immediately unplug the heater. Do not attempt to remove the object. Contact customer support. Immediately unplug the heater and contact customer support. Do not attempt repairs.

9. Specifications

Detailed technical specifications for the TRESKO 1200W Infrared Heater:

Feature	Specification
Brand	TRESKO

Feature	Specification
Model	B09PBT84K4
Power Output	800W / 1200W (2 settings)
Voltage	220 Volt
Heating Element Type	Infrared (Carbon Tube)
Protection Class	IP34 (Water-resistant)
Mounting Type	Ceiling Mount
Color	Black
Dimensions (Approx.)	Height: 25 cm (9.8 inches) Diameter: 43 cm (16.9 inches) Total Length (with chain): 56 cm (22 inches)
Cable Length	1.55 meters (approx. 5.1 feet)
Weight	1 Kilogram (approx. 2.2 lbs)
Manufacturer	DWD-Company GmbH & Co. KG



Image 9.1: Dimensions of the TRESKO Infrared Heater.

10. Warranty and Support

For warranty information, technical support, or service inquiries, please contact the retailer or manufacturer directly. Keep your proof of purchase for any warranty claims.

© 2023 TRESKO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the

question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Is it possible to link the TRESKO 1200W Infrared Heater to my room's light switch so that the heater turns on automatically when I turn on the light?

Based on the manual for the TRESKO 1200W Infrared Heater (Model B09PBT84K4), linking the heater directly to a light switch is not recommended and may be unsafe for the following reasons: Power Requirements: The...

Read full answer

Open the live page

https://manuals.plus/asin/B09PBT84K4

More documents and user manuals: **https://manuals.plus/**