Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LUXPRO LP1530

LUXPRO LP1530 Rechargeable Bluetooth Speaker Lantern User Manual

Introduction

Thank you for choosing the LUXPRO LP1530 Rechargeable Bluetooth Speaker Lantern. This versatile device combines a powerful LED lantern, a Bluetooth speaker, and a portable power bank for charging your devices. Designed for durability and convenience, it is an ideal companion for outdoor activities, emergencies, or everyday use. Please read this manual carefully to ensure proper operation and to maximize the lifespan of your product.





Image: The LUXPRO LP1530 lantern, showcasing its compact design with a clear light housing and a speaker base.

Safety Information

- Do not expose the device to extreme temperatures or direct sunlight for extended periods.
- Keep the device away from water and moisture, unless specified as water-resistant.
- Do not attempt to disassemble or modify the device. This will void the warranty and may cause damage.
- Use only the provided charging cable or a certified equivalent.
- Keep out of reach of children.

Package Contents

Please check the package for the following items:

- LUXPRO LP1530 Rechargeable Bluetooth Speaker Lantern
- USB Charging Cable
- 2 Lithium-Ion Batteries (pre-installed)

Product Overview

The LP1530 features a robust design integrating multiple functionalities:

- **LED Lantern:** Provides bright, adjustable illumination.

- **Bluetooth Speaker:** Connects wirelessly to your devices for audio playback.
- **USB Charging Port:** Allows you to charge external devices like smartphones.
- **Control Dial/Buttons:** Located on the top for light and speaker control.
- **Integrated Handle:** For easy carrying or hanging.



Image: The LUXPRO LP1530 lantern next to a smartphone, illustrating its dual function as a lantern and a Bluetooth speaker.

Setup

Initial Charging

1. Locate the USB charging port on the lantern.
2. Connect the provided USB charging cable to the lantern's charging port.
3. Plug the other end of the USB cable into a compatible USB power source (e.g., wall adapter, computer USB port).
4. The charging indicator light will illuminate. Ensure the device is fully charged before first use. The indicator light will turn green when charging is complete.



Image: Close-up of the LUXPRO LP1530 lantern showing the USB-C charging port and a USB-C cable, indicating its device charging capability.

Operating Instructions

Lantern Operation

1. **Power On/Off:** Press and hold the power button (usually located on the top) to turn the lantern on or off.
2. **Adjust Brightness:** Rotate the variable mode dial to adjust the light output from low to high. The lantern offers a maximum brightness of 572 lumens.



Image: The LUXPRO LP1530 lantern with text overlay indicating "ULTRA BRIGHT 572 Lumens on high", highlighting its powerful illumination.



Image: The LUXPRO LP1530 lantern in use outdoors at dusk, with text overlay indicating "Extended Run Time 29 Hour run time on low mode", demonstrating its long-lasting battery.

Bluetooth Speaker Operation

1. **Pairing:** With the lantern powered on, activate Bluetooth on your smartphone or other audio device. Search for "LUXPRO LP1530" (or similar) in the list of available devices and select it to pair.
2. **Audio Playback:** Once paired, audio from your device will play through the lantern's speaker.
3. **Volume Control:** Adjust the volume using the controls on your connected device or the dedicated volume controls on top of the lantern.

Device Charging Port Usage

1. Connect your smartphone or other portable device to the USB output port on the lantern using your device's charging cable.
2. The lantern will begin charging your device. Note that using the charging port may reduce the lantern's battery life for light and speaker functions.

Maintenance

- **Cleaning:** Wipe the lantern with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the lantern in a cool, dry place when not in use. If storing for an extended period, ensure the battery is partially charged (around 50%) to maintain battery health.
- **Battery Care:** Recharge the lantern regularly, even if not in frequent use, to prevent deep discharge and prolong battery life.

Troubleshooting

Problem	Possible Cause	Solution
Lantern does not turn on.	Battery is depleted.	Charge the lantern fully.
Lantern does not recharge.	Faulty charging cable or power source.	Try a different USB charging cable and a different power source. Ensure the cable is securely connected.
Bluetooth speaker is too quiet.	Volume settings are low.	Increase the volume on both the connected device and the lantern's controls.
Cannot pair Bluetooth speaker.	Device is not in pairing mode or already connected to another device.	Ensure the lantern is discoverable. Disconnect from other devices if necessary. Restart both the lantern and your audio device.
External device not charging.	Lantern battery low or incorrect cable.	Ensure the lantern is sufficiently charged. Use a functional charging cable for your external device.

Specifications



Image: Infographic summarizing key specifications for the LUXPRO LP1530, including brightness (572 lumens high, 37 lumens low), run time (3h 45m high, 29h 45m low), beam distance (25m high, 6m low), shockproof (1m), and weatherproof (IPX4).

Feature	Detail
Model Number	LP1530
Product Dimensions	4.25"L x 4.25"W x 6.5"H
Item Weight	1.2 Pounds
Brightness	Up to 572 Lumens
Battery Type	2 Lithium-Ion (included)
Battery Life	Up to 29.75 Hours (on low mode)
Voltage	3.7 Volts
Light Source	LED (Light Emitting Diode)

Feature	Detail
Water Resistance Level	Water Resistant (IPX4)
Material	Plastic
UPC	812436010252

Warranty and Support

For warranty information or technical support, please refer to the manufacturer's official website or contact LUXPRO customer service directly. Keep your purchase receipt as proof of purchase.
Manufacturer: LUXPRO

© 2023 LUXPRO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09RLXNCXV

More documents and user manuals: **https://manuals.plus/**