Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Fisher-Price Y9854

Fisher-Price Y9854 Musical Lion Walker Instruction Manual

Model: Y9854

1. Introduction

Thank you for choosing the Fisher-Price Y9854 Musical Lion Walker. This product is designed to support your child's development through two modes of play: sit-and-play and stand-and-walk. It features engaging activities, lights, and music to stimulate sensory development and encourage motor skills.

Please read this instruction manual thoroughly before assembly and use to ensure safe and proper operation. Keep this manual for future reference.

2. Safety Information

- **Adult supervision is required at all times.** Never leave a child unattended with the walker.
- Ensure all parts are securely assembled before each use.
- Do not use the walker on uneven surfaces, near stairs, or in areas with potential hazards.
- This product is intended for children who can sit unassisted and are learning to walk.
- Regularly inspect the product for damage or loose parts. Discontinue use if any damage is found.
- Keep small parts and packaging materials away from children to prevent choking hazards.
- Batteries should be installed and replaced by an adult. Follow battery safety guidelines.

3. Assembly Instructions

Assembly requires a Phillips head screwdriver (not included).

1. Unpack all components and verify against the parts list (refer to packaging for detailed list).
2. Attach the handle to the main lion body. Ensure it clicks securely into place.
3. Insert the wheels into their designated slots on the base of the walker. Press firmly until they lock.
4. **Battery Installation:** Locate the battery compartment on the underside of the lion's head. Unscrew the cover, insert 3 AA batteries (not included) observing polarity (+/-), then replace the cover and screw it shut.
5. Before first use, check all connections to ensure they are firm and secure.



Image 1: The Fisher-Price Musical Lion Walker in its sit-and-play configuration, with a baby interacting with the front panel. This image illustrates the product's primary appearance and initial play mode.

4. Operating Instructions

4.1. Sit-and-Play Mode

In this mode, the walker's handle is folded down or not yet attached, allowing the child to sit on the floor and interact with the activity panel. The panel features various elements:

- **Light-up Nose:** Press the lion's nose for lights and sounds.
- **Musical Keys:** Press the colorful keys to activate different melodies and sounds.
- **Spinning Dial:** Turn the dial for clicking sounds and visual engagement.
- **Flip-up Mirror:** Discover reflections and peek-a-boo play.
- **Movable Butterfly:** Slide the butterfly for tactile stimulation.



Image 2: A baby sitting and engaging with the interactive front panel of the lion walker, highlighting the various buttons, spinners, and a mirror for sensory play.

4.2. Stand-and-Walk Mode

Once your child is ready to stand and take their first steps, the walker can be used as a push-along aid. Ensure the handle is securely attached and upright.

- Encourage your child to grasp the handle and push the lion forward.
- The walker provides stability and support as your child practices walking.
- Sounds and music activate as the walker is pushed, providing auditory feedback and encouragement.



Image 3: A toddler standing and pushing the Fisher-Price Musical Lion Walker across a wooden floor, demonstrating its use as a walking aid.

5. Maintenance and Care

- **Cleaning:** Wipe the walker with a damp cloth and mild soap. Do not immerse in water. Do not use abrasive cleaners or solvents.
- **Storage:** Store the walker in a clean, dry place away from direct sunlight and extreme temperatures.
- **Battery Replacement:** When sounds or lights become faint or stop working, replace the batteries. Always use 3 new AA alkaline batteries. Do not mix old and new batteries, or different types of batteries. Dispose of used batteries responsibly.

6. Troubleshooting

Problem	Possible Cause	Solution
No sound or lights	Batteries are dead or incorrectly installed.	Replace batteries with new AA alkaline batteries, ensuring correct polarity.
Sounds are faint or distorted	Low battery power.	Replace batteries.
Walker feels unstable	Parts not securely assembled.	Recheck all connections, especially the handle and wheels, to ensure they are locked in place.

7. Specifications

Model Number: Y9854

Brand: Fisher-Price

Material: Plastic

Product Dimensions: Approximately 51 x 37 x 50 cm (L x W x H)

Item Weight: 2.16 kg

Batteries Required: 3 x AA (Alkaline recommended)

Age Range: 6 months and up



Image 4: The Fisher-Price Musical Lion Walker shown with its approximate dimensions (height 60 cm / 23.4 in, width 42 cm / 16.4 in) for reference.

8. Warranty and Support

For warranty information or customer support, please refer to the contact details provided on the product packaging or

visit the official Fisher-Price website. Keep your purchase receipt as proof of purchase.

Fisher-Price is committed to providing quality products. If you encounter any issues not covered in this manual, please contact customer service for assistance.

© 2024 Fisher-Price. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09V15RKR2

More documents and user manuals: **https://manuals.plus/**