Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Edillas 8206B

Edillas Kids Digital Watch User Manual

Model: 8206B

1. Product Overview

The Edillas Kids Digital Watch is designed for children aged 4-12, offering a range of useful functions including an alarm clock, stopwatch, calendar, and colorful LED lights. It features a durable, waterproof design suitable for daily activities.



Image: Front view of the Edillas Kids Digital Watch, highlighting its water-resistant design.

Key Features:

- Multifunctional: Alarm, Stopwatch, Calendar, 12H/24H display.

- 7-Color LED Backlight: Blue, green, red, light blue, yellow, purple, white, with monochrome and colorful flashing options.
- 30M/3 ATM Water Resistance: Suitable for hand washing, rain, splashes, and swimming (avoid pressing buttons underwater).
- Durable Construction: High-transparency resin glass, fine metal steel case, stainless steel case back, and soft TPU strap.
- Japan Imported Movement and Battery: Ensures accurate timekeeping and long battery life.



Image: Overview of the watch's main functions, including stopwatch, alarm, calendar, and water resistance.

2. Setup

Initial Setup:

Upon receiving your watch, ensure any protective films are removed from the screen and case back. The watch comes

with a pre-installed battery. If the display is not active, check for a small plastic tab near the crown or buttons that may need to be removed to activate the battery.

Wearing the Watch:

The Edillas Kids Digital Watch features a soft and flexible TPU strap designed for comfort. Adjust the buckle to ensure a snug yet comfortable fit on the wrist. The strap is designed to maintain good elasticity and flexibility for active children.

▶ **Watch video online**

Wear Comfortable kids watch

Video: This short video demonstrates how to comfortably wear and adjust the Edillas Kids Digital Watch on a wrist, showcasing the flexibility of the strap.

3. Operating Instructions

Familiarize yourself with the watch buttons:



Image: Labeled diagram of the watch buttons for easy identification.

- **LIGHT Button:** Activates the backlight.
- **MODE Button:** Cycles through different modes (Time, Alarm, Stopwatch).
- **START Button:** Used to start/stop functions in Stopwatch mode, or adjust settings.
- **RESET Button:** Used to reset functions in Stopwatch mode, or adjust settings.

Setting Time and Date:

1. From the Time Display Mode, press the**MODE** button repeatedly until the time setting flashes (usually seconds).
2. Use the **START** button to adjust the flashing value (e.g., hours, minutes).
3. Press the **RESET** button to move to the next setting (e.g., from hours to minutes, then date, month, day of week).
4. Repeat steps 2 and 3 until all desired settings are adjusted.
5. Press the **MODE** button to exit setting mode.



Image: The watch's calendar function helps children keep track of the day and date.

Using the LED Backlight:

Press the **LIGHT** button to illuminate the dial. The watch supports 7 different colors (blue, green, red, light blue, yellow, purple, white) and can switch between monochrome and colorful flashing modes. This feature is particularly useful in low-light conditions and adds a fun element for children.



Image: Demonstration of the watch's luminous display with various color options.

Using the Stopwatch:

1. Press the **MODE** button until 'ST' or 'STOPWATCH' appears on the display.
2. Press the **START** button to begin timing.
3. Press the **START** button again to pause timing.
4. Press the **RESET** button to clear the stopwatch to zero.



Image: The stopwatch function is ideal for sports and timing activities.

Setting and Using the Alarm:

1. Press the **MODE** button until 'AL' or 'ALARM' appears on the display.
2. Press the **START** button to adjust the alarm hour.
3. Press the **RESET** button to move to the alarm minute setting.
4. Press the **START** button to adjust the alarm minute.
5. Press the **MODE** button to exit alarm setting mode.
6. To turn the alarm on or off, from the alarm display mode, press the **START** button. An alarm icon will appear/disappear to indicate its status.



Image: The alarm function helps children wake up or remember important times.

Water Resistance:

The watch is 30M/3 ATM water resistant, meaning it can withstand splashes, rain, hand washing, and brief immersion in cold water. **Important: Do not press any buttons while the watch is submerged in water, as this can compromise the water seal.**



Image: The watch is designed to be water resistant for everyday activities, but avoid pressing buttons underwater.

4. Maintenance

Cleaning:

If the watch becomes dirty, it can be rinsed directly with cold water. For stubborn dirt, use a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the watch's materials.

Battery:

The watch uses a Japan imported battery designed for long life. If the display becomes dim or the watch stops functioning, the battery may need replacement. While the battery is long-lasting, professional replacement is recommended to maintain water resistance.



Image: The watch's construction features a durable case back and comfortable strap for long-term use.

5. Troubleshooting

Hourly Chime:

If your digital watch is chiming every hour and you wish to turn it off or on:

- From the Time Display Mode, press the**RESET** button and the **MODE** button simultaneously (R+M).
- Repeat the action to toggle the hourly chime on or off.

General Issues:

If you encounter any other issues with the watch's functionality, such as display problems or button unresponsiveness, please refer to the support section for assistance.

6. Specifications

Feature	Detail
Model Number	8206B
Product Dimensions	2.95 x 2.95 x 0.07 inches
Item Weight	0.8 ounces
Water Resistance	30M / 3 ATM
Clasp Type	Buckle
Battery	1 C battery (included)
Department	Girls
Manufacturer	Yadelai



Image: Detailed dimensions and material breakdown of the watch components.

7. Warranty and Support

Warranty:

Edillas provides support for issues related to the watch's battery and movement. If you experience problems with these components, please contact customer service for assistance with replacement.

Customer Support:

For further assistance, questions, or troubleshooting not covered in this manual, please contact Edillas customer support. You may also find additional information in the official User Manual (PDF).

© 2024 Edillas. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09V7PDMHZ

More documents and user manuals: **https://manuals.plus/**