Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEXiBOOK RC18

LEXiBOOK RC18 Crosslander Radio Road Motorcycle Instruction Manual

Model: RC18 | Brand: LEXiBOOK

1. Introduction

Thank you for purchasing the LEXiBOOK RC18 Crosslander Radio Road Motorcycle. This manual provides essential information for the safe and effective operation, setup, and maintenance of your new remote-controlled motorcycle. Please read this manual thoroughly before use and retain it for future reference.

2. Safety Information

- **Age Recommendation:** This product is suitable for users aged 6 years and up. Adult supervision is recommended for younger users.
- **Battery Safety:**
  - Do not mix old and new batteries.
  - Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
  - Non-rechargeable batteries are not to be recharged.
  - Rechargeable batteries are only to be charged under adult supervision.
  - Rechargeable batteries are to be removed from the toy before being charged.
  - Exhausted batteries are to be removed from the toy.
  - The supply terminals are not to be short-circuited.
  - Dispose of batteries responsibly according to local regulations.
- **Operating Environment:** Operate the motorcycle on flat, clear surfaces. Avoid water, sand, thick carpets, or uneven terrain that may damage the product.
- **Avoid Obstacles:** Ensure the operating area is free from people, pets, and obstacles to prevent accidents or damage.
- **Impacts:** Avoid collisions with hard surfaces or objects, as this may damage the motorcycle or its components.
- **Cleaning:** Refer to the Maintenance section for proper cleaning instructions. Do not immerse the motorcycle or remote control in water.

3. Package Contents



Image: The LEXiBOOK RC18 Crosslander Radio Road Motorcycle shown in its retail packaging, displaying the motorcycle, remote control, and accessories.

- 1 x LEXiBOOK RC18 Crosslander Radio Road Motorcycle (Scale 1:18)
- 1 x Ergonomic Remote Control (2.4 GHz)
- 1 x Rechargeable Battery for Motorcycle
- 1 x USB Charging Cable
- 1 x Instruction Manual (this document)

Note: 2 x LR6 / AA batteries for the remote control are **not included** and must be purchased separately.

4. Product Overview



Image: The LEXiBOOK RC18 Crosslander Radio Road Motorcycle with its remote control, showcasing the motorcycle's design and the ergonomic remote.

The LEXiBOOK RC18 Crosslander is a 1:18 scale radio-controlled motorcycle designed for dynamic play. It features a 2.4 GHz radio control system for interference-free operation, allowing for fast acceleration, precise turns, and impressive skids. The motorcycle is equipped with full spring suspension and durable wheels to handle various maneuvers.

Key Features:

- **2.4 GHz Radio Control:** Enables multiple vehicles to operate simultaneously without interference.
- **High Speed:** Achieves speeds up to 12 km/h (7 mph).
- **Advanced Balance System:** Designed for stable piloting and stunt execution.
- **Light Effects:** Enhances visual appeal during operation.
- **Durable Construction:** Full spring suspension and resistant wheels for various terrains.
- **Ergonomic Remote Control:** Provides comfortable grip and precise control.
- **Rechargeable Battery:** Motorcycle includes a rechargeable battery and USB charging cable.



Image: Front view of the LEXiBOOK RC18 Crosslander Motorcycle, surrounded by icons representing its features such as stunts, off-road capability, rechargeable battery, 2.4 GHz control, light effects, and 1:18 scale.

5. Setup

5.1. Remote Control Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Using a small screwdriver (not included), unscrew the battery compartment cover.
3. Insert 2 x LR6 / AA batteries (not included) into the compartment, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.

5.2. Motorcycle Battery Installation and Charging

1. Locate the battery compartment on the underside of the motorcycle.
2. Using a small screwdriver (not included), unscrew the battery compartment cover.
3. Connect the included rechargeable battery to the motorcycle's battery connector, ensuring a secure fit.
4. Place the battery inside the compartment and replace the cover, securing it with the screw.
5. To charge the motorcycle battery: Connect the USB charging cable to the battery. Plug the other end of the USB cable into a standard USB power adapter (e.g., computer USB port, wall charger).
6. The charging indicator light on the USB cable will illuminate during charging. Charging time is approximately 90 minutes.
7. Once fully charged, the indicator light may change or turn off (refer to charger specific behavior). Disconnect the battery from the charger.

Important: Always ensure the motorcycle's power switch is in the OFF position before charging.

6. Operating Instructions

6.1. Pairing the Remote Control and Motorcycle

1. Ensure both the motorcycle and remote control have fresh or fully charged batteries installed.
2. Turn on the motorcycle using the power switch located on its underside.
3. Turn on the remote control. The indicator light on the remote will flash.
4. Place the motorcycle on a flat surface. The remote control and motorcycle will automatically pair within a few seconds. The remote's indicator light will become solid once paired.
5. If pairing fails, turn both devices off and repeat the steps.

6.2. Driving the Motorcycle



Image: A child is shown operating the LEXiBOOK RC18 Crosslander Radio Road Motorcycle with the remote control, demonstrating the motorcycle in action, possibly performing a jump.

- **Forward/Backward:** Use the trigger on the remote control. Pull the trigger to move forward, push it to move backward.
- **Steering:** Use the steering wheel on the remote control. Turn the wheel left to steer left, and right to steer right.
- **Stunts and Skids:** The motorcycle's advanced balance system allows for dynamic maneuvers. Practice combining steering and acceleration to perform skids and turns.
- **Light Effects:** The motorcycle features integrated light effects that activate during operation.

The playing time for a fully charged battery is approximately 20 minutes. When the motorcycle's speed decreases significantly or it becomes unresponsive, it's time to recharge the battery.

7. Maintenance

- **Cleaning:** Wipe the motorcycle and remote control with a soft, dry cloth. Do not use chemical cleaners or immerse in water.
- **Storage:** When not in use for extended periods, remove all batteries from both the motorcycle and the remote control. Store the product in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Battery Care:** Always fully charge the rechargeable battery before storage and periodically during long storage periods to maintain battery health.

8. Troubleshooting

Problem	Possible Cause	Solution
Motorcycle does not respond to remote.	Batteries are low or incorrectly installed. Motorcycle and remote are not paired. Power switches are off.	Check and replace/recharge batteries; ensure correct polarity. Turn both devices off and on again to re-pair. Ensure both power switches are ON.
Motorcycle moves slowly or inconsistently.	Motorcycle battery is low. Operating on unsuitable surfaces (e.g., thick carpet).	Recharge the motorcycle battery. Move to a flat, smooth operating surface.
Remote control indicator light flashes continuously.	Not paired with motorcycle. Remote control batteries are low.	Ensure motorcycle is on and attempt to re-pair. Replace remote control batteries.

9. Specifications

Feature	Detail
Model Number	RC18
Brand	LEXiBOOK
Scale	1:18
Maximum Speed	12 km/h (7 mph)
Radio Frequency	2.4 GHz
Motorcycle Battery	1 x Rechargeable Battery (included)
Remote Control Batteries	2 x LR6 / AA Batteries (not included)
Motorcycle Charging Time	Approx. 90 minutes
Motorcycle Playing Time	Approx. 20 minutes
Recommended Age	6 years and up
Product Dimensions	10.04 x 4.09 x 6.69 inches
Item Weight	10.4 ounces

10. Warranty and Support

LEXiBOOK products are manufactured to high standards. For any questions regarding your LEXiBOOK RC18 Crosslander Radio Road Motorcycle, or for warranty claims, please refer to the contact information provided on the product packaging or visit the official LEXiBOOK website for customer support details.
Please retain your proof of purchase for warranty purposes.

© 2025 LEXiBOOK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09V7PSWM3

More documents and user manuals: **https://manuals.plus/**