Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEXiBOOK RC58

LEXiBOOK Crosslander Slide RC58 Remote Control Car User Manual

Model: RC58 | Brand: LEXiBOOK

1. Introduction

This manual provides essential instructions for the safe and effective operation of your LEXiBOOK Crosslander Slide RC58 Remote Control Car. Please read this manual thoroughly before use and retain it for future reference.
The Crosslander Slide RC58 is a versatile remote control car designed for various terrains, featuring 4-wheel drive and specialized tires. It is capable of drift functions, lateral and diagonal movements, and can be driven on both sides. Experience impressive tricks, including 360° turns, and choose between two speeds, reaching up to 12km/h. The car also includes amazing lighting effects and operates on a 2.4 GHz frequency for optimized range and reduced interference. It is powered by a rechargeable battery and is suitable for users aged 6 years and up.

2. Safety Information

WARNING! Not suitable for children under 3 years. Choking Hazard – Small parts.

- Always operate the vehicle in a safe environment, away from people, pets, and obstacles.
- Do not operate near water or in wet conditions to prevent electrical damage.
- Ensure adult supervision for children operating the vehicle.
- Do not touch moving parts during operation to avoid injury.
- Use only the specified batteries and charging equipment.
- Dispose of batteries responsibly according to local regulations.

3. What's in the Box



Image: The LEXiBOOK Crosslander Slide RC58 remote control car, its remote controller, a rechargeable battery, and a USB charging cable, all displayed alongside the product packaging.

- 1 x LEXiBOOK Crosslander Slide RC58 Remote Control Car
- 1 x Remote Controller
- 1 x Rechargeable Battery (for car)
- 1 x USB Charging Cable
- Instruction Manual (this document)

Note: 2 x LR6 / AA batteries are required for the remote controller and are not included.

4. Setup

4.1 Battery Installation

1. **For the Remote Control:** Locate the battery compartment on the back of the remote controller. Open the compartment cover. Insert 2 x LR6 / AA batteries, ensuring correct polarity (+/-). Close the cover securely.
2. **For the Car:** Locate the battery compartment on the underside of the car. Open the compartment cover. Connect the included rechargeable battery to the car's battery connector. Place the battery inside the compartment and close the cover securely.

4.2 Charging the Car Battery

1. Connect the rechargeable battery to the USB charging cable.
2. Plug the USB charging cable into a standard USB power adapter (not included) or a computer USB port.
3. The charging indicator light on the USB cable will illuminate during charging and turn off or change color when fully charged.
4. Charging time is approximately 2-3 hours. A full charge provides approximately 25 minutes of playtime.

4.3 Pairing the Remote Control with the Car

1. Ensure both the car and the remote control have fresh or fully charged batteries.
2. Turn on the car using the power switch.
3. Turn on the remote control.
4. The remote control and car should automatically pair. If not, turn both off and on again, or refer to the specific pairing instructions on the remote control or car.

5. Operating Instructions

5.1 Basic Controls

Use the joysticks on the remote control to maneuver the car:

- **Left Joystick:** Controls forward and backward movement.
- **Right Joystick:** Controls left and right turning.

5.2 Special Features



Image: The LEXiBOOK Crosslander Slide RC58 car is shown with various icons around it, representing its key features such as lighting effects, 360-degree stunts, reversible driving, and rechargeable battery.

- **4-Wheel Drive & Sticky Tires:** Designed for optimal traction and performance across various terrains.
- **Drift Function:** Execute lateral and diagonal movements by combining specific joystick inputs. Refer to the remote control diagram for precise commands.
- **Reversible Driving:** The car is designed to operate effectively even when flipped, allowing for continuous play without manual reorientation.
- **360° Stunts:** Perform impressive 360-degree spins and turns.
- **Two Speed Modes:** Select between two speed settings, including a high-speed mode up to 12km/h for advanced maneuvers.
- **Lighting Effects:** The car features integrated lighting for enhanced visual appeal during operation.
- **2.4 GHz Frequency:** Ensures a stable connection and reduced interference for a smooth control experience.



Image: A child is seen kneeling on a paved surface outdoors, actively controlling the LEXiBOOK Crosslander Slide RC58 remote control car with its remote controller.

5.3 Age Recommendation

This product is recommended for ages 6 years and up.

5.4 Official Product Video

▶ **Watch video online**
Lexibook, Crosslander slide, remote control car, 4 wheel drive

Video: An official demonstration of the Lexibook Crosslander Slide remote control car, showcasing its 4-wheel drive capabilities and various stunts.

6. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the car and remote control. Do not use water or cleaning solvents.
- **Storage:** When not in use, store the car and remote control in a cool, dry place, away from direct sunlight. Remove batteries from the remote control if storing for extended periods.
- **Battery Care:** Do not overcharge the rechargeable battery. Allow it to cool down before recharging.

7. Troubleshooting

- **Car not responding:** Ensure both the car and remote control are powered on and batteries are correctly installed and charged. Re-pair the remote control if necessary.
- **Short Playtime:** The rechargeable battery provides approximately 25 minutes of play after a 2-3 hour charge. If playtime is significantly shorter, the battery may need to be replaced or fully charged.
- **Poor Range/Interference:** Ensure no other 2.4 GHz devices are causing interference. Operate in an open area away from large metal objects or other electronic devices.
- **Car not performing stunts:** Check for any obstructions in the wheels or chassis. Ensure the battery is fully charged for optimal power.

8. Specifications

Feature	Detail
Model Number	RC58
Brand	LEXiBOOK
Product Dimensions	6.3 x 5.91 x 2.76 inches
Item Weight	1.21 pounds
Scale	1/14
Max Speed	Up to 12 km/h
Frequency	2.4 GHz
Car Battery	1 Rechargeable Battery (included)

Remote Control Batteries	2 x LR6 / AA batteries (not included)
Charging Time	2-3 hours
Playing Time	Approx. 25 minutes
Recommended Age	6 years and up

9. Warranty and Support

Information regarding product warranty and customer support is not provided in the available product data. Please refer to the product packaging or the manufacturer's official website for details on warranty coverage and how to contact customer support for assistance.

© 2023 LEXiBOOK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09VL81XZW

More documents and user manuals: **https://manuals.plus/**