Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TRESKO THSL-001

TRESKO Infrared Heater 2500W (Model THSL-001) User Manual

Comprehensive instructions for safe and efficient use.

1. Important Safety Instructions

Please read this manual carefully before operating the TRESKO Infrared Heater. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Electrical Safety:** Ensure the power supply matches the voltage specified on the heater. Do not overload electrical outlets. Always unplug the heater when not in use or before cleaning. Do not operate with a damaged cord or plug.
- **Placement:** Maintain a safe distance from combustible materials such as furniture, curtains, and paper. Do not cover the heater. Ensure stable placement on a flat, level surface if using the tripod stand.
- **Hot Surfaces:** The heater's grille and housing become very hot during operation. Avoid direct contact with hot surfaces to prevent burns. Allow the unit to cool completely before handling or storing.
- **Indoor/Outdoor Use:** This heater is designed for both indoor and outdoor use, featuring an IP34 protection rating, making it waterproof and corrosion-resistant. However, avoid direct exposure to heavy rain or extreme weather conditions.
- **Children and Pets:** Keep children and pets away from the heater during operation. Adult supervision is required when the heater is in use near children.
- **Ventilation:** Ensure adequate ventilation when operating the heater, especially in enclosed spaces.
- **Maintenance:** Do not attempt to repair or modify the heater yourself. Contact qualified service personnel for any repairs.

2. Package Contents

Verify that all components are present and undamaged:

- TRESKO Infrared Heater Unit
- Adjustable Tripod Stand
- Wall Mounting Bracket
- Remote Control
- Protective Cover (IP34 waterproof)
- User Manual

3. Product Overview

The TRESKO Infrared Heater features a modern design with a robust aluminum housing and a quartz tube heating element. It offers three power levels and can be controlled via a digital display or remote control.



Image 3.1: TRESKO Infrared Heater with its remote control and digital display. The display shows the current power setting (e.g., P2) and indicates timer activation. The remote allows for power adjustment and timer settings.

4. Setup

4.1 Tripod Assembly

1. Unfold the legs of the tripod stand until they are fully extended and stable.
2. Insert the main pole into the tripod base and secure it with the provided fasteners.
3. Attach the heater unit to the top of the main pole, ensuring it is firmly secured.
4. Adjust the height of the tripod between 110 cm and 180 cm using the adjustment knob.

4.2 Wall Mounting

1. Select a suitable wall location, ensuring it is sturdy enough to support the heater's weight and away from flammable materials.
2. Use the provided wall mounting bracket as a template to mark drilling points.
3. Drill holes and insert appropriate wall plugs (if necessary).
4. Secure the bracket to the wall.
5. Attach the heater unit to the wall mounting bracket.



Image 4.1: The adjustable tripod stand of the TRESKO Infrared Heater, showing its height adjustment mechanism, 360-degree rotation capability, and non-slip feet for stability.



Image 4.2: The TRESKO Infrared Heater installed on a wall, demonstrating its versatility. The image highlights the durable aluminum casing, stainless steel protective grille, and suitability for various environments.

4.3 Power Connection

Plug the power cord into a grounded electrical outlet. Ensure the outlet meets the heater's power requirements.

5. Operating Instructions

5.1 Powering On/Off

Press the 'Open/Close' button on the control panel or the remote control to turn the heater ON or OFF.

5.2 Adjusting Heat Levels

The heater has three power levels: 850W, 1650W, and 2500W. Use the 'Power' button on the remote control or the control panel to cycle through the settings. The current power level will be displayed on the digital screen.

5.3 Using the Remote Control

The remote control allows convenient operation from a distance. It includes buttons for:

- **Open/Close:** Power ON/OFF
- **Power:** Cycle through heat levels (850W, 1650W, 2500W)
- **Time:** Set the timer function

5.4 Setting the Timer

Press the 'Time' button on the remote control or control panel to activate the timer. You can set the timer for 1 to 24 hours. The heater will automatically turn off after the set duration.

5.5 Adjusting Heater Angle

The heater unit can be rotated 360 degrees on its stand to direct heat where needed. Loosen the adjustment knob on the stand, position the heater, and then tighten the knob to secure it.

6. Maintenance

6.1 Cleaning

Always unplug the heater and allow it to cool completely before cleaning.

- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Ensure no water enters the internal components.
- Periodically check the power cord for any damage.

6.2 Storage

When not in use, especially during off-season, store the heater in a cool, dry place. Use the provided IP34 waterproof protective cover to shield the unit from dust and moisture.



Image 6.1: The TRESKO Infrared Heater with its protective cover, illustrating how the cover safeguards the unit from environmental elements when not in use, enhancing its durability.

7. Troubleshooting

If you encounter issues with your TRESKO Infrared Heater, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Heater does not turn on.	No power supply. Power cord damaged. Overheating protection activated.	Check power outlet and plug. Inspect power cord for damage. Unplug and allow to cool for 30 minutes, then restart.

Problem	Possible Cause	Solution
Remote control not working.	Batteries are dead or incorrectly inserted. Obstruction between remote and heater.	Replace batteries, ensuring correct polarity. Remove any obstructions. Ensure remote is pointed at the heater's receiver.
Heater produces insufficient heat.	Incorrect power level selected. Heater placed too far from target area.	Increase power level to 1650W or 2500W. Reposition heater closer to the desired heating area.
Unusual noise during operation.	Loose components.	Turn off and unplug the heater. Check for any loose parts. If noise persists, contact customer support.

If the problem persists after attempting these solutions, please contact TRESKO customer support or your retailer for assistance.

8. Specifications

Detailed technical specifications for the TRESKO Infrared Heater 2500W:

Model Number: THSL-001

Power Output: 850W / 1650W / 2500W (3 levels)

Power Source: Electric Cable

Voltage: [Not specified in JSON, assume standard European 220-240V]

Heating Method: Radiant (Infrared)

Material: Aluminum housing, Stainless Steel protection grille

Protection Rating: IP34 (Waterproof and corrosion-resistant)

Usage: Indoor and Outdoor

Tripod Height Adjustment: 110 cm to 180 cm

Rotation: 360 degrees

Timer Function: 1-24 hours

Special Features: Remote control, Digital display

Product Dimensions (Heater Unit): Approximately 87 cm (Length) x 18 cm (Height) x 9 cm (Depth)

Product Dimensions (with Tripod): 50 cm (L) x 85 cm (W) x 175 cm (H max)

Weight: Approximately 1 kg (heater unit, excluding tripod)



Image 8.1: A detailed diagram illustrating the key dimensions of the TRESKO Infrared Heater when assembled on its tripod stand, including overall height, width, and depth.

9. Warranty and Support

For warranty information, please refer to the terms and conditions provided by your retailer at the time of purchase. For technical support, spare parts, or any inquiries not covered in this manual, please contact the manufacturer or your authorized dealer.

Manufacturer: DWD-Company GmbH & Co. KG

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09WYRKLNC

More documents and user manuals: **https://manuals.plus/**