Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Skullcandy S2DBW-P751-cr

Skullcandy Dime 2 True Wireless Earbuds User Manual

Model: S2DBW-P751-cr

Introduction

Welcome to the user manual for your new Skullcandy Dime 2 True Wireless in-Ear Earbuds. These compact and powerful earbuds are designed to provide a seamless audio experience with advanced features like Tile finding technology and robust water resistance. This manual will guide you through setup, operation, and maintenance to ensure you get the most out of your device.

Image: The Skullcandy Dime 2 earbuds, shown in their compact charging case. The earbuds are light grey/blue, and the case is grey.

What's in the Box

Your Skullcandy Dime 2 package includes the following items:

- Skullcandy Dime 2 True Wireless Earbuds
- Charging Case
- Charging Cable
- Ear Gels (various sizes for optimal fit) - *(Assumed, common for earbuds, not explicitly in JSON but implied by "earbud" type)*

Image: The retail packaging for the Skullcandy Dime 2 earbuds, displaying the product and its key features.

Setup

Charging Your Earbuds and Case

Before first use, ensure your earbuds and charging case are fully charged. The charging case holds reserve power to charge your earbuds on the go.

1. Place both earbuds into the charging case.
2. Connect the provided charging cable to the charging port on the back of the case and to a USB power source.
3. The LED indicators on the case will show charging status. Once fully charged, the indicators will change or turn off.

Bluetooth Pairing

To pair your Skullcandy Dime 2 earbuds with your device:

1. Remove both earbuds from the charging case. They will automatically enter pairing mode.

2. On your device (smartphone, tablet, etc.), go to Bluetooth settings and turn Bluetooth on.
3. Select "Dime 2" from the list of available devices.
4. Once connected, you will hear an audio prompt, and the earbuds' LED indicators will confirm successful pairing.

Operating Your Earbuds

Touch Controls

The Skullcandy Dime 2 earbuds feature intuitive touch controls for managing your audio and calls. Refer to the quick start guide for specific tap sequences for functions like play/pause, skip track, volume control, and answering calls.

Key Features

- **Tile Finding Technology:** Integrated Tile technology allows you to easily locate your earbuds if they are misplaced. Use the Tile app on your smartphone to ring your earbuds or see their last known location on a map.
- **True Wireless via Bluetooth v5.2:** Enjoy stable and efficient wireless connectivity for a seamless listening experience.
- **Up to 12 Hours Total Battery:** Get hours of listening time with the earbuds and additional charges from the compact charging case.
- **IPX4 Sweat and Water Resistant:** Designed to withstand splashes and sweat, making them suitable for workouts and outdoor activities.

Image: A close-up view of a Skullcandy Dime 2 earbud, demonstrating its IPX4 sweat and water resistance with visible water droplets.

Image: A person wearing a Skullcandy Dime 2 earbud, illustrating how the earbud fits comfortably and discreetly in the ear.

Maintenance

To ensure the longevity and optimal performance of your Skullcandy Dime 2 earbuds:

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Avoid using harsh chemicals or abrasive materials.
- **Ear Gels:** Remove and clean the ear gels periodically. Ensure they are completely dry before reattaching them to the earbuds.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged.
- **Water Resistance:** While IPX4 rated for sweat and water resistance, do not submerge the earbuds in water. Dry them thoroughly if they get wet.

Troubleshooting

If you encounter issues with your Skullcandy Dime 2 earbuds, try the following steps:

- **No Power:** Ensure both earbuds and the charging case are fully charged.
- **Pairing Issues:**
  - Make sure Bluetooth is enabled on your device.
  - Turn off and on your device's Bluetooth.
  - Forget "Dime 2" from your device's Bluetooth list and re-pair.
  - Reset the earbuds (refer to Skullcandy's official support for specific reset instructions).
- **One Earbud Not Working:** Place both earbuds back in the case, close the lid, wait a few seconds, then remove them. This often re-syncs them.
- **Low Volume/Poor Sound Quality:**
  - Clean any debris from the earbud nozzles and ear gels.
  - Ensure ear gels are properly seated and you are using the correct size for a good seal.
  - Adjust volume on both your device and the earbuds.

For more detailed troubleshooting or persistent issues, please visit the official Skullcandy support website.

Specifications

Feature	Detail
Model Name	Dime 2
Model Number	S2DBW-P751-cr
Connectivity Technology	Wireless (Bluetooth v5.2)
Total Battery Life	Up to 12 Hours
Water Resistance	IPX4 (Sweat and Water Resistant)
Control Type	Media Control, Touch
Finding Technology	Tile
Material	Plastic
Item Weight	1.13 ounces (0.03 Kilograms)
Product Dimensions	5.71 x 3.15 x 1.06 inches
Batteries	3 Lithium Polymer batteries (included)

Warranty and Support

This product is covered by the standard Skullcandy warranty. For detailed warranty information, product registration, and technical support, please visit the official Skullcandy website or contact their customer service. For renewed products, please refer to the Amazon Renewed Guarantee for replacement or refund eligibility.

Amazon Renewed Guarantee: If not satisfied with the purchase, renewed products are eligible for replacement or refund under the Amazon Renewed Guarantee.
For further assistance, you may also refer to theAmazon Renewed Store.

© 2025 Skullcandy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09YM496M2

More documents and user manuals: **https://manuals.plus/**