Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Keter Planet Outdoor Alto

Keter Planet Outdoor Resin Storage Cabinet

Model: Planet Outdoor Alto | 80 x 44 x 182 cm

1. Introduction

Thank you for choosing the Keter Planet Outdoor Resin Storage Cabinet. This durable and versatile cabinet is designed to provide efficient storage solutions for your outdoor spaces, garages, or utility rooms. Constructed from high-quality resin, it features four adjustable shelves, offering flexible organization for various items. Please read this manual carefully before assembly and use to ensure safe operation and optimal performance of your cabinet.



Figure 1: Keter Planet Outdoor Resin Storage Cabinet (Front View)
This image shows the Keter Planet Outdoor Resin Storage Cabinet from the front, with its two doors closed. The cabinet is green and features a textured surface, indicating its resin construction. It stands on four sturdy legs.

2. Safety Information

Please observe the following safety precautions to prevent injury and damage to the product:

- **Read All Instructions:** Before assembly and use, carefully read and understand all instructions in this manual.
- **Adult Assembly Required:** Assembly should be performed by adults only. Keep children and pets away from the assembly area.
- **Use Proper Tools:** Ensure you have the necessary tools as specified in the assembly section.
- **Inspect Components:** Before assembly, check all parts for damage. Do not assemble if any parts are damaged. Contact customer support for replacements.
- **Stable Surface:** Assemble the cabinet on a flat, level, and stable surface to prevent tipping.
- **Secure Placement:** Once assembled, place the cabinet on a firm, level surface. Consider anchoring it to a wall

for added stability, especially in areas prone to strong winds or if heavy items are stored.

- **Weight Capacity:** Do not exceed the maximum weight capacity of 30 kg (66 lbs) per shelf. Distribute weight evenly.
- **Avoid Climbing:** Do not allow children to climb on or play with the cabinet.
- **Flammable Materials:** Do not store flammable liquids or hazardous materials inside the cabinet.
- **Ventilation:** Ensure adequate ventilation if storing items that require it.

3. Package Contents

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, do not proceed with assembly. Contact Keter customer service for assistance.

- Side Panels (2)
- Top Panel (1)
- Bottom Panel (1)
- Back Panels (flexible, multiple sections)
- Doors (2)
- Adjustable Shelves (4)
- Shelf Supports/Brackets
- Door Handles (2)
- Assembly Hardware (screws, pins, etc.)
- Instruction Manual (this document)

4. Setup and Assembly

Assembly typically requires one to two adults. No special tools are usually required beyond a rubber mallet (optional) and a Phillips head screwdriver for handles.

4.1 Preparation

1. Clear a spacious, flat, and clean area for assembly.
2. Unpack all components and lay them out, identifying each part according to the parts list.
3. Ensure all parts are free from damage.

4.2 Assembly Steps

1. **Attach Side Panels to Bottom Panel:** Securely connect the two side panels to the bottom panel. Ensure they click firmly into place.
2. **Insert Back Panels:** Carefully slide the flexible back panels into the grooves of the side panels. Start from the bottom and work your way up. Ensure they are fully seated in the grooves.
3. **Attach Top Panel:** Place the top panel onto the assembled structure. Align it carefully with the side panels and back panels. Press down firmly until it clicks into place. *Note: Ensure the back edge of the top panel properly grips the back panels for a secure fit. This step may require two people for easier alignment.*
4. **Install Doors:** Attach the doors to the cabinet using the provided hinges. Ensure the doors swing freely and align correctly.
5. **Install Handles:** Attach the handles to the doors. Align the handles with the pre-drilled holes on the doors and

secure them with the provided screws from the inside. *Note: Some handle designs may have more screw points than required; use only the necessary ones as indicated in the specific handle instructions.*



Figure 2: Cabinet Door Handles

This image provides a close-up view of the two handles on the cabinet doors. The handles are a contrasting color, likely beige or light brown, against the green cabinet doors, and are designed for easy gripping.

6. **Install Shelves:** Insert the shelf supports into the desired slots on the side panels. Place the shelves onto these supports. Ensure shelves are level and securely seated.



Figure 3: Cabinet Interior with Adjustable Shelves

This image shows the interior of the Keter Planet Outdoor cabinet with its doors open. Four adjustable shelves are visible, along with the various slots on the side panels that allow for shelf height customization. The interior matches the exterior green color.

5. Operating Instructions

5.1 Adjusting Shelves

The Keter Planet Outdoor cabinet features four adjustable shelves, allowing you to customize the storage space to fit your needs.

1. Empty the shelf you wish to adjust.
2. Carefully lift the shelf and remove it from its supports.
3. Relocate the shelf supports to the desired height slots on the side panels. Ensure supports are level.
4. Place the shelf back onto the supports, ensuring it is stable and fully seated.

5.2 Loading the Cabinet

- Distribute weight evenly across each shelf.
- Do not exceed the maximum weight capacity of 30 kg (66 lbs) per shelf.
- Place heavier items on lower shelves to improve cabinet stability.
- Ensure doors can close freely without obstruction from stored items.

6. Maintenance and Care

To ensure the longevity and appearance of your Keter Planet Outdoor cabinet, follow these simple maintenance guidelines:

- **Cleaning:** Clean the cabinet regularly with a soft cloth, mild soap, and water. Avoid abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the resin surface.
- **Stains:** For stubborn stains, a non-abrasive household cleaner can be used, followed by thorough rinsing with water.
- **Inspection:** Periodically check all connections and hardware to ensure they are secure. Tighten any loose screws if necessary.
- **Weather Protection:** While designed for outdoor use, extreme weather conditions (e.g., prolonged direct sunlight, heavy snow loads) can affect the material over time. Consider placing the cabinet in a sheltered area if possible.
- **Winter Storage:** If storing the cabinet empty during winter, ensure it is clean and dry.

7. Troubleshooting

Problem	Possible Cause	Solution
Cabinet is wobbly/unstable	Not on a level surface; connections not fully secured.	Move cabinet to a level surface. Check all panel connections to ensure they are fully clicked into place. Consider wall anchoring.

Problem	Possible Cause	Solution
Doors do not close properly	Hinges misaligned; items obstructing closure; cabinet not square.	Check hinge installation and alignment. Ensure no items are blocking the doors. Verify the cabinet is assembled squarely and on a level surface.
Shelves sag or are unstable	Overloaded; shelf supports not fully inserted.	Reduce weight on the shelf, ensuring it does not exceed 30 kg. Re-insert shelf supports firmly into the slots.
Back panels come out of grooves	Top panel not fully secured; cabinet not square.	Ensure the top panel is firmly clicked into place, especially along the back edge, to secure the back panels. Verify the cabinet is assembled squarely.

8. Specifications

Brand	Keter
Model Name	Planet Outdoor Alto
Product Dimensions (W x D x H)	80 cm x 44 cm x 182 cm (31.5 in x 17.3 in x 71.7 in)
Material	Resin (Extruded Polypropylene)
Color	Green
Number of Shelves	4 (Adjustable)
Maximum Weight Load per Shelf	30 kg (66 lbs)
Assembly Required	Yes
Mounting Type	Floor Mount / Freestanding
Number of Doors	2
Model Number	9750200023102
GTIN	08013183121983





Figure 4: Cabinet Dimensions Overview

This image displays the Keter Planet Outdoor cabinet with its key dimensions clearly marked: Height (W182cm), Depth (G44cm), and Width (S80cm). The doors are slightly ajar, showing the interior shelves.

9. Warranty and Support

9.1 Warranty Information

This Keter product is covered by a manufacturer's warranty against defects in materials and workmanship. The

availability period for spare parts in the EU is 2 years from the date of purchase. Please retain your proof of purchase for warranty claims.

9.2 Customer Support

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Keter customer service. For the most up-to-date contact information, please visit the official Keter website or refer to the packaging.

Website: www.keter.com

© 2023 Keter. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09Z73RTP7

More documents and user manuals: **https://manuals.plus/**