Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Geepas GIC33014

Geepas Infrared Cooker GIC33014 User Manual

Model: GIC33014

1. Introduction

Thank you for purchasing the Geepas Infrared Cooker GIC33014. This manual provides important information regarding the safe operation, installation, maintenance, and troubleshooting of your new appliance. Please read this manual thoroughly before use and retain it for future reference.

2. Important Safety Instructions

To reduce the risk of fire, electric shock, injury to persons, or damage to the appliance, basic safety precautions should always be followed, including the following:

- Read all instructions carefully before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- **Caution: Surface remains hot after use. Do not touch. Please don't pull out the plug before the surface cools down in 30 minutes!**

3. Product Overview

The Geepas Infrared Cooker GIC33014 is a portable, single-burner appliance designed for efficient cooking using infrared technology. It features a ceramic heating element, digital display, and touch controls.



Figure 1: Front view of the Geepas Infrared Cooker GIC33014, showcasing its sleek design with the control knob and ceramic cooking surface.



Figure 2: Top view of the Geepas Infrared Cooker GIC33014, highlighting the ceramic cooking surface with the "HI-LIGHT" and "SMART TOUCH" indicators, and safety warnings.

Components:

1. **Ceramic Cooking Surface:** The main heating area.
2. **Control Knob:** Used for power adjustment and timer settings.
3. **Digital LED Display:** Shows temperature levels and timer.
4. **Power Indicator Light:** Signals when the unit is powered on.
5. **Non-slip Rubber Feet:** Ensures stability during use.
6. **Ventilation Openings:** For cooling the internal components.

4. Setup and First Use

1. **Unpacking:** Carefully remove the cooker from its packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the cooker on a stable, flat, heat-resistant surface, away from flammable materials. Ensure adequate ventilation around the unit.
3. **Cleaning:** Before first use, wipe the ceramic surface with a damp cloth. Ensure the unit is completely dry before plugging it in.
4. **Power Connection:** Plug the power cord into a standard electrical outlet. The power indicator light will illuminate briefly.

5. Operating Instructions

The Geepas Infrared Cooker is designed for ease of use with its intuitive touch controls and digital display.



Figure 3: Close-up of the control panel, showing the digital LED display and touch-sensitive buttons for timer and lock functions.

5.1 Power On/Off

- To turn on, press the power button (usually integrated into the control knob or a dedicated touch button). The display will light up.
- To turn off, press the power button again. The unit will enter standby mode.

5.2 Adjusting Temperature/Power Levels

- The cooker offers **10 temperature/power levels**.
- Rotate the central control knob clockwise to increase the power level and counter-clockwise to decrease it. The current level will be shown on the digital LED display.
- Select the desired power level based on your cooking needs (simmer, steam, sear, slow cook, deep fry, boiling, grill).



Figure 4: Detailed view of the control knob, which allows for precise adjustment of heating levels and timer settings.

5.3 Timer Function

- The cooker features a **99-minute timer**.
- To set the timer, press the timer button (indicated by a clock icon).
- Use the control knob or '+' and '-' buttons to adjust the desired cooking time.
- Once the timer expires, the cooker will automatically turn off or alert you.

5.4 Cookware Compatibility

Unlike induction cookers, the Geepas Infrared Cooker works with**all types of cookware**, including ceramic, glass,

aluminum, copper, and stainless steel. Ensure the cookware base is flat and covers the heating element adequately for optimal performance.



Figure 5: The infrared cooker in operation with a frying pan, demonstrating its versatility with various cookware types.

5.5 Overheat Protection

The cooker is equipped with an **overheat protection system**. If the internal temperature exceeds a safe limit, the unit will automatically shut down to prevent damage. Allow the unit to cool down before attempting to use it again.

6. Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your Geepas Infrared Cooker.

1. **Before Cleaning:** Always unplug the cooker from the power outlet and allow it to cool completely. The ceramic surface remains hot for up to 30 minutes after use.
2. **Ceramic Surface:** Wipe the ceramic glass surface with a soft, damp cloth and mild detergent. For stubborn stains, use a non-abrasive cleaner specifically designed for ceramic cooktops. Rinse with a clean damp cloth and

dry thoroughly.

3. **Body:** Wipe the exterior body with a soft, damp cloth. Do not use abrasive cleaners or scourers.
4. **Do Not Immerse:** Never immerse the cooker, power cord, or plug in water or any other liquid.
5. **Storage:** When not in use, store the cooker in a cool, dry place.

7. Troubleshooting

If you encounter any issues with your infrared cooker, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Cooker does not turn on.	Not plugged in; power outage; faulty outlet.	Ensure the plug is securely inserted. Check the power supply. Try a different outlet.
Cooker stops heating during operation.	Overheat protection activated; timer expired.	Allow the unit to cool down. Check if the timer has run out.
Uneven heating.	Cookware not centered; cookware base is warped.	Ensure cookware is centered on the heating element. Use cookware with a flat base.
Display shows an error code.	Internal malfunction.	Unplug the unit, wait a few minutes, then plug it back in. If the error persists, contact customer support.

8. Product Specifications

Feature	Specification
Brand	Geepas
Model Number	GIC33014
Power / Wattage	2000 watts
Voltage	240 Volts
Material	Ceramic, Plastic
Special Features	Digital Display, Portable, Timer, Overheat Protection
Product Dimensions	33 x 29 x 8.8 cm
Item Weight	2.15 Kilograms
Heating Elements	2 (Double Heat Ring)
Temperature Levels	10
Timer	99 minutes
Control Type	Touch

9. Warranty and Support

Geepas products are manufactured to the highest quality standards. For information regarding warranty coverage,

please refer to the warranty card included with your purchase or visit the official Geepas website. For technical support or service inquiries, please contact Geepas customer service.

Geepas Official Website: www.geepas.com

© 2023 Geepas. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

What should I do if my Geepas GIC33014 Infrared Cooker shows the error code Er 1?

According to the troubleshooting section of the Geepas GIC33014 manual, when the digital display shows an error code, it typically indicates an internal malfunction or a safety trigger. To resolve the Er 1 error,...

Read full answer

Open the live page

https://manuals.plus/asin/B09ZPMNXQG

More documents and user manuals: **https://manuals.plus/**