Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MUSIC HERO Floating Speaker

MUSIC HERO Floating Speaker User Manual

Wireless Waterproof 3W Audio with Inflatable Unicorn Float

Introduction

Thank you for choosing the MUSIC HERO Floating Speaker. This wireless, waterproof 3W audio device is designed to provide entertainment in various water environments, including pools, bathtubs, and beaches. It features Bluetooth V5.0 connectivity, an IPX6 waterproof rating, and comes with an inflatable unicorn float for buoyant use. This manual provides essential instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your speaker.

Package Contents

- MUSIC HERO Floating Speaker (3W)
- Inflatable Unicorn Float
- Mini Air Pump
- USB to Micro-USB Charging Cable

Setup Instructions

1. Inflating the Unicorn Float

Locate the inflatable unicorn float and the included mini air pump. Insert the pump nozzle into the float's air valve and inflate until the float is firm but not overinflated. Ensure the valve is securely closed after inflation.

2. Inserting the Speaker into the Float

Carefully place the MUSIC HERO Floating Speaker into the designated opening on the inflatable unicorn float. Ensure the speaker is seated securely within the float.



Figure 1: Inserting the wireless speaker into the inflatable unicorn float. The speaker fits snugly into the central opening of the float, allowing it to float on water.

3. Charging the Speaker

Before first use, fully charge the speaker. Connect the Micro-USB end of the charging cable to the speaker's charging port and the USB end to a compatible power source (e.g., USB wall adapter, computer USB port). The charging indicator light will illuminate. A full charge takes approximately 1 hour and 30 minutes.

Operating Instructions

1. Powering On/Off

Press and hold the power button (usually marked with a power symbol) on the speaker for a few seconds to turn it on or off. A sound or indicator light will confirm the power status.

2. Bluetooth Pairing

1. Ensure the speaker is powered on and in pairing mode (often indicated by a flashing LED light).

2. On your smartphone, tablet, or other Bluetooth-enabled device, go to the Bluetooth settings.
3. Search for available devices and select "MUSIC HERO Floating Speaker" (or similar name) from the list.
4. Once paired, the speaker will emit a confirmation sound, and the LED indicator will typically stop flashing and remain solid.

The wireless range is approximately 10 meters (33 feet). Keep your audio source within this range for stable connection.



Figure 2: Pairing the speaker with a smartphone. The speaker is shown on a beach, ready for wireless music playback.

3. Playing Music

After successful pairing, start playing music from your connected device. The audio will be streamed wirelessly to the MUSIC HERO Floating Speaker. Adjust volume from your device or directly on the speaker if it has volume controls.

4. Water Resistance (IPX6)

The speaker is rated IPX6, meaning it is resistant to powerful water jets and immersion up to 1 meter deep. This allows for safe use in pools, bathtubs, and other wet environments. Ensure the charging port cover is securely closed before exposing the speaker to water.



Figure 3: Key features including IPX6 water resistance and approximate battery life.

Maintenance

- **Cleaning:** Wipe the speaker and float with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, deflate the unicorn float and store both the speaker and float in a cool, dry place away from direct sunlight.
- **Battery Care:** To prolong battery life, avoid fully discharging the speaker frequently. Recharge it regularly, even if not in constant use.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not turn on.	Battery is discharged.	Charge the speaker using the provided USB cable.
Cannot pair with Bluetooth device.	Speaker is not in pairing mode; device is out of range; Bluetooth is off on the device.	Ensure speaker is on and in pairing mode. Move device closer to speaker (within 10m). Enable Bluetooth on your device.
Sound is distorted or intermittent.	Device is out of range; interference; low battery.	Move device closer to speaker. Avoid obstacles. Charge the speaker.
Speaker does not float correctly.	Unicorn float is not fully inflated.	Re-inflate the unicorn float using the mini pump.

Specifications

Feature	Detail
Brand	MUSIC HERO
Model Name	Floating Speaker
Connectivity Technology	Bluetooth V5.0, USB
Wireless Range	Up to 10 meters (33 feet)
Speaker Output Power	3 Watts
Water Resistance Rating	IPX6 (Resistant to powerful water jets and immersion up to 1 meter)
Battery Capacity	400 mAh Lithium-polymer
Playing Time	Up to 2 hours
Standby Time	Up to 6 hours
Charging Time	Approximately 1 hour 30 minutes
Compatible Devices	Smartphones, Tablets, Laptops, PCs with Bluetooth
Included Components	Floating Speaker, Inflatable Unicorn Float, Mini Pump, USB Charging Cable
Color	White
Material	Plastic or Silicone (speaker), PVC (float)
Special Features	High-resolution audio, Integrated microphone, Wireless, Waterproof

Warranty and Support

This product is covered by a standard manufacturer's warranty. Please refer to the warranty card included in your original packaging for specific terms and conditions. For technical support, product inquiries, or warranty claims, please contact your retailer or the manufacturer directly. Keep your proof of purchase for warranty validation.
Manufacturer: SBS
Brand: MUSIC HERO

© 2024 MUSIC HERO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B18NGKDD

More documents and user manuals: **https://manuals.plus/**