Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Joyroom JR-T03S

User Manual: Joyroom JR-T03S Plus TWS Wireless Bluetooth Headset

Model: JR-T03S
Brand: Joyroom

1. Introduction

This manual provides detailed instructions for the safe and effective use of your Joyroom JR-T03S Plus TWS Wireless Bluetooth Headset. This product features a dual-core chip with long-lasting battery life, delivering excellent and clear sound with rich details. It is equipped with a comfortable microphone and enhanced sound absorption for clear calls. Please read it thoroughly before use and retain it for future reference.

2. Safety Information

- Do not expose the device to extreme temperatures, humidity, or liquids.
- Avoid dropping or subjecting the device to strong impacts.
- Do not attempt to disassemble or repair the device yourself. Refer to qualified service personnel.
- Keep out of reach of children and pets.
- Use only approved chargers and cables.
- Dispose of the device and its components responsibly according to local regulations.

3. Package Contents

- Joyroom JR-T03S Plus TWS Wireless Bluetooth Headset (Left and Right Earbuds)
- Charging Case
- USB Type-C Charging Cable
- User Manual
- Ear tips (various sizes)

4. Product Overview

4.1 Components

The Joyroom JR-T03S Plus TWS Wireless Bluetooth Headset consists of two earbuds and a portable charging case.



Figure 1: Joyroom JR-T03S Plus TWS Wireless Bluetooth Headset with charging case.



Figure 2: Joyroom JR-T03S Plus TWS Wireless Bluetooth Headset in open charging case, showing the earbuds inside.



Figure 3: Close-up view of the Joyroom JR-T03S Plus TWS earbuds, highlighting the L (Left) and R (Right) indicators.

4.2 Controls and Indicators

The earbuds feature intuitive touch controls for various functions.



Figure 4: Touch Control Technology Overview.

- **Turn On/Off:** Touch and hold the touch area.
- **Play/Pause:** Single tap the touch area.
- **Next Track:** Double tap the right earbud.
- **Previous Track:** Double tap the left earbud.
- **Answer Call/Call Back:** Single tap the touch area.
- **End Call:** Single tap the touch area during a call.
- **Reject Call:** Touch and hold the touch area during an incoming call.
- **Voice Assistant:** Triple tap the touch area.

5. Setup

5.1 Charging the Headset

Before first use, fully charge the earbuds and the charging case.



Figure 5: Wired and Wireless Charging Options.

- **Wired Charging:** Connect the provided USB Type-C cable to the charging port on the case and a power source. The indicator light on the case will show charging status.
- **Wireless Charging:** Place the charging case on a compatible wireless charging pad. Ensure the case is properly aligned for efficient charging.
- The earbuds charge automatically when placed inside the charging case.

5.2 Pairing with a Device

1. Ensure the charging case has sufficient power and the earbuds are inside.
2. Open the charging case lid. The earbuds will automatically enter pairing mode, indicated by a flashing light on the earbuds.
3. On your device (smartphone, tablet, etc.), enable Bluetooth.
4. Search for available Bluetooth devices and select "JR-T03S" from the list.
5. Once connected, the indicator light on the earbuds will stop flashing, and you will hear a confirmation tone.
6. If pairing fails, place the earbuds back into the case, close the lid, and repeat the steps.

6. Operating Instructions

6.1 Power On/Off

- **Power On:** Open the charging case, or touch and hold the touch area on the earbuds for a few seconds.
- **Power Off:** Place the earbuds back into the charging case and close the lid, or touch and hold the touch area on the earbuds for a few seconds until they power off.

6.2 Music Playback

- **Play/Pause:** Single tap either earbud.
- **Next Track:** Double tap the right earbud.
- **Previous Track:** Double tap the left earbud.

6.3 Call Management

- **Answer/End Call:** Single tap either earbud.
- **Reject Call:** Touch and hold either earbud for 2 seconds during an incoming call.

6.4 Voice Assistant

- **Activate Voice Assistant:** Triple tap either earbud.

7. Maintenance

7.1 Cleaning

- Wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Gently clean the charging contacts on the earbuds and inside the case with a dry cotton swab if necessary.

7.2 Storage

- Store the headset in its charging case when not in use to protect it and keep it charged.
- Store in a cool, dry place away from direct sunlight and extreme temperatures.

7.3 Battery Care

- To prolong battery life, avoid fully discharging the battery frequently.
- Charge the device regularly, even if not used for extended periods.

8. Troubleshooting

Issue	Possible Solution
Earbuds not pairing	Ensure earbuds are charged. Place them back in the case, close, then reopen. Turn off and on Bluetooth on your device. Forget the device in Bluetooth settings and re-pair.
No sound from one earbud	Check battery level of both earbuds. Re-pair the earbuds. Ensure both earbuds are properly seated in the charging case.
Charging case not charging	Check the charging cable and adapter. Try a different power source. Ensure the cable is securely connected.

Issue	Possible Solution
Low volume or poor sound quality	Adjust volume on your device. Clean earbud grilles. Ensure ear tips fit properly. Try different ear tip sizes.
Touch controls not responding	Ensure your fingers are clean and dry. Restart the earbuds by placing them in the case and taking them out.

9. Specifications

Feature	Detail
Brand Name	Joyroom
Model Name	JR-T03S
Style	JR-T03S Plus TWS
Connectivity Technology	Wireless
Wireless Communication Technology	Bluetooth
Headphones Form Factor	In-Ear
Color	White
Material Type	Plastic
Item Weight	100 grams
Product Dimensions	17.2 x 9.2 x 4.8 cm
Frequency Range	20 Hz - 20 kHz
Sensitivity	93 dB
Connector Type	USB Type C
Voltage	5 Volts
Water Resistance Level	Not water resistant
Control Type	Media Control
Recommended Product Uses	Making calls, Exercise, Running
Compatible Devices	All iPhone devices and all Android devices
Included Components	Ear tips

10. Warranty and Support

For warranty information and customer support, please refer to the official Joyroom website or contact their customer service. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2024 Joyroom. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B1S1STK2

More documents and user manuals: **https://manuals.plus/**