Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MINISO 2011885610107

MINISO Gradient Water Bottle User Manual

Model: 2011885610107

Introduction

The MINISO Gradient Water Bottle is designed to help you stay hydrated and motivated throughout your day. Crafted from high-quality, BPA-free Tritan material, this durable and leakproof bottle features time markers and motivational maxims to encourage consistent water intake. Its large capacity and portable design make it ideal for various activities, from daily office use to sports and travel.



Image: Front view of the MINISO Gradient Water Bottle, showcasing its pink and green gradient design, integrated handle, and time markers for hydration tracking.

Setup

Unpacking and Initial Cleaning

1. Carefully remove the water bottle from its packaging.
2. Before first use, hand wash all parts of the bottle (bottle body, lid, straw) with warm water and mild soap. Rinse thoroughly.
3. Ensure all components are completely dry before reassembling.

Assembly

1. Insert the silicone straw firmly into the designated opening on the underside of the lid.
2. Ensure the food-grade silicone sealing ring is properly seated within the lid to prevent leaks.
3. Screw the lid onto the bottle body securely until it is hand-tight.



Image: Detailed view of the bottle's lid, showing the internal straw connection point and the silicone sealing ring, crucial for leak prevention.

Operating Instructions

Filling the Bottle

- Unscrew the lid from the bottle.
- Fill the bottle with your desired beverage. The 74oz capacity allows for ample hydration throughout the day.
- Screw the lid back on tightly to ensure a leakproof seal.

Drinking from the Bottle

- To open the flip-top lid, press the safety lock button located on the front of the lid. The lid will spring open, revealing the straw.
- Drink directly from the straw.
- After drinking, push the flip-top lid down firmly until it clicks into place, ensuring the safety lock engages to prevent accidental spills.

Product Details



Image: A collage of product details, highlighting the secure flip-top mechanism, the internal straw, and the ergonomic handle for easy carrying.

Using Time Markers and Motivational Maxims

The bottle features time markers (e.g., "8 AM - READY. SET. DRINK!") and motivational phrases printed on its side. These are designed to help you track your daily water intake and encourage consistent hydration throughout the day. Aim to drink to the indicated level by the corresponding time.



Image: The MINISO water bottle positioned on a desk, illustrating its use in a daily environment and clearly displaying the time markers for hydration tracking.

Portability

The MINISO water bottle is equipped with an adjustable strap, making it easy to carry for various activities such as gym workouts, office use, travel, running, cycling, camping, and other sports. The integrated handle also provides a comfortable grip.



Image: Two MINISO water bottles, one in pink and green gradient and another in grey, demonstrating the product's design and available color variations.

Maintenance and Care

Cleaning Instructions

- **Hand Wash Only:** This water bottle is not dishwasher safe. Wash all components by hand using warm water and mild dish soap.
- For thorough cleaning, disassemble the lid and straw. Use a straw brush to clean the inside of the straw.
- Rinse all parts thoroughly to remove any soap residue.
- Allow all parts to air dry completely before reassembling or storing to prevent mold or odors.

Storage

Store the bottle in a clean, dry place away from direct sunlight and extreme temperatures. Ensure the bottle is completely dry before storage.

Precautions

- Do not fill with hot liquids (above 60°C / 140°F) as this may cause pressure buildup and potential injury or damage to the bottle.
- Do not freeze the bottle when full, as this can cause the bottle to crack.
- Avoid dropping the bottle, especially when full, to prevent damage.
- Keep out of reach of small children when not in use.

Troubleshooting

Problem	Possible Cause	Solution
Bottle is leaking	Lid not screwed on tightly; silicone sealing ring improperly seated or damaged; flip-top lid not fully closed.	Ensure lid is securely tightened. Check that the silicone sealing ring is correctly positioned and free from damage. Press the flip-top lid down firmly until it clicks.
Difficulty drinking through straw	Straw clogged or not fully inserted; air vent blocked.	Remove and clean the straw thoroughly. Ensure the straw is fully inserted into the lid. Check for any blockages in the air vent on the lid.
Unpleasant odor inside bottle	Improper cleaning or drying; residue buildup.	Wash all parts thoroughly with warm, soapy water and a bottle brush. Rinse well and allow to air dry completely before reassembling. For stubborn odors, a mixture of baking soda and water can be used for soaking.

Specifications

Brand	MINISO
Model Number	2011885610107
Material	Tritan Plastic (BPA-Free)
Capacity	74 Ounces (approx. 2.2 Liters)
Color	Pink & Green Gradient
Product Dimensions	5.75"W x 12.1"H
Item Weight	9.1 ounces
Special Features	Leak-proof, Eco-friendly, Large capacity, Time Markers, Motivational Maxims, Adjustable Strap
Care Instructions	Hand Wash Only
Recommended Uses	Fitness, Running, Travel, Daily Hydration



Image: The MINISO water bottle with a clear "2.2L" label, confirming its approximate capacity in liters.

Warranty and Support

For any questions, concerns, or support regarding your MINISO Gradient Water Bottle, please contact MINISO customer service through their official channels or the retailer from whom the product was purchased. Please refer to your purchase receipt for specific warranty details, as warranty terms may vary by region and retailer.

Keep your purchase receipt as proof of purchase for any warranty claims.

For more information, you may visit the official MINISO store page:MINISO Store on Amazon

© 2023 MINISO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B2DM9CZQ

More documents and user manuals: **https://manuals.plus/**