Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Neakasa Power Scrub-2

Neakasa Power Scrub-2 3-in-1 Wet/Dry Vacuum Cleaner Instruction Manual

Model: Power Scrub-2

Introduction

This manual provides essential instructions for the safe and efficient operation, maintenance, and troubleshooting of your Neakasa Power Scrub-2 3-in-1 Wet/Dry Vacuum Cleaner. This appliance is designed to vacuum, mop, and dry hard floors simultaneously, offering a comprehensive cleaning solution. Please read this manual thoroughly before first use and keep it for future reference.

Safety Instructions

To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using an electrical appliance. This includes:

- Read all instructions before using the appliance.
- Do not immerse the appliance in water or other liquids.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with a damaged cord or plug. If the appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Unplug from outlet when not in use and before cleaning.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Product Overview



The Neakasa Power Scrub-2 3-in-1 Wet/Dry Vacuum Cleaner, showcasing its main body and cleaning head.

Key Components:

- Main Unit with Handle
- Clean Water Tank (780ml capacity)
- Dirty Water Tank (700ml capacity)
- Roller Brush
- Charging Station
- Removable Li-ion Battery (3000 mAh)
- HEPA Filter



Illustration of the dual-tank system, showing the 780ml clean water tank and 700ml dirty water tank, which keeps clean and dirty water separate.

Setup

1. Assembly

1. Insert the handle into the main unit until it clicks securely into place.

2. Ensure the clean water tank and dirty water tank are correctly seated in their respective positions.

2. Charging the Battery

Before first use, fully charge the appliance. The removable 3000 mAh Li-ion battery takes approximately 3 hours for a full charge.

- Place the vacuum cleaner on its charging station.
- Connect the power adapter to the charging station and a wall outlet.
- The LCD display will indicate charging status.



The Neakasa Power Scrub-2 vacuum cleaner positioned on its charging station.

3. Filling the Clean Water Tank

1. Remove the clean water tank from the main unit.
2. Open the tank cap and fill with clean tap water. You may add a small amount of non-foaming floor cleaning solution if desired. Do not exceed the MAX fill line.
3. Close the cap securely and reinsert the tank into the main unit until it clicks.

Operating Instructions

1. Powering On/Off

Press the power button on the handle to turn the appliance on or off.

2. Selecting Cleaning Modes

The Neakasa Power Scrub-2 offers different cleaning modes for various needs:

- **Standard Mode:** Suitable for everyday cleaning and light dirt.
- **Max Mode:** Provides increased suction power for stubborn dirt and heavier messes. Press the mode button on the handle to switch between modes.

3. Cleaning Process

The appliance vacuums, mops, and dries simultaneously. Push the vacuum cleaner forward and pull it back slowly for optimal cleaning results. The roller brush is continuously moistened with clean water, and dirty water is collected in the separate dirty water tank.



The Neakasa Power Scrub-2 in use, effectively cleaning a hard floor surface.



The Neakasa Power Scrub-2 demonstrating its ability to clean close to wall edges.

4. LCD Display Indicators

The integrated LCD display provides real-time information about the appliance's status, including:

- Battery level
- Current cleaning mode (Standard/Max)
- Dirty water tank full indicator

- Self-cleaning status
- Water spray indicator



Close-up view of the Neakasa Power Scrub-2's LCD display, showing various operational indicators.

Self-Cleaning Function

The Neakasa Power Scrub-2 features a convenient one-touch self-cleaning function to maintain hygiene and performance of the roller brush.

How to Use:

1. After cleaning, place the vacuum cleaner back on its charging station.
2. Ensure there is sufficient clean water in the clean water tank.
3. Press the dedicated self-cleaning button (refer to the product diagram for location).
4. The appliance will automatically clean the roller brush, rinsing it with clean water and then vacuuming the dirty water into the dirty water tank.
5. Once the cycle is complete, empty the dirty water tank.



Diagram showing the self-cleaning process and the UV disinfection feature for the roller brush.

Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your Neakasa Power Scrub-2.

1. Emptying and Cleaning the Dirty Water Tank

Empty the dirty water tank after each use.

1. Remove the dirty water tank from the main unit.
2. Open the tank and dispose of the dirty water.
3. Rinse the tank thoroughly with clean water.
4. Allow the tank to air dry completely before reattaching.

2. Cleaning the Roller Brush

Even with the self-cleaning function, occasional manual cleaning of the roller brush is recommended.

1. Turn off the appliance and remove the dirty water tank.
2. Remove the roller brush cover and then the roller brush itself.
3. Rinse the roller brush under running water to remove any hair or debris. Use the provided cleaning tool if necessary.
4. Allow the roller brush to air dry completely before reinstalling.



Illustration showing the roller brush and its rotation for effective cleaning.

3. Cleaning the HEPA Filter

The HEPA filter should be cleaned regularly to maintain suction performance.

1. Remove the dirty water tank. The HEPA filter is located within or near the dirty water tank assembly.
2. Carefully remove the HEPA filter.
3. Tap the filter gently to remove loose dust. You may rinse it under running water, but ensure it is completely dry before reinstallation.
4. Reinstall the dry HEPA filter and the dirty water tank.



A close-up view of the removable HEPA filter, ready for cleaning or replacement.

Troubleshooting

If you encounter issues with your Neakasa Power Scrub-2, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on	Battery is not charged or not properly installed.	Ensure the battery is fully charged and correctly inserted.
Poor suction power	Dirty water tank is full, roller brush is clogged, or HEPA filter is dirty.	Empty and clean the dirty water tank. Clean the roller brush and HEPA filter.
Leaves streaks on the floor	Dirty roller brush, dirty water tank not emptied, or incorrect cleaning solution.	Clean the roller brush. Empty and rinse the dirty water tank. Use only recommended non-foaming cleaning solutions.
Water leakage	Water tanks not properly installed or caps not sealed.	Ensure both clean and dirty water tanks are securely in place and their caps are tightly closed.

Specifications

Feature	Specification
Brand	Neakasa
Model Number	Power Scrub-2
Color	White
Product Dimensions (L x W x H)	31 x 32 x 113 cm
Item Weight	4 Kilograms
Suction Power	18,000 Pa
Battery Type	Removable Li-ion

Feature	Specification
Battery Capacity	3000 mAh
Voltage	24 Volts
Runtime	Up to 30 minutes
Noise Level	76 Decibels
Clean Water Tank Capacity	780 ml
Dirty Water Tank Capacity	700 ml
Filter Type	HEPA Filter
Special Features	3-in-1 (Vacuum, Mop, Dry), Self-Cleaning, Dual Tank System, Edge Cleaning
Surface Recommendation	Hard floors (sealed waxed parquet, oiled, laminate, tile, PVC, vinyl)

Warranty and Support

Your Neakasa Power Scrub-2 3-in-1 Wet/Dry Vacuum Cleaner comes with a standard manufacturer's warranty. For detailed warranty information, please refer to the warranty card included in your product packaging or visit the official Neakasa website.

If you have any questions, require technical assistance, or need to report a problem, please contact Neakasa customer support. Contact details can typically be found on the product packaging, the official website, or your purchase receipt.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B4JZ7BKG

More documents and user manuals: **https://manuals.plus/**